



Model 10530



Model 10530

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	05244A	Bearing Housing	32.	741-0192	Flange Bearing w/ Flats
2.	618-0281A	Bracket Assembly: Auger Break	33.	741-0475	Plastic Bushing
3.	684-0090A	Impeller Assembly: 16"	34.	741-0494	Flange Bushing
4.	710-0371	Hex Lock Bolt 5/16-18 x .875"	35.	747-0980	Idler Rod: Auger
5.	710-0451	Carriage Bolt 5/16-18 x .750"	36.	754-0222A	V-Belt
6.	710-0459A	Hex Screw, Special 3/8-24 x 1.5"	37.	756-0178	Flat Idler
7.	710-0528	Hex Screw 5/16-18 x 1.25"	38.	756-0243	Pulley
8.	710-0604A	Self-Tapp. Screw 5/16-18 x .625"	39.	784-0385A	Idler Bracket: Auger
9.	710-0891	Shear Bolt 5/16-18 x 1.75"	40.	784-5076	Support Bracket
10.	711-0640	Stud	41.	784-5123	Chute Crank Bracket
11.	711-0677	Ferrule	42.	784-5710	Support Plate
12.	712-0116	Jam Nut 3/8-24	43.	784-5711	Chute Bracket
13.	712-0429	Hex Lock Nut 5/16-18	44.	618-0436	Gear Assembly
14.	712-3010	Hex Nut 5/16-18	45.	705-5206A	Spiral Assembly RH
15.	714-0104	Hairpin Clip	46.	705-5207A	Spiral Assembly LH
16.	714-0126	Key	47.	684-04006	Auger Housing Assembly
17.	714-0135	Key	48.	784-5697	Slide Shoe
18.	715-0118	Spiral Pin	49.	737-3000	Lube Fitting
19.	731-1696	Chute Adapter	50.	738-0491	Spiral Axle
20.	732-0858	Extension Spring	51.	736-0105	Bell Washer
21.	736-0119	Lock Washer	52.	784-0315	Bearing Housing
22.	736-0159	5/16 Washer	53.	784-5715A	Shave Plate
23.	736-0169	Lock Washer	54.	710-0389	Carriage Screw
24.	736-0174	Wave Washer	55.	710-3168	Carriage Bolt
25.	736-0242	Beleville Washer	56.	712-0798	Hex Nut 3/8-16
26.	736-0250	Flat Washer	57.	710-1260A	Screw, 5/16-18 x .75
27.	736-0271	Spring Washer	58.	712-0717	Insert Nut, 3/8-16
28.	736-3008	Flat Washer	59.	731-2643	Chute Clean-out Tool
30.	738-0281	Shoulder Screw	60.	731-2635	Mount, Chute Clean-out Tool
31.	741-04024	Self-Aligning Bearing			


Model 10530



Model 10530

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	05523	Pivot Support Bracket	46.	736-0163	Flat Washer
2.	750-1302A	Spacer, .6725 x 1.125 x 2.485	47.	736-0217	Lock Washer
3.	618-0279	Dogg Assembly LH	48.	736-0242	Bell Washer
4.	618-0280	Dogg Assembly RH	49.	710-0604A	Self-tapping Screw, 5/16-18 x .625
5.	618-0282B	Shaft Assembly	50.	736-0300	Flat Washer
6.	618-0296A	Friction Wheel Assembly	51.	736-0329	Lock Washer
7.	684-0162	Support Bracket Assembly	52.	736-0623	Flat Washer
8.	684-0161	Shift Arm Assembly	53.	712-0717	Nut Insert, 3/8-16
9.	684-0117	Shift Rod Assembly	54.	784-0404	Bearing Retainer Bracket
10.	684-0118	Auger Actuator Bracket Assy.	55.	784-0407	Axle Bearing Support Bracket
11.	684-0119	Drive Actuator Bracket Assy.	56.	738-0143	Shoulder Screw
12.	684-0120	Frame Assembly	57.	738-0279	Spindle: Drive Plate
13.	684-0122	Sprocket Assembly	58.	738-0924	Shoulder Screw 1/4-28 x .375"
14.	710-0195	Hex Screw, 1/4-28 x .625"	59.	741-0163A	Bearing Housing Assembly
15.	710-0538	Hex Screw, 5/16-18 x .625"	60.	714-0151A	Click Pin
16.	710-0599	Self-tapping Screw, 1/4-20 x .5	61.	741-0563	Ball Bearing
17.	710-0788	Self-tapping Screw, 1/4-20 x 1"	62.	741-0747	Ball Bearing
18.	710-1652	Self-tapping Screw, 1/4-20 x .625"	63.	746-0949A	Steer Cable
19.	710-3001	Hex Screw 3/8-16 x .880"	64.	746-0951	Auger Idler Cable
20.	710-3008	Hex Screw 5/16-18 x .75"	65.	747-0973	Drive Clutch Rod
21.	710-3103	Hex Screw 5/16-18 x 2"	66.	750-0903	Split Spacer
22.	710-3180	Hex Screw 5/16-18 x 1.75"	67.	750-0997	Spacer
23.	711-1191	Hex Shaft: Drive	68.	741-0748	Flange Bearing
24.	711-1193	Actuator Shaft	69.	737-3000	Lube Fitting, 3/16
25.	711-1194	Actuator Drive Shaft	70.	756-0344	Drive Pulley
26.	712-0116	Lock Nut	71.	756-0625	Roller Cable
27.	712-0138	Hex Nut 1/4-28	72.	784-0406	Frame Support Bracket
28.	712-0221	Jam Lock Nut	73.	784-0379	Frame Cover: Upper
29.	712-0429	Hex Lock Nut	74.	784-0380	Frame Cover: Lower
30.	712-0798	Hex Nut 3/8-16	75.	784-0384	Auger Cable Bracket
31.	712-3010	Hex Nut 5/16-18	76.	784-0403	Shift Bracket
32.	713-0284	Chain	77.	738-0975	Axle: Wheel
33.	713-0286	Chain	78.	784-5617A	Friction Plate
34.	713-0413	Sprocket	79.	735-0243B	Friction Wheel Rubber
35.	714-0101	Hairpin Clip	80.	718-0301A	Friction Wheel Hub
36.	714-0104	Hairpin Clip	81.	618-0063A	Friction Wheel Bearing
37.	714-0115	Cotter Pin	82.	634-0225-662	Wheel Assembly, LH
38.	714-0388	Key	—	734-2031	X-Trac Tire Only
39.	715-0249	Roll Pin	—	734-1124	Rim Only
40.	717-0302	Drive Plate	—	734-0255	Air Valve Only
41.	732-0121	Extension Spring	83.	634-0226-662	Wheel Assembly, RH
42.	732-0209	Extension Spring	—	734-2031	X-Trac Tire Only
43.	736-0119	Lock Washer 5/16	—	734-1124	Rim Only
44.	736-0158	Lock Washer 5/8	—	734-0255	Air Valve Only
45.	736-0160	Flat Washer			


Model 10530



Model 10530


Ref. No.	Part No.	Part Description
1.	646-0012	Cable Assembly: Auger/Drive
2.	684-0053B	Chute Crank Assembly, Lower
3.	705-5266	Chute Crank Bracket
4.	710-1879	Hex Screw, 3/8-16 x .88"
5.	710-1878	Hex Screw, 3/8-16 x 1.75"
6.	710-0458	Carriage Bolt 5/16-18 x 1.75"
7.	710-0572	Carriage Bolt 5/16-18 x 2.5"
8.	747-1136	Lamp Retainer
9.	710-3015	Hex Screw 1/4-20 x .75"
10.	711-0677	Ferrule
11.	712-0287	Hex Nut 1/4-20
12.	629-04010	Lamp Wire Harness
13.	712-3010	Hex Nut
14.	714-0101	Hairpin Clip
15.	714-0104	Hairpin Clip
16.	720-0201A	Chute Crank Knob
17.	720-0284	Knob
18.	726-0100	Push Cap
19.	736-0105	Bell Washer
20.	736-0185	Flat Washer
21.	736-0242	Beleville Washer
22.	736-0270	Bell Washer
23.	736-0275	Flat Washer
24.	741-0475	Plastic Bushing
25.	747-0624	Chute Crank
26.	747-0983	Lower Shift Rod
27.	747-0997	Upper Shift Rod
28.	749-0989A	Upper Handle LH
29.	749-0990A	Upper Handle RH
30.	749-0991	Lower Handle
31.	750-0963	Clutch Rod Connector
32.	710-1625	Oval C-Sunk Screw
33.	712-0127	Flat Weld Nut
34.	725-0157	Cable Tie
35.	746-0950	Trigger Control
36.	725-1658	Halogen Lamp
37.	705-5218	Handle Engagement RH
38.	705-5219	Handle Engagement LH
39.	710-1003	Special B Screw
40.	712-0271	Hex Sems Nut
41.	712-0429	Hex Lock Nut
42.	720-0232	Shift Knob
43.	731-04069	Handle Panel
44.	725-1672	Lens Assembly

Model 10530




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	07386	Washer	17.	738-0982	Shoulder Screw
2.	684-0123A	Belt Cover Bracket Assembly	18.	748-0234	Shoulder Spacer
3.	710-0191	Hex Screw 3/8-24 x 1.25"	19.	754-0131	V-Belt
4.	710-0237	Hex Screw 5/16-24 x .625"	20.	756-0240	Flat Idler
5.	710-1008	Self-tapping Sems Screw	21.	756-0241B	Double Pulley
6.	710-0607	TT Screw 5/16-18 x 0.5"	22.	784-5726	Idler Bracket
7.	710-0672	Hex Lock Screw 5/16-24 x 1.25"	23.	750-1148A	Spacer
8.	712-0116	Jam Nut	24.	748-0418	Spacer, .33 x 1.0 x .36
9.	714-0118	Key	25.	717-0882A	Spacer
10.	731-2531	Belt Cover	26.	629-0071	Extension Cord: 110V, 3-prong
11.	732-0303	Extension Spring	27.	684-04011	Spark Plug Cap
12.	736-0159	5/16 Washer	28.	684-04014	Engine Shroud (Incl. Ref. 27)
13.	736-0217	Lock Washer	29.	710-04082	Screw, #10-16 x .75
14.	736-0242	Beleville Washer	30.	712-3004A	Flange Lock Nut, 5/16-18
15.	736-0264	Flat Washer			

Model 10530



Ref. No.	Part No.	Description
1.	710-0276	Carriage Screw
2.	710-0458	Carriage Bolt 5/16-18 x 1.75"
3.	710-0805	Hex Bolt 5/16-18 x 1.5"
4.	710-0896	Hex AB Screw 1/4-14 x .625"
5.	710-3015	Hex Screw 1/4-20 x .75"
6.	712-0429	Hex Lock Nut
7.	712-3027	Hex Flange Lock Nut
8.	731-0846C	Upper Chute
9.	731-0851A	Chute Flange Keeper
10.	731-1313C	Cable Guide: Chute Tilt
11.	731-0903D	Lower Chute
12.	784-5680	Handle Suppt. Bracket 5/8 RH
13.	736-0159	5/16 Washer
14.	736-0231	Flat Washer
15.	736-0506	Special Washer
16.	746-0902	Chute Control Cable
17.	746-0903	Chute Cable w/Clip
18.	784-5594	Cable Bracket
19.	784-5604	Chute Tilt Handle
20.	684-0102	Handle Panel Assembly w/ Tilt
21.	710-0459A	Hex Bolt 3/8-24 x 1.5"
22.	710-0599	TT Screw 1/4-20 x 0.5"
23.	711-0653	Clevis Pin
24.	712-0116	Jam Nut
25.	784-5682	Handle Suppt. Bracket 3/8 RH
26.	714-0104	Cotter Pin
27.	732-0145	Spring
28.	732-0193	Spring
29.	732-0746	Torsion Spring
30.	735-0199A	Rubber Bumper
31.	736-0105	Bell Washer
32.	784-5681	Handle Suppt. Bracket 3/8 LH
33.	736-0509	Special Washer
34.	747-0877	Cam Rod
35.	748-0362	Cam: Handle Lock
36.	748-0363	Pawl: Handle Lock
37.	784-5619A	Shift Handle
38.	784-5679	Handle Suppt. Bracket 5/8 LH

Model 10530



Ref. No.	Part No.	Description
1.	618-0246	Housing Assembly, RH
2.	618-0435	Housing Assembly, LH
3.	710-1260A	Screw, 5/16-18 x 0.75
4.	711-0908A	Axle, Auger
5.	711-1133	Shaft, Auger Drive
6.	714-0126	Key, Hi Pro, 3/16 x 3/4
7.	714-0135	#91 Woodruff Key 1/4 x 3/4
8.	716-0111	Snap Ring .875 Dia.
9.	717-0299	Gear, Worm, Double Thread LH
10.	717-1425	Gear, Worm, LH
11.	721-0145	Seal, Oil .875 ID
12.	721-0325	Plug, 1/4 x .437
13.	736-0266	Washer, Flat, 1.52 x 2.0
14.	736-0291	Washer, Flat, .88 x 1.38
15.	737-3000	Lube Fitting, 3/16 Drive
16.	738-0275	Shaft, Worm Gear
17.	741-0184	Bearing, Thrust .877
18.	741-0217	Sleeve Bearing, .877 x .125 x 1.11
19.	618-0436	Auger Gearbox Assembly Complete

NOTE: When rebuilding a gearbox assembly, include 3 oz. of Shell Alvania EP Lead-Free Grease (Part No. 737-0168).