


REPLACEMENT PARTS - MODEL TB4BP 4-CYCLE BACKPACK BLOWER

PPN 41CR4BPG966




Item	Part No.	Description
1	753-05669	Muffler Assembly (includes 2 & 26)
2	753-05670	Muffler Gasket
3	753-05377	Screw
4	753-05671	Rocker Cover
5	753-05672	Rocker Cover O-Ring
6	753-05784	Spark Plug
7	753-05673	Insulator Gasket
8	753-05248	Nut
9	753-05674	Insulator
10	791-181003	Screw
11	753-05675	Carburetor Gasket
12	753-06002	Carburetor
13	791-181751	Carburetor O-Ring
14	753-05253	Screw
15	753-05711	Air Cleaner Assembly (includes 16)
16	753-05677	Air Filter
17	753-05970	Throttle Cable

Item	Part No.	Description
18	753-05681	Cylinder Gasket
19	753-05635	Pawl Assembly
20	753-05400	Oil Plug
21	753-05682	Oil Fill Tube (includes 3)
22	753-05687	Nut
23	753-05688	Flywheel Assembly
24	753-06003	Module Assembly
25	753-05690	Lead Wire
26	791-182361	Muffler Screw
27	753-05674	Short Block Assembly
*	753-05297	Spark Arrestor

REPLACEMENT PARTS - MODEL TB4BP

4-CYCLE BACKPACK BLOWER

PPN 41CR4BPG966



Item	Part No.	Description
1	753-06000	Nozzle
2	753-05971	Lower Blower Tube
3	753-05975	Throttle Grip Assembly
4	753-05991	Upper Blower Tube
5	753-05640	Clamp
6	753-05641	Flex Tube
7	753-05990	Elbow Tube
8	753-06345	Grip
9	753-06141	Support System
10	753-05647	Nut
11	791-182678	Washer
12	753-05648	Insulator Mount
13	753-05786	Intake Cover
14	753-04595	Screw

Item	Part No.	Description
15	753-05658	Impeller Housing Assembly
16	791-180050	Nut
17	791-181003	Screw
18	753-05989	Impeller (includes 19)
19	791-182409	Washer
20	753-05661	Throttle Retaining Clip
21	753-05289	Fuel Cap
22	753-05662	Fuel Tank Assembly (includes 23)
23	753-05663	Stand
24	753-05660	Engine Cover Assembly
25	791-182348	Screw
26	753-06340	Hip Belt