



TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
SCHEMATIC



REPAIR PARTS

TRACTOR - - MODEL NUMBER 425014X92E (96014000100) ELECTRICAL




TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION
1	163465	Battery
2	74760412	Bolt Hex Hd 1/4-20 unc x 3/4
8	176689	Box Battery Fender
16	176138	Switch, Interlock
21	175688	Harness Asm Light W/4152j
22	4152J	Bulb Light #1156
24	4799J	Cable Battery 6 Ga. 11" red
25	146147	Cable Battery 6 Ga. w/16 wire red
26	175158	Fuse 20 AMP
27	73510400	Nut, Keps Hex 1/4-20 unc
28	4207J	Cable Ground 6 Ga. 12" black
29	192749	Switch Seat
30	193350	Switch Ign
33	140401	Key Ign Molded
34	110712X	Switch Light
40	193374	Harness Ign
41	71110408	Bolt Blk. Fin Hex 1/4-20 unc x 1/2
42	131563	Cover Terminal Red
43	192507	Solenoid
48	140844	Adapter Ammeter
52	141940	Protection Wire Loop
90	180449	Cover Battery Terminal
92	193465	Harness Pigtail Reverse Switch
93	192540	Screw Plastic 10-14 x 2.0
94	191834	Module Reverse ROS

NOTE: All component dimensions give in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)

CHASSIS AND ENCLOSURES




Chassis-Alpha_Stlt_3

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
CHASSIS AND ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION
1	174619	Chassis Stamping
2	176554	Drawbar
5	155272	Bumper Hood/Dash
9	193510X010	Dash
10	72140608	Bolt, Carriage 3/8-16 x 1
11	174996	Panel, Dash, L.H.
13	172105X010	Panel, Dash, R.H.
14	17490608	Screw Thdrol 3/8-16 x 1/2
17	187559X505	Hood Assembly
18	184921	Bumper Hood Large 1.75
24	74780616	Bolt Fin Hex 3/8-16 unc x 1 Gr. 5
25	19131312	Washer 13/32 x 13/16 x 12 Ga.
26	73800600	Nut
28	187598	Grille Lens Asm Laser (Includes Key Nos. 29 and 212)
29	187567X599	Lens
30	192526X505	Fender
31	136619	Bracket, Fender Support
33	179716X505	Footrest LH
34	179717X505	Footrest RH
35	72110606	Bolt Rdhd Sht Sqnk 3/8-16 x 3/4
37	17490508	Screw Thdrol 5/16-18 x 1/2 Tyl
38	175710	Bracket Asm. Pivot Mower Rear
39	187568	Bracket Pivot
64	154798	Dash Lower
114	158112	Keeper Belt Rear LH
115	17060620	Screw 3/8-16 x 1-1/4
142	175702	Plate Reinforcement
145	156524	Rod Pivot Chassis/Hood
206	170165	Bolt Shoulder 5/16 -18 TT
207	17670508	Screw 5/16-18 x 1/2
208	17670608	Screw Thdrol 3/8-16 x 1/2
209	17000612	Screw Hex Wsh Thdr 3/8-16 x 3/4
211	145212	Nut Hex Flange Lock
212	187569	Insert Lens Reflective
278	191611	Screw 10 x 3/4 Single Head-Hex
- -	5479J	Plug, Button
- -	187801	Plug Dome Plastic

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
GROUND DRIVE



drive-fender.stlt_46

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
GROUND DRIVE


KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle Peerless 206-544C (Order parts from transaxle manufacturer)
2	146682	Spring Brake Return
3	123666X	Pulley Transaxle
4	12000028	Ring Retainer
5	121520X	Strap Torque 30 Degrees
6	17060512	Screw 5/16-18 x 3/4
8	192706	Rod Shift Fender Adjust
10	76020416	Pin Cotter 1/8 x 1 CAD
11	105701X	Washer Plate Shift
13	74550412	Bolt 1/4-28unf Gr. 8 W/Patch
14	10040400	Washer Lock Hvy Helical
15	74490544	Bolt Hex FLGHD 5/16-18 Gr. 5
16	73800500	Nut Lock Hex W/Ins 5/16-18 UNC
18	74780616	Bolt Fin Hex 3/8-16 UNC x 1 Gr 5
19	73800600	Nut Lock Hex W/Ins 3/8-16 UNC
21	106933X	Knob
22	130804	Rod, Brake
24	73350600	Nut, Hex Jam 3/8-16 unc
25	106888X	Spring, Brake Rod
26	19131316	Washer 13/32 x 13/16 x 16 Ga.
27	76020412	Pin Cotter 1/8 x 3/4 CAD.
28	175765	Rod, Parking Brake
29	71673	Cap, Parking Brake
30	169592	Bracket, Transaxle
32	74760512	Bolt Hex Hd 5/16-18 UNC x 3/4
34	175578	Shaft, Foot Pedal
35	120183X	Bearing, Nylon
36	19211616	Washer
37	1572H	Pin, Roll
38	179114	Pulley, Composite, Flat
39	72110622	Bolt RDHD 3/8-16 UNC x 1 Gr. 5
41	175556	Keeper, Belt Idler
47	127783	Pulley, Idler, V-Groove
48	154407	Bellcrank, Clutch
49	123205X	Retainer, Belt
50	72110612	Bolt Hex Hd 3/8-16 x 1-1/2
51	73680600	Nut Crownlock 3/8-16 unc
52	73680500	Nut, Crownlock 5/16-18 unc
53	105710X	Link, Clutch
55	105709X	Spring, Return, Clutch
56	17060620	Screw 3/8-16 x 1.04
57	130801	V-Belt
59	169691	Keeper, Center Span
61	17120614	Screw . 3/8-16 x .875

KEY NO.	PART NO.	DESCRIPTION
62	8883R	Cover, Pedal
63	175410	Pulley, Engine
64	173937	Bolt Hex 7/16-20 x 4 x Gr. 5
65	10040700	Washer Lock
66	154778	Keeper Belt Engine Hydro
69	142432	Screw Hex Wsh Hi-Lo 1/4 x 1/2 unc
70	134683	Keeper Belt Engine
74	137057	Spacer
75	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
76	12000001	E-Ring
77	123583X	Key, Square
78	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
79	2228M	Key Woodruff
80	145090	Arm Shift
81	165594	Shaft Asm Cross Tapered
82	165711	Spring Torsion
83	19171216	Washer 17/32 x 3/4 x 16 Ga.
84	166231	Link Transaxle
85	150360	Nut Lock Center 1/4-20
89	192054X428	Console, Shift
96	4497H	Retainer Spring 1" Zinc/Cad
112	19091210	Washer 9/32 x 3/4 x 10 Ga.
113	127285X	Strap Torque 90 Degrees
116	72140608	Bolt Rdhd Sqneck 3/8-16 x 1.25
120	73900600	Nut Lock Flg 3/8-16
150	175456	Spacer Retainer
151	19133210	Washer 13/32 x 2 x 10 Ga.
156	166002	Washer Srrted 5/16ID x 1.125
158	165589	Bracket Shift Mount
159	183900	Hub Tapered Flange Shift Lt
161	72140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
162	73680400	Nut Crownlock 1/4-20 unc
163	74780416	Bolt Hex Fin 1/4-20 unc x 1 Gr 5
165	165623	Bracket Pivot Lever
166	17490510	Screw 5/16-18 x 5/8
168	165492	Bolt Shoulder 5/16-18 x .561
169	165580	Plate Fastening
170	187414	Keeper Belt T/A
197	169613	Nyliner Snap-In 5/8"ID
198	169593	Washer Nyl
202	72110614	Bolt Carr Sh 3/8-16 x 1-3/4 Gr.5
212	145212	Nut Hex Flg. Lock

NOTE: All component dimensions given in U.S.
inches 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)

STEERING ASSEMBLY




TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	186780	Steering Wheel
2	175131	Axle Assembly
3	169840	Spindle Assembly, L.H.
4	169839	Spindle Assembly, R.H.
5	6266H	Bearing, Race, Thrust, Hardened
6	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
7	19272016	Washer 27/32 x 1-1/4 x 16 Ga.
8	12000029	Ring, Klip
9	3366R	Bearing Col. Strg.
10	175121	Draglink
11	10040600	Washer, Lock
13	136518	Spacer Brg Axle Front
15	145212	Nut, Hexflange Lock
17	190753	Shaft, Steering
26	126847X	Bushing, Link, Drag
28	19131416	Washer 13/32 x 7/8 x 16 Ga.
29	17000612	Screw 3/8-16 x 3/4
30	76020412	Pin
32	192757	Rod, Tie
34	10040500	Washer Lock Hvy Hlcl Spr. 5/16
36	155099	Bushing, Steering
37	152927	Screw
38	192916	Insert, Steering Wheel
39	19113812	Washer 11/32 x 2-3/8
40	73540600	Nut Crownlock 3/8-24
41	186737	Adaptor, Steering Wheel
42	145054x428	Boot, Steering Shaft
43	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
44	190752	Extension Shaft Steering
46	121232X	Cap, Spindle
47	183226	Fitting Grease
65	160367	Spacer Brace Axle
67	72110618	Bolt Rdhd Sqnk 3/8-16 x 2-1/4
68	169827	Axle, Brace
71	175146	Steering Asm
82	169835	Bracket Susp Chassis Front
88	175118	Bolt Shoulder 7/16-20
91	175553	Clip Steering
95	188967	Washer Hardened .793 x 1.637 x .060
97	74780564	Bolt 5/16-18 unc x 4 Gr. 5

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
ENGINE




TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
ENGINE

KEY NO.	PART NO.	DESCRIPTION
1	170551	Control, Throttle/Choke
2	17720408	Screw, Hex Head, Thread Cutting 1/4-20 x 1/2
3	-----	Engine, Briggs Model No. 282H07 (Order parts from engine manufacturer)
4	137352	Muffler
13	165291	Gasket
14	148456	Tube Drain Oil Easy
23	169837	Shield Brn/Dbt Guard
25	167994	Clutch Cable Asm.
29	137180	Arrestor, Spark
31	187750	Tank, Fuel
32	140527	Cap Assembly, Fuel, Vented
33	123487X	Clamp, Hose
37	137040	Line, Fuel
38	181654	Plug, Drain Oil Easy
40	124028X	Bushing Snap
44	17670412	Screw, Hex Washer Head, Thd., Roll. 1/4-20 x 3/4
45	17000612	Screw Hex Wsh Thdr 3/8-16 x 3/4
46	19091416	Washer 9/32 x 7/8 x 16 Ga.
62	10010500	Washer Split
72	71070512	Screw Hex Head Cap 5/16-18 x 3/4
78	17060620	Screw 3/8-16 x 1-1/4
81	73510400	Nut Keps Hex 1/4-20 unc

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)

SEAT ASSEMBLY



seat_lt.knob_9


KEY PART NO.	NO.	DESCRIPTION
1	188705	Seat
2	180166	Bracket, Pivot, Seat
3	71110616	Bolt
4	19131610	Washer 13/32 x 1 x 10 Ga.
5	145006	Clip, Push-In Hinged
6	73800600	Nut
7	124181X	Spring, Seat
8	17000616	Screw 3/8-16 x 1-1/2
9	19131614	Washer 13/32 x 1 x 14 Ga.
10	180186	Pan, Seat
11	166369	Knob Seat
12	174648	Bracket, Switch Mounting

KEY PART NO.	NO.	DESCRIPTION
13	121248X	Bushing, Snap
14	72050412	Bolt, Carriage 1/4-20 x 1-1/2
15	134300	Spacer, Split .28 x .88
16	121250X	Spring
17	123976X	Locknut, Flange 1/4 Gr. 5
21	171852	Bolt, Shoulder 5/16-18 unc
22	73800500	Nut
24	19171912	Washer 17/32 x 1-3/16 x 12 Ga.

NOTE: All component dimensions given in U.S.
inches 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)


DECALS



KEY NO.	PART NO.	DESCRIPTION
1	193308	Decal, Oper. Instr.
2	184769	Decal, HP Engine
3	198348	Decal, Hood
5	194691	Decal, Hood Replacement
7	198358	Decal, Hood Side
10	157002	Decal, Fender Danger
11	179128	Decal, Deck "B" 42"
13	198350	Decal, Chassis
14	160396	Decal, V-Belt Schematic

KEY NO.	PART NO.	DESCRIPTION
20	145005	Decal, Battery Dngr/Psn Eng
--	138311	Decal, Lift Handle
--	179768X428	Pad, Footrest LH
--	179769X428	Pad, Footrest RH
--	198339	Owner's Manual


WHEELS & TIRES



KEY NO.	PART NO.	DESCRIPTION
1	59192	Valve Cap, Tire
2	65139	Stem, Valve
3	106222X	Tire, Front
4	59904	Tube, Front Tire (Not Provided, Service Item Only)
5	106732X624	Rim, Front
6	278H	Fitting, Grease (Front Wheel Only)
7	9040H	Bearing, Flange (Front Wheel Only)
8	106108X624	Rim, Rear
9	138468	Tire, Rear
10	7152J	Tube, Rear Tire (Not Provided, Service Item Only)
11	104757X428	Cap, Axle
--	144334	Sealant, Tire 10 oz.

NOTE: All component dimensions given in U.S.
inches 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
LIFT ASSEMBLY




TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
LIFT ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	159460	Lift Lever Inner Wire Assembly
2	159471	Shaft Assembly, Lift
3	105767X	Pin, Groove
4	12000002	E-Ring
5	19211621	Washer 21/32 x 1 x 21 Ga.
6	120183X	Bearing, Nylon
7	109413X	Grip, Handle
8	122365X	Button, Plunger, Red
11	139865	Link, Lift, L.H.
12	139866	Link, Lift, R.H.
13	4939M	Retainer Spring
15	173288	Link, Front
16	73350800	Nut, Hex, Jam 1/2-13 unc
17	175689	Trunnion
18	73800800	Locknut, Hex, with Washer Insert 1/2-13 unc
19	139868	Arm, Suspension, Rear
20	163552	Retainer Spring
31	169865	Bearing, Pvt, Lift
32	73540600	Nut, Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER 425014X92E (96014000100)

MOWER DECK



TRACTOR - - MODEL NUMBER 425014X92E (96014000100)
MOWER DECK

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	165892	Mower Deck Assembly, 42"	34	72110612	Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5
2	72140506	Bolt 5/16-18 x 3/4	36	131494	Pulley, Idler, Flat
3	138017	Bracket Assembly, Sway Bar, Front	40	73900600	Nut Lock Flg. 3/8-16 unc
4	165460	Bracket Sway Bar 38/42" eck	44	140088	Guard, Mandrel, L.H.
5	4939M	Retainer Spring	45	4497H	Retainer
6	178024	Bar Sway Deck	46	137729	Screw, Thd. Roll 1/4-20 x 5/8
8	850857	Bolt, Hex 3/8-24 x 1.25 Gr. 8	48	133944	Washer, Hardened
9	10030600	Washer, Lock	52	139888	Bolt, Shoulder 5/16-18 unc
10	140296	Washer, Hardened	53	184907	Arm Assembly, Pad, Brake
		(The following blades are available)	54	178515	Washer, Hardened
11	138971	Blade, 42" Hi-Lift	55	155046	Arm, Idler
		(For bagging or discharging)	56	165723	Spacer, Retainer
--	134149	Blade, Mulching Std.	59	141043	Guard, TUV Idler
		(For mulching mowers only)	67	149846	Knob Custom Oval
--	139775	Blade, 42" Mulching Premium	68	144959	V-Belt
		(For better wear when mulching)	142	165890	Arm Spring Brake Mower
13	137645	Shaft Assembly, Mandrel, Vented	143	157109	Bracket Arm Idler 42"
14	128774	Housing, Mandrel, Vented	144	158634	Keeper Belt 42" Clutch Cable
15	110485X	Bearing, Ball, Mandrel	145	165888	Pulley Idler Flat
16	174493	Stripper, Mower Deck	146	171977	Bolt Carriage Idler
18	72140505	Bolt, Carriage 5/16-18 x 5/8	147	131335	Spring Extension
19	132827	Bolt, Shoulder	148	169022	Spring Return Idler
20	159770	Baffle, Vortex	149	165898	Retainer Spring Yellow Zinc
21	73680500	Nut Crownlock 5/16-18 unc	150	19091210	Washer 9/32 x 3/4 x 10 Ga.
23	177563	Bracket, Deflector	152	169676	Cable Clutch 42 In
24	105304X	Cap, Sleeve	158	17720408	Screw Hex Thd Cut 1/4-20 x 1/2
25	123713X	Spring, Torsion, Deflector	159	72140614	Bolt Rdhd Sqn 3/8-16 unc x 1-3/4
26	110452X	Nut, Push	184	19131410	Washer 13/32 x 7/8 x 10 Ga.
27	130968X428	Shield, Deflector	185	188234	Head Assy. Cable Clutch
28	19111016	Washer 11/32 x 5/8 x 16 Ga.	--	130794	Mandrel Assembly (Includes housing, shaft and shaft hardware only-pulley not included)
29	131491	Rod, Hinge	--	171639	Replacement Mower, Complete
30	173984	Screw Thdrol DOD PT Hex			
31	187690	Washer, Spacer			
32	153535	Pulley, Mandrel			
33	178342	Nut, Toplock, Flanged			

NOTE: All component dimensions given in U.S.inches
1 inch = 25.4 mm