




IGNITION SWITCH


POSITION	CIRCUIT	"MAKE"
OFF	M+G+A1	
RUN/OVERRIDE	B+A1	
RUN	B+A1	L+A2
START	B+S+A1	

WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.


REMOVABLE
CONNECTIONS

NON-REMOVABLE
CONNECTIONS




KEY PART NO.	DESCRIPTION
1	BATTERY
3	SWITCH, IGN. D/LTA, P-I/N, ROS
4	KEY/CHAIN
9	SWITCH, INTLK CL, MWR, GRAY
10	SWITCH, INTERLOCK, NONC, GRAY
12	SWITCH, SEAT, DP, ROS
13	HARNES, IGN, ELECTSTART, LRV
15	SOLENOID
16	SCREW THD CUT 1/4-20 X 1/2 TY23
17	NUT KEPS HEX 1/4-20 UNC
18	873 51 04-00
19	532 41 66-94
20	532 42 12-99
21	CABLE STARTER
22	CABLE GROUND
23	SCREW 5/16-18 X 3/4
24	SCREW HEX M5X0.8, 9MM
25	NUT M5
	SCREW TORX #10-14 X .750
	FUSE, 10

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



KEY PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1	532 43 61-76 WELDMENT CHASSIS	69	532 43 74-27 BRACKET MOUNT CABLE
2	532 18 01-66 BRACKET, SEAT	70	532 44 20-68 CONSOLE CENTER
7	532 43 61-77 PLATE, ENGINE	71	532 43 78-57 CUPHOLDER
8	532 43 96-14 BRACKET, CHASSIS FRONT	72	532 18 51-61 THROTTLE ASM
10	532 44 18-05 PAN, SEAT	73	873 90 05-00 STUD FASTENER
11	532 19 93-70 BRACKET, SWITCHMOUNTING	74	873 90 04-00 NUT HEX FLANGE 1/4-20
13	532 44 20-71 COVER, FOOT REST	76	877 10 08-12 PIN CLEVIS
14	532 44 20-75 FOOTREST STRUCTURAL	77	876 02 02-08 PIN COTTER 1/16 X 1/2
15	532 44 20-69 SUPPORT, FOOT REST	78	532 43 70-56 BRACKET SUPPORT ROD
16	532 43 93-97 PANEL, ASM. CONTROL	79	532 43 70-57 BRAKE WELDMENT
18	---	80	532 43 96-93 BRAKE PEDAL COVER
19	532 43 68-61 KEEPER, BELT	81	532 43 73-74 WELDMENT/CONNECTING
22	532 44 21-30 DECK CLUTCH ASM	82	532 16 94-84 RETAINER CLIP
23	532 14 98-46 KNOB	83	532 43 93-66 STEERING TOWER REAR
24	532 41 63-58 SCREW #10 X 0.750 BOS THREAD	84	532 43 92-89 STEERING BOOT FRONT
25	872 14 04-24 BOLT	85	532 43 76-60 PARKING BRAKE HANDLE
26	873 51 04-00 NUT 1/4-20	86	532 43 87-62 ACTUATOR PARKING BRAKE
29	532 43 89-21 BOLT 7/16-20 X 1.00	87	532 16 54-92 SHOULDER BOLT
32	817 06 06-20 SCREW 3/8-16 X 1-1/4	88	532 42 81-10 CROSS BRACE
33	532 12 41-81 SPRING, SEAT	89	532 42 17-56 SCREW
34	532 12 37-40 SPRING	91	532 43 74-01 TRACK CLUTCH BRKT
35	872 05 04-12 BOLT 1/4-20 X 1 1/2	92	532 18 44-71 BOLT
39	532 13 43-00 SPACER	94	874 49 05-48 BRACKET CLUTCHING
40	532 12 12-48 BUSHING, NYLON SNAP	95	532 43 67-02 BUMPER REAR
41	532 12 98-76 NUT, LOCK	96	532 44 20-73 PULLEY ENGINE
42	532 17 18-52 BOLT, 5/16-18 SHOULDER	97	817 49 04-08 SCREW 1/4-20 X 1/2
43	873 80 05-00 SEAT	98	532 19 76-61 HANDLE SLIDE SEAT
44	532 43 66-12 NUT, 5/16-18	100	532 19 08-00 SPRING LATCH SEAT
45	817 00 05-12 BOLT, 5/16-18 X 3/4	101	874 76 06-12 BOLT FIN-HEX 3/8-16 UNC X 3/4
51	532 42 88-56 BRACKET	102	819 13 38-12 WASHER 13/32 X 2 3/8 X 12 GA
52	532 14 50-06 CLIP PUSH-IN HINGED	103	818 10 10-08 SCREW TORQ #10-14 X 1/2
53	532 43 85-62 SCREW	104	532 44 20-78 ENGINE COVER
54	532 43 64-73 DISC FRICTION	105	532 43 68-34 STRAP BATTERY
55	532 43 58-08 TORSION BODY UPPER	106	532 44 20-74 FRONT BRUSH GUARD
56	532 44 19-25 TORSION BODY LOWER	108	532 43 71-68 COVER REAR TRANSAXLE
57	532 43 64-79 SPRING HELIX	109	532 43 90-08 RETAINER BRAKE
59	819 18 24-11 WASHER 9/16ID X 1/2 20D11G	110	532 42 21-45 CONTROL PANEL HINGE PIN
60	532 43 78-56 FUEL TANK ASM	111	532 43 81-71 SHIELD, BRAKE CABLE
62	532 40 04-14 FUEL LINE	112	817 72 04-08 SCREW THD CUT
63	532 41 41-19 PURGE LINE	113	817 06 05-12 SCREW 5/16-18 X 3/4
64	532 12 34-87 CLAMP HOSE	115	532 43 92-85 BRACKET CANISTER CARB
65	532 43 02-19 FUEL CAP	116	532 43 92-86 CARB CANISTER
66	532 43 66-06 SCREW #10 X 0.500		
67	532 42 17-56 SHIELD HEAT		


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



LRV4_Drive_1.03


KEY PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1	WHEEL ASM (REAR)	70	GRIP LEVER
2	WASHER, 16 GA.	71	TUBE SHIFT LRV
3	E-CLIP	72	BOLT CARR.
6	SPACER AXLE	73	NUT CROWNOOK 1/4-20 UNC
7	HCS 1/4-20 X 1-3/4 GR 5 ZD	75	BRACKET MOUNT SHIFT
8	WELMENT SUPPORT AXLE RH	76	HUB SHIFT
9	SUBASM FINAL DRIVE	78	SPACER NYLON .866 X 1.25 X .250
10	SCREW 5/16 - 18 X 3/4	79	BOLT FINI, HEX 1/4-20 UNC X .75
11	BRACKET SUPPORT RH	80	WASHER LOCK H/V H/LCL SPRING
12	CASE CHAIN RH	81	WASHER 9/32 X 3/4 X 10 GA.
13	BEARING BALL 6207-SRS	84	WASHER 11/32 X 1.00 X 10 GA.
14	SPROCKET DRIVE 37 TOOTH	85	SPRING FRICTION PACK
15	TUBE INPUT HEX	86	BUSHING PACK FRICTION FD2
16	CHAIN PRIMARY DRIVE	87	WASHER PLASTIC
17	BEARING BALL 6204-3-2HS	88	STUD PACK FRICTION
18	CASE CHAIN LH	89	SPACER PACK FRICTION FD2
19	SCREW 10-24 X 5/8 PAN/HEAD TORX	90	WASHER 11/32 X 7/8 X 16 GA.
20	WASHER THRUST .75 X 1.230	91	SUBASM LINK SHIFT
22	WELMENT SUPPORT AXLE LH	92	WELDMENT SHIFT FD2
23	SCREW TORX #10 - 14 X 1/2	94	PLATE SHIFT
32	BLOCK TENSION CHAIN	95	DRUM CLUTCH MULTI DISC
33	SPRING ADJUSTER TENSION	96	SUBASM LINK SHIFT PRIMARY
34	PIN CLEVIS 5/16 X 2-1/2	97	NUT LOCK CENTER 1/4 - .28 FNTHD
36	SHAFT INPUT CLUTCH	98	SCREW 3/8-16X1-1/2 SMCML TAP/R
37	SPROCKET SPLINED 14 TOOTH	101	THREAD CUTTER
39	BEARING BALL	102	SWITCH SEAT
40	ARM BRAKE	103	HUB CENTER
41	SWITCH INTLK CL MWR GRAY 4 TERM	104	SPRING WAVE C125-H5
43	NUT LOCK HEX W/INSERT 5/16 - 18 UNC	105	SPACER RETAINER
44	COVER END HEX	106	RETAINER SPRING 1" ZINC/CAD
45	SPRING DRIVE	107	BUSHING 5/16 ID X 7/16 OD X 1/2
47	BRACKET MOUNT CABLE	108	CAP HUB AXLE 1.50 X 1.00
48	SCREW HEX HEAD WASH. 10-24 X 1.00	109	BRACKET SHIFTER FLEX
51	BRACKET SUPPORT LH	110	KEY SQUARE 2.0X .1845/1865
53	LOCK NUT, FLANGED	111	SCREW TORX #10-14 X .750
54	BEARING BALL	112	NUT LOCK FLANGE HEX
55	COVER WHEEL CLUTCH	113	BEARING FLANGE
57	WHEEL FRICTION	114	
59	PLATE CLUTCH DRIVE		
60	PLATE PRESSURE DRIVE		
62	PLATE CLUTCH BRAKE		
63	PLATE PRESSURE BRAKE		
65	PLATE PRESSURE MASTER		
66	BEARING THRUST 20MM		
67	PLATE THROWOUT		
68	BEARING BALL LOOSE		
69	COVER CLUTCH		

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm





KEY NO.	PART NO.	DESCRIPTION
1	532 44 20-64	WHEEL TUBE
2	812 00 00-01	E-CLIP
3	532 18 89-67	WASHER, HARDENED
4	532 12 17-49	WASHER, 1/4 X 3/4
5	532 43 61-81	SPINDLE, RH
6	532 12 49-31	WASHER, HARDENED THRUST
7	532 12 49-37	BUSHING, STEERING COLUMN
9	819 13 14-14	WASHER
10	532 42 80-57	WELDMENT, LWR STRG SHAFT
11	532 43 61-83	LINK, STRNG LH
12	532 43 61-84	LINK, STRNG RH
13	874 78 05-24	BOLT, 5/16-18 X 1 1/2
14	819 11 12-16	WASHER 11/32 X 3/4 X .16 GA
16	532 43 62-82	BUSHING SNAP
15	873 80 05-00	NUT, 5/16-18
17	532 43 61-78	SUPPORT, UPPER STEERING
19	817 00 05-12	BOLT, 5/16-18 X 3/4
20	532 42 80-45	CLIP RETAINER SPRING
23	532 43 77-47	ADAPTER, STEERING WHEEL
26	532 42 45-51	WHEEL, STEERING
27	532 42 45-53	CAP, STEERING WHEEL
28	532 19 98-49	CLIP RETAINER SPRING
29	532 43 61-80	SPINDLE LH
30	532 19 32-68	CAP HUB, AXLE
31	819 34 32-10	WASHER 1-1/16 X 2 X .10GA.
32	817 58 05-20	SCREW HEXWSH THD 5/16-18 X 1-3/4
34	532 43 61-82	SHAFT STEERING UPPER
35	532 44 20-66	BOOT LOWER STEERING WHEEL
36	532 19 60-75	SHAFT EXTENSION STEERING SPLINE
37	874 78 05-80	BOLT FIN HEX 5/16-18 UNC X 5 GR5
38	810 04 05-00	WASHER LOCK HYV HLCL SPR 5/16
39	819 11 38-12	WASHER
41	532 43 65-90	FOAM SHAFT STEERING
42	532 42 10-76	PIN, 5/64 X 3/4 COTTER
43	873 54 05-00	CROWN LOCK NUT 5/16-24 UNF
44	532 42 80-44	BUSHING

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



KEY NO.	PART NO.	DESCRIPTION
1	532 43 66-48	DECK
2	532 19 28-70	MANDREL ASM
3	532 43 68-56	KEEPER, BELT
4	532 43 68-55	PULLEY, MANDREL
5	532 44 15-97	BELT
6	532 43 68-63	COVER, MANDREL
7	532 43 68-91	LIFT ASM, DECK
10	532 43 96-38	DEFLECTOR
12	532 43 66-47	PIN, HINGE
13	532 43 74-62	SPRING, TORSION
14	532 19 51-85	ARM, MOWER SUPPORT
17	819 19 19-12	WASHER
18	532 19 42-09	PIN
19	532 19 65-39	BOLT, SHOULDER
20	532 19 42-08	PIN COTTER 5/16 BOW TIE LOCK
22	532 44 15-98	LINK ASM DECK
25	532 12 47-88	RETAINER SPRING 1"
26	532 18 76-90	SPACER, MANDREL
27	532 17 39-84	BOLT, MANDREL
28	532 40 02-34	NUT FLANGE LOCK TOP
29	532 41 92-73	BLADE
30	532 19 30-03	BOLT, BLADE
31	532 19 31-97	PULLEY, IDLER
32	532 14 10-43	GUARD, IDLER TUV
34	872 11 06-12	BOLT, 3/8-16 X 1 1/2
35	532 19 94-70	ARM, BRAKE
36	532 13 77-29	SCREW THD ROLL 1/4-20 X 5/8
37	873 90 06-00	NUT, 3/8-16 FLANGE
40	819 17 16-16	WASHER, 16 GA.
48	532 43 68-57	ARM CLUTCHING
49	532 19 90-92	SPACER RETAINER
50	817 00 06-16	SCREW 3/8-16 X 1
52	817 60 04-06	SPRING RETURN DECK
53	532 40 18-72	E-RING 5/16
55	532 43 79-88	ROD ANTI-SWAY
56	532 43 68-62	WASHER 13/32 X 13/16 X 12 GA
57	819 13 13-12	GUARD TUV IDLER
59	532 43 68-58	MULCH COVER ASM
61	532 43 79-47	TRUNION SUSPENSION ARM
62	532 17 62-05	NUT LIFT LINK 7/16-20
63	532 17 59-94	SCREW THDROL 3/8-16 X 1/2
64	817 67 06-08	

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



KEY PART NO.	PART NO.	DESCRIPTION
1	532 44 14-14	DECAL, STEERING WHEEL
2	532 42 15-43	DECAL, V-BELT SCH 30"
3	532 42 51-12	DECAL, WARN. DEFLECT/CTFGR
4	532 44 14-15	DECAL, DECK
5	532 40 88-07	DECAL, ENGINE H.P.
6	532 42 41-02	DECAL, WARNING SPARK ARRESTOR
--	532 44 19-65	MANUAL OWNERS ENGLISH
--	532 44 19-66	MANUAL OWNERS SPANISH

NOTE: All component dimensions given in U.S. inches
1 inch = 25,4 mm