



TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73 DECALS



KEY NO.	PART NO.	DESCRIPTION
1	197538	Decal, Hood RH
2	197540	Decal, Hood LH
3	419771	Decal, Side Panel
4	196674	Decal, Fender
5	408834	Decal, Eng H.P.
6	411658	Decal, Fender Operator's
7	419778	Decal, Lower Dash
8	170563	Decal, Warning
9	145005	Decal, Battery Dnge/Poi

KEY NO.	PART NO.	DESCRIPTION
11	411630	Decal, Replacement
13	196673	Decal, Steering Wheel
14	160396	Decal, Mower Schematic
--	166960	Decal, Bypass
--	400981X428	Pad, Footrest Control
--	193226X428	Pad, Footrest, LH
--	419764	Manual, Operator's (Eng/French)
--	419765	Manual, Parts (Eng/French)

WHEELS AND TIRES




KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap, Valve, Tire
2	65139	Stem, Valve
3	106732X624	Rim Assembly, Front
4	59904	Tube, Front
5	106222X	Tire, Front
6	278H	Fitting, Grease
7	9040H	Bearing, Flange
8	104757X428	Cap, Axle (Front Wheel Only)
9	106268X	Tire R 18 x 9.5-8 Turf Saver
--	420531	Tire R 18 x 9.5-8 Turf Saver LT
10	7152J	Tube, Rear
11	106108X624	Rim Assembly, Rear
--	144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
SCHEMATIC



SCH11

NOTE
YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.




IGNITION SWITCH

POSITION	CIRCUIT "MAKE"
OFF	M+G+A1
RUN/OVERRIDE	B+A1
RUN	B+A1 L+A2
START	B + S + A1



CHASSIS HARNESS
CONNECTOR
(MATING SIDE)



DASH HARNESS
CONNECTOR
(MATING SIDE)




WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
ELECTRICAL

T04S




TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION
1	163465	Battery
2	74760412	Bolt Hex Head 1/4-20 x 3/4
8	193228	Box Battery
16	176138	Switch Interlock Push-In
21	183759	Harness Socket Light w/4152J
22	4152J	Bulb Light
25	401662	Cable Starter
26	175158	Fuse
27	73510400	Nut Keps Hex 1/4-20 unc
28	198885	Cable, Ground
29	401545	Switch, Seat
30	193350	Switch, Ignition
33	411935	Key/Chain
34	110712X	Switch Light/Reset
40	401098	Harness Ignition Dash
41	17720408	Screw Thd Cut 1/4-20 x 1/2
42	131563	Cover, Terminal
43	192507	Solenoid
46	401763	Gauge SRVCMNDR HRMTR
55	17060512	Screw Thdrol 5/16-18 x 3/4 TYTT
71	400449	Harness Ignition
79	175242	Socket Asm. Bulb Twistlock
87	197802	Switch Interlock Clutch Cable
90	400725	Cover Terminal Battery
141	416977	Kit T2 ROS

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73

CHASSIS




Chassis-tex_elite-sv pro_9_r1

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
CHASSIS

KEY NO.	PART NO.	DESCRIPTION
2	194263	Drawbar
5	401715X428	Dash
14	183393X505	Hood
15	183834X599	Lens Grille LH
18	197482	Grille Asm.
25	183835X599	Lens Grille RH
36	17060512	Screw 5/16-18 x 3/4
37	414879X505	Fender
68	17490508	Screw THDROL 5/16-18 x 1/2
130	416358	Screw #10 x 0.750 BOS Thread
137	184921	Bumper Hood
138	193224X428	Cupholder
150	189350	Duct Heat Hood
151	407807	Bracket Pivot
152	194329	Shield Browning/Debris
159	17000612	Screw Hexwsh Thdrol 3/8-16 x 3/4
162	142432	Screw Hex Wsh Hi-Lo 1/4 x 1/2 unc
175	193243	Crossmember
176	400776	Screw 10-24 x 5/8 Wshd Qdrx
177	195227	Bushing Steering
180	194260	Chassis
181	193102X428	Bushing Mtg. Fender Crgo.
182	193057	Dash Lower
183	74780520	Bolt Fin Hex 5/16-18 x 1-1/4
186	183829X428	Insert Grille
194	73900500	Nut Lock Hex Flange 5/16-18
196	414579	Console Asm. Deck Lift
197	409167	Rod Pivot Chassis
207	183833	Bezel RH
208	183832	Bezel LH
228	195161	Stud Fastener
235	406129	Spacer Fender
236	73930500	Nut Centerlock 5/16-18 unc
287	17600406	Screw Hex Washead 1/4-20 x 3/8

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
DRIVE




Drive-tex_T2_pedal_2_r2

**TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
DRIVE**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle, Hydro Gear T2 (Internal Parts Not Available)	163	413322	Rod Pedal Control
2	123583X	Key	166	197290	Nut Push .625
15	19131316	Washer 13/32 x 13/16 x 16 Ga.	167	405257	Latch Brake Parking
17	197296	Spring, Brake	170	413430	Keeper Belt Centerspan
26	199679	Spring Return Cruise	171	72110622	Bolt
29	408391	Rod, Brake	183	156972	Spacer Axle
33	12000001	Ring E	184	198403X505	Handle Parking Brake
35	197722	Rod, Brake, Park	185	72110620	Bolt
37	121749X	Washer 25/32 x 1-1/4 x 16 Ga.	186	194321	Spacer Retainer
42	8883R	Cover, Foot Pedal	187	19133210	Washer
49	72110614	Bolt	188	194323	Link Clutch Ground Drive
50	194327	Pulley Idler Flat	189	194317	Bellcrank Ground Drive
51	73900600	Lock Nut 3/8-16	190	194318	Keeper Bellcrank Ground Drive
52	194326	Idler V-Groove 910" Offset	205	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
56	125907X	V-Belt, Drive	206	197867	Bracket Mount Latch Cruise
64	197865	Shaft Asm. Pedal Brake Control	207	197868	Latch Control Cruise
73	74490544	Bolt 5/16-18 Gr. 5	208	197869	Gear Sector Control Cruise
80	408393	Strap Torque	209	400769	Rod Control Cruise
92	74760520	Bolt Fin Hex 5/16-18 unc x 1.25	210	400980	Rockr Asm. Pdeal Control
99	408418	Rod Asm. Bypass	211	120183X	Bearing Nylon
114	73800500	Nut Lock 5/16-18 unc	213	400799 x428	Knob Control Cruise
116	73900500	Nut Lock Hex Flange 5/16-18	214	197302 x428	Pad Pedal Forward
121	175611	Bracket Strap Torque	215	197301 x428	Pad Pedal Reverse
122	72010520	Bolt 5/16-18 x 2.50	221	403187	Retainer Spring Clip Handle
125	17000512	Screw 5/16-18 x 3/4	222	79212010	Washer 21/32 x 1-1/4 10 Ga.
153	4497H	Retainer Spring	231	407287	Idler V-Groove 1.688" Offset
159	76020412	Pin Cotter 1/8 x 3/4			
160	169484	Retainer Clip			
161	105709X	Spring, Return, Clutch			
162	408784	Adapter Transaxle			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
ENGINE**



TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73 ENGINE

KEY NO.	PART NO.	DESCRIPTION
1	- - - - -	Engine B&S Model No. 31P677
2	137352	Muffler
9	194319	Keeper Belt Engine
12	405140	Pulley Engine
15	407489	Tank Fuel
18	197725	Cap Asm
20	176636X428	Control Throttle
21	416358	Screw #10 x .750 BOS Thread
28	401137	Fuel Line
29	137180	Spark Arrester Kit
37	123487X	Clamp Hose
42	10040700	Washer Lock 7/16
45	73510400	Nut Keps Hex 1/4-20 unc
69	165291	Gasket
79	192334	Screw Socket HD 5/16-18 x .75
81	148456	Tube Drain Oil Easy
82	181654	Plug Drain Oil
84	17060620	Screw 3/8-16 x 1-1/4
85	173937	Bolt 7/16-20 x 4 x GR 5-1.5
90	17000616	Screw 3/8-16 x 1
96	19091416	Washer 9/32 x 7/8 x 16 Ga
97	17670412	Screw Hexwsh Thdrol 1/4-20 x 3/4

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm


For engine service and replacement parts, call the toll free
number for your engine manufacturer listed below:

Briggs & Stratton 1-800-233-3723

ENGINE POWER RATING INFORMATION

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J11940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-5). Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net horsepower). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
STEERING ASSEMBLY




Steering-tex_LEGND2_8

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	186093X428	Wheel, Steering	53	188967	Washer Hardened .793x1.637x.060
2	184706	Axle Asm., Front	54	74760636	Bolt Hex 3/8-16 unc x 2-1/4
4	403087	Spindle Asm., LH	55	414736	Spacer Brace Axle
5	403088	Spindle Asm., RH	57	407465	Bracket Upstop
6	6266H	Bearing, Race Thrust Harden	58	194747	Bolt Shoulder Sector Pivot CFM
7	121748X	Washer 25/32 x 1-5/8 x 16 Ga.	59	194748	Washer Thrust Sector Steering
8	12000029	Ring, Clip #T5304-75	60	73971000	Nut Flange Lock 5/8-11
9	121232X	Cap, Spindle	61	194740	Draglink, LH
13	121749X	Washer 25/32 x 1-1/4 x 16 Ga.	62	194741	Draglink, RH
14	10040600	Washer, Lock Hvy Hlcl Spr 3/8	63	17000512	Screw 5/16-18 x 3/4
15	73540600	Nut, Crown Lock 3/8-24 unf	64	199849	Retainer Clip Spring Steering
16	408219	Shaft Steering	65	194734	Brace Axle Front
19	194729	Plate Steering	66	71020748	Bolt Hex Fghd 7/16-14 x 3 Serr
20	199743X428	Boot, Steering	67	194737	Bushing PM Front Axle
21	186737	Adapter, Wheel Steering	68	73900700	Nut Lock Flange 7/16-14 Gr. 5
22	194845	Bushing, Strg. Blk	69	199162	Washer 1.5 x .505 x .118
26	186095X428	Insert, Wheel Steering	70	196197	Bracket Deck Susp. Front
28	17000612	Screw 3/8-16 x 3/4	78	57079	Washer Thrust .515 x .750 x .033
35	194732	Gear, Sector Plate			
45	19183812	Washer 9/16 ID x 2-3/8 x 12 Ga.			
50	73900600	Nut Lock 3/8-16 unc			
51	73940800	Nut Hex Jam Toplock 1/2-20 unf			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
SEAT ASSEMBLY




seat-tex_7A-vgt

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	406623	Seat	37	73800500	Nut, Lock 5/16-18 unc
2	180166	Bracket Pivot Fender	40	197661	Handle Slide Seat
3	140675	Strap, Asm Fender	41	198200	Spring Latch Seat
6	73800600	Nut, Lock w/Ins. 3/8-16 unc	43	74760612	Bolt Fin Hex 3/8-16 unc x 3/4
7	124181X	Spring, Seat Cprsn	44	19133812	Washer 13/32 x 2-3/8 x 12 Ga.
8	171877	Bolt 5/16-18 unc x 3/4 w/Sems			
10	196977	Pan, Seat			
21	171852	Bolt, Shoulder 5/16-18			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
MOWER DECK




46_tex_lt_pred_12

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
MOWER DECK

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	405050	Mower Housing	63	199477	Arm Brake Mower
2	405506	Cover Mandrel RH	64	405138	Linkage Brake
3	405507	Cover Mandrel LH	67	198398X428	Handle, Clutch Cable
6	195186	Arm Suspension	68	405143	V-Belt
7	416358	Screw #10 x 0.750 BOS Thread	69	72140505	Bolt
8	193003	Bolt/Washer Asm 7/16-20 unf	70	199779	Clutch Asm. Manual
11	405380	Blade Mower	113	17000510	Screw 5/16-18
13	192872	Shaft Assembly, Mandrel	116	4898H	Bolt, Shoulder
14	187281	Housing, Mandrel	117	188606	Wheel, Gauge
15	110485X	Bearing, Ball, Mandrel	118	73930600	Nut, Crownlock 3/8-1
19	196539	Bolt, Shoulder	119	19121414	Washer 13/32 x 7/8 x 14 Ga.
21	73680500	Nut	122	197258	Keeper Belt Eng. LH
23	192557	Bracket, Deflector	123	197259	Keeper Belt Eng. RH
24	105304X	Cap, Sleeve	144	199204	Keeper Belt
25	197026	Spring, Torsion, Deflector	145	197379	Pulley Idler
26	110452X	Nut, Push	147	401872	Spring Return
27	405357	Shield, Deflector	152	408714	Cable Clutch Manual w/Spr.
29	131491	Rod, Hinge	188	195161	Stud Fastener
30	173984	Screw Thdrol Rolling Wsh Hd	189	73900500	Nut Lock Hex Flange
31	187690	Washer, Spacer	195	17000612	Screw 3/8-16 x 3/4
32	197473	Pulley, Mandrel	197	19131312	Washer 13/32 x 13/16 x 12 Ga.
33	400234	Nut, Toplock, Flanged	198	403149	Baffle Center Front
34	72110612	Bolt Carr Sh. 3/8-16 x 1-1/2 Gr. 5	199	403150	Baffle Front RH
36	193197	Pulley, Idler, Flat	200	413524	Washer 13/32 x 1 x 1/2 11 Ga.
37	19131316	Washer 13/32 x 13/16 x 16 Ga.	208	17670608	Screw 3/8-16 x 1/2
38	199189	Keeper Belt LH Mandrel	240	74520636	Bolt Fin Hex 3/8-16 x 2-1/4 Gr. 5
40	73900600	Nut, Lock Flg. 3/8-16 unc	- -	192870	Mandrel Assembly (Includes housing, shaft assembly, and bearing only - pulley/nut/washer and blade bolt/washers not included)
42	198410	Spring Torsion Brake	- -	408316	Replacement Mower, Complete
43	197256	Spring Torsion Retainer			
46	137729	Screw			
47	197250	Bracket Clutch Cable			
55	197249	Arm, Idler			
56	199092	Spacer, Retainer			
57	17000616	Screw Hexwsh Thd 3/8-16 x 1			
59	141043	Guard, Tuv Idler (94)			
60	199471	Arm Brake Mower			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. XT195H46YT (96042007300), PRODUCT NO. 960 42 00-73
MOWER LIFT



lift-tex_6

KEY NO.	PART NO.	DESCRIPTION
2	195223	Shaft Asm., Lift
3	195231	Lever Asm., Lift RH
7	196492X428	Grip, Lever
10	196314	Spring Torsion
87	194209	Pin Cotter 7/16 Bow Tie Lock
88	410710	Spring Lift Assist
89	19191912	Washer Clear Zinc
90	194208	Pin Cotter 5/16 Bow Tie Lock

KEY NO.	PART NO.	DESCRIPTION
91	195181	Link Asm. Lift Rear
97	17000612	Screw 3/8-16 x .75 Smgml Tap/R.Z
98	195270	Link Lift Susp. Front Mower
100	73930600	Nut Centerlock 3/8-16 unc

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm