





ROTARY LAWN MOWER -- MODEL NUMBER 961470009 (MFG. ID. NUMBER 96147000901)

PARTS LIST FOR PAGE 2

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1	403196 Handle, Upper (Includes Foam Grip)	23	163183 Bolt, Hex Head 5/16-18 x 5/8	39	410684 Grassbag
2	193664X479 Handle, Lower	24	73800500 Nut, Hex, with Lockwasher Insert 5/16-18	40	407453 Frame, Grassbag
3	405416 Spring, Rear Door, RH	25	161333 Baffle, Side	41	404763 Danger Decal
4	194788 Rope Guide	26	163409 Screw #12 x 5/8	42	54583 Screw
5	132004 Nut, Hex, with Lockwasher Insert 1/4-20	27	408442 Skirt, Rear	45	183058X428 Mulcher Door Assembly
6	66426 Wire, Tie	28	88652 Screw, Hinge 1/4-20 x 1.25	46	169699X428 Discharge Guard
7	191574 Bolt, Handle 5/16-18 x 2-5/8	29	194953 Key Start Switch Assembly (Includes Key)	47	Nut, Hex
8	189713X428 Knob, Handle	30	189179 Blade Adapter / Pulley	48	188839X004 Mounting Bracket, Debris Shield
9	194199X428 Control Bar	31	406712 Blade, 21"	58	182003 Clip, Packaging
10	188821 Pin, Handle Adjustment	32	851074 Washer	59	186362 Grip, Foam
11	751153 Nut, Hex	33	850263 Washer, Lock	60	182226 Spring, Return
12	51793 Cotter, Hairpin	34	851084 Bolt, Hex Head	61	163409 Screw, Hi-Lo Thread
13	405415 Spring, Rear Door, LH	35	405843 Debris Shield	62	408002 Battery Box
14	750634 Screw	36	192325 Bolt	63	189589 Battery
15	850733X004 Bracket, Upstop	37	150406 Bolt, Engine	64	190097 Battery Charger
16	401815X428 Rear Door Assembly	38	---	65	186159 Screw
17	184193 Bolt, Rear Door			67	180331 Key
18	198170 Plug, Mulcher			96	197991 Clip, Cable
19	411581 Kit, Housing			--	404764 Warning Decal (not shown)
20	193917X479 Handle Bracket Assembly, LH			--	193733 Operator's Manual, English
21	193916X479 Handle Bracket Assembly, RH			--	193736 Operator's Manual, French
22	150078 Screw, Hex Washer Head			--	412668 Repair Parts Manual, English/French

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.



ROTARY LAWN MOWER - - MODEL NUMBER 961470009 (MFG. ID. NUMBER 96147000901)

*****PARTS LIST FOR PAGE 1*****

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1	404846 Drive Control Assembly (Includes Cable)	39	407059 Bolt, Shoulder, Semi-Gimlett Point
2	194185X428 Bar, Drive Control	40	193909X427 Wheel 8 x 2
3	191730 Nut, Hex	41	404835 Pinion
4	199687 Screw	44	406580 V-Belt
11	406558 Spring, Return	45	404845 Pawl
13	404839 Gear Case Assembly, Complete	47	67725 Washer
14	193443 Pulley, Drive	49	163409 Screw, Hi-Lo Thread
16	407147 Rod, Connecting	50	404832X004 Belt Keeper
17	404942 Spring, Extension	60	412747 Case, Lower
18	193663X004 Spring, Selector	61	412736 Case, Upper
19	189808X428 Knob, Selector Spring	62	412757 Shaft, Output, Long
20	12000022 E-Ring 7/8	63	183508 Seal, Output Shaft
22	404838 Bearing, Ball	64	183511 Bushing
23	161118X004 Retainer, Drive Assembly	65	183509 Washer
24	57808 Screw, Tapping, Hex Head 1/4-20 x .75	66	183514 Seal, Worm Shaft
25	408001X428 Cover Drive	67	183506 Bearing, Ball
26	750634 Screw, Threaded, Rolled #10-25 x .50	68	412742 Gear, 28 Teeth
27	52160 Washer, Shim (as required)	69	412739 Fixed Dog Clutch, LH
28	12000058 E-Ring 7/16	70	412741 Pin, Output Shaft
29	189403 Cover, Dust, Wheel	71	412740 Movable Dog Clutch, LH
32	405744X427 Wheel 9 x 2	72	412756 Shaft, Output, Short
33	409148 Nut, Flangelock 3/8-16	73	183513 Screw, Case
34	851226 Washer	75	412746 Pin, Worm Shaft
35	403102X004 Shaft Assembly, Rear	76	412744 Fixed Dog Clutch, RH
36	407175X004 Shaft Assembly, Front	77	412743 Movable Dog Clutch, RH
37	161463 Retainer, Front Shaft	78	410731 Spring, Leaf
38	163409 Screw #12 x 5/8	79	412737 Shaft, Worm

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.
IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.