


TONDEUSE À GAZON ROTATIVE - NO. DE MODÈLE 961470010 (NO. DE MFG. 96147001000)




ROTARY LAWN MOWER - - MODEL NUMBER 961470010 (MFG. ID. NUMBER 96147001000)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	403196	Handle, Upper (Includes Foam Grip)	25	161333	Baffle, Side	46	169699X428	Discharge Guard
2	193664X479	Handle, Lower	26	163409	Screw #12 x 5/8	47	88349	Nut, Hex
3	405416	Spring, Rear Door, RH	27	192876	Skirt, Rear	48	188839X004	Mounting Bracket, Debris Shield
4	194788	Rope Guide	28	88652	Screw, Hinge 1/4-20 x 1.25	50	57808	Screw
5	132004	Nut, Hex, with Lockwasher Insert 1/4-20	29	194953	Key Start Switch Assembly (Includes Key)	51	193791	Pulley, V-Groove, Idler
6	66426	Wire, Tie	30	189179	Blade Adapter / Pulley	52	145212	Flanged Nut
7	191574	Bolt, Handle 5/16-18 x 2-5/8	31	406712	Blade, 21"	53	155552	Locknut
8	189713X428	Knob, Handle	32	851074	Washer	54	193792X004	Idler Arm
9	194199X428	Control Bar	33	850263	Washer, Lock	55	166043	Idler Pulley
10	188821	Pin, Handle Adjustment	34	851084	Bolt, Hex Head	56	160829	Shoulder Bolt
11	73930500	Nut, Hex	35	188786	Debris Shield	57	193315	Bracket Assembly
12	51793	Cotter, Hairpin	36	192325	Bolt	59	186362	Grip, Foam
13	405415	Spring, Rear Door, LH	37	150406	Bolt, Engine	60	182226	Spring, Return
14	750634	Screw	38	---	Engine, Briggs & Stratton, Model Number 125T05 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)	61	17411318	Screw
15	850733X004	Bracket, Upstop	39	410684	Grassbag	62	195743	Battery Box
16	401815X428	Rear Door Assembly	40	407453	Frame, Grassbag	63	189589	Battery
17	184193	Bolt, Rear Door	41	404763	Danger Decal	64	190097	Battery Charger
18	198170	Plug, Mulcher	42	54583	Screw	65	186159	Screw
19	411727	Kit, Housing	45	183058X428	Mulcher Door Assembly	67	180331	Key
20	192980X479	Handle Bracket Assembly, LH				96	197991	Clip, Cable
21	192979X479	Handle Bracket Assembly, RH				--	404764	Warning Decal (not shown)
22	150078	Screw, Hex Washer Head				--	193733	Operator's Manual, English
23	163183	Bolt, Hex Head 5/16-18 x 5/8				--	193736	Operator's Manual, French
24	73800500	Nut, Hex, with Lockwasher Insert 5/16-18				--	411726	Repair Parts Manual, English/French

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

TONDEUSE À GAZON ROTATIVE - NO. DE MODÈLE 961470010 (NO. DE MFG. 96147001000)



ROTARY LAWN MOWER - - MODEL NUMBER 961470010 (MFG. ID. NUMBER 96147001000)

KEY NO.	PART NO.	DESCRIPTION
1	400162	Drive Control Assembly (Includes Cable)
2	194185X428	Bar, Drive Control
3	191730	Nut, Hex
4	199687	Screw
11	188291	Spring, Torsion
12	187653	Screw
13	193354	Gear Case Assembly, Complete
14	193443	Pulley, Drive
15	410290	Kit, Wheel Adjuster Assembly, RH (Includes Knob and Bearing)
16	410288	Kit, Wheel Adjuster Assembly, LH (Includes Knob and Bearing)
17	166785	Nut, Hex
18	401621X004	Spring, Selector
19	87877	Knob, Selector Spring
20	407494X005	Bracket, Wheel Adjusting
21	401638	Bolt, Shoulder
22	169911	Bearing, Ball
23	401175X004	Axle Arm Assembly, RH
24	401174X004	Axle Arm Assembly, LH
25	199775X428	Cover Drive
26	750634	Screw, Threaded, Rolled #10-25 x .50
27	401629	Spacer
28	12000058	E-Ring 7/16
29	189403	Cover, Dust, Wheel
30	73800400	Nut, Hex

KEY NO.	PART NO.	DESCRIPTION
31	175098	Pawl
32	193912X427	Wheel 9 x 2
33	83923	Nut, Flangelock 3/8-16
34	175103	Pinion, Gear
35	175105	Retainer, Drive, LH
36	175104	Disc, Drive
37	184172	Seal, Friction
38	175102	Retainer, Drive, RH
40	193909X427	Wheel 8 x 2
41	188330	Pinion Assembly, RH
43	188331	Pinion Assembly, LH
44	183688	V-Belt
47	67725	Washer
51	187530	*Case, Lower
52	187531	*Case, Upper
53	187532	Gear, 24 Teeth
54	187533	Shaft, Input
55	183505	Wire, Formed
56	183506	Bearing, Ball
57	183508	Seal, Output Shaft
58	183509	Washer
59	183511	Bushing
60	197385	Shaft, Output
61	183513	Screw
62	183514	Seal, Input Shaft

* Use Dow Corning #709 to reseat Gear Case Halves.

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.