







Key No. N° sur le schéma	Part No. N° de pièce	Description
1	198563	CORD, STARTER
2	LH1955P-67510 D	TEC ENGINE
3	198539	BOLT, CARRIAGE 5/16-18
4	198540	RETAINER, PUSH
5	198541	NUT 5/16-18
6	198542	PULLEY, ENGINE
7	400026	WASHER
8	850263	WASHER
9	851084	SCREW, 3/8-24X1.00
10	198546	BELT, V 3L
11	400043	BELT, V 4L
12	198558X004	BRACKET ASSEMBLY, IDLER
13	198559	BUSHING, IDLER BRACKET
15	74610516	SCREW 5/16-24 X 0.75
16	198580	SPRING
17	198561	PULLEY, IDLER
18	198562	NUT, JAM 3/8-16
20	198555	GUIDE, ROD BELT
21	400025	WASHER
22	10040500	WASHER, SPTLK .31X.58X.08
24	74610516	SCREW, 5/16-24X 0.75
25	- - - - -	FRAME ASSEMBLY
25-1	198784X428	PLATE, ENGINE MOUNT
25-2	198574	SCREW 1/4-20 X .63
25-3	198584	SCREW 5/16-18 X .50
25-4	198766X428	FRAME, MOTOR BOX
27	59289	WASHER
--	406885	OWNER'S MANUAL




Key No.	Part No.	Description	Key No.	Part No.	Description
19	73800400	NUT, HEX LOCK 1/4-20	41	404965	HOUSING, GEARCASE, RH
27	404953	WASHER, FLAT	42	404959	SEAL, OIL
32	404955	NUT, 1/4-20	43	404960	BEARING, FLANGE
33	404956	COLLAR, THRUST	44	404952	KEY, WOODRUFF #605
34	174684	WASHER, THRUST	45	404962	GEAR, WORM
35	404957	PIN, SPRING	46	404946	SHAFT, AUGER OUTPUT
36	404948	SHAFT, AUGER INPUT (IMPELLER)	47	404964	HOUSING, GEARCASE, LH
37	404944	GEARCASE, COMPLETE	48	405027X479	IMPELLER
38	404961	BUSHING, FLANGE	49	74780426	SCREW
39	404954	BOLT 1/4-20 x 3/4	50	404950	GASKET, GEARCASE
40	B6447	PLUG	51	7B36M	PIN, ROLL




Key No.	Part No.	Description
650	199039X008	SHAFT, AXLE
652	198679	SPRKT & HUB
653	198667	SCREW, 1/4-20 x 1.75
654	73800400	NUT, 1/4-20 HEX NYLOCK
655	198680	BEARING, AXLE
671	400025	FLATWASHER
673	1199040	BUSHING, WHEEL
675	405067X417	TIRE & RIM, RIGHT
676	198674	SCREW, 1/4-20X1.75 HH
677	73800400	NUT, 1/4-20 HEX NYLOCK
678	198675	RING, RET
679	155443	PIN, KLIK .25 X 1.38 DIA
680	405066X417	TIRE & RIM, LEFT



Key No.	Part No.	Description
90	198573X479	COVER, BOTTOM
91	198574	SCREW, 1/4-20X .63
103	406853X008	IDLER ASSEMBLY, AUGER
105	198576	PIN, HAIR .38DIA X 1.64LG
106	198580	PIN, CLEVIS 3/16" DIA
107	400024	SPRING, TENSION
108	405484	ASSY., SPRING ATTACH
110	72110612	BOLT, 3/8-16X1.25 CARR.
111	198578	WASHER, FLAT
122	198584	SCREW, TAP 5/16-18 X 0.50
123	150078	SCREW, TAP 5/16-18 X 0.75
148	198561	PULLEY, IDLER
149	73930600	NUT, JAM 3/8-16
160	407095X428	COVER, BELT
162	405024	SCREW, TAP
167	198592	WASHER, FLAT
168	198581	SPACER, AUGER BRACKET




Key No.	Part No.	Description
200	198800X008	LF AXLE, SWING PLATE YZ
201	198588	CHAIN, ROLLER #420 x19.00
206	198584	SCREW, TAP 5/16-18x0.5
207	198815	ASSY, HEX SHAFT
208	198596	CHAIN, ROLLER #420 x18.00 LG
210	198819	BEARING, TRUNION CLUTCH R
212	198820	WHEEL, FRICTION DISC
213	198822	BOLT
215	73800400	NUT, KEPS HEX 1/4-20
217	405538	RING, RETEXT
218	198592	WASHER
220	198591	BEARING AND RETAINER, ASSY
221	198684	SCREW, TAP 5/16-18 x .5
223	198808	ASSY, FRICTION PULLEY
225	198792X008	LF PLATE, SWINGING YZ
226	198850	SPACER, FRICTION PULLEY
227	73040800	NUT, FLANGE LOCK 3/8-24
229	19859X008	RETAINER, RING
230	198594X008	LF ASSY, SPRING LINK YZ
232	198945	RETAINER, RING
234	198597	SPRING, EXTENSION
236	198598	WLD, INTERMED SPROCKET 33T/7
238	198599	WASHER, FLAT
239	198945	RING,RETAINER(5100-50)



MODEL 96194000200

REPAIR PARTS AUGER HOUSING


Key No.	Part No.	Description
480	45011	PULLEY, 4L 6.12X .67
490	74950512	SCREW, 5/16-18X.63
484	19111507	WASHER, FLAT
485	10040500	LOCKWASHER
491	188909	BEARING, BALL
493	199879	BOLT, HEX 5/16-18X .50
499	198541	NUT, 5/16-18 HEXWDFLLK
500	405680X428	HOUSING, ASSY
510	199045X479	BLADE, SCRAPER 24"
511	198634	BOLT, 5/16-18x0.62
514	400100	NUT, 5/16-18
520	405646X479	AUGER, ASSY, LH
521	405647X479	AUGER, ASSY, RH
522	198636	SCREW, 1/4-20X1.75
523	198638	SPACER, SLEEVE
524	73800400	NUT, 1/4-20
525	405535	BEARING, FLANGE
527	179582	SCREW, 5/16-18X .75
540	400039X479	SKID, HEIGHT ADJUST
541	198648	BOLT, 5/16-18 X .75
544	198541	NUT, 5/16-18
550	192199	BRUSH, CLEANOUT
551	405400	CLIP, RETAINER
552	194189	SCREW
555	401351	WRENCH



MODEL 96194000200

REPAIR PARTS DISCHARGE CHUTE


Key No.	Part No.	Description
582	198661	BOLT, CARRIAGE 5/16-18 X.75
584	751153	NUT, 5/16-18 REGHEX NYLOCK
594	198662	WASHER, FLAT
596	198662	WASHER, FLAT
597	198851	KNOB, T 3.00
599	198539	BOLT, 5/16-18X1.00
600	198842	CHUTE UPPER
601	198661	BOLT, 5/16-18 X1.00
602	198662	WASHER, FLAT
603	73800500	NUT, 5/16-18 HEXNYL
606	1198659	CHUTE COLLAR
607	405024	SCREW, 1/4-20 X 0.75
609	73800400	NUT, 1/4-20 HEX NYLOCK
610	198831	RETAINER RING INNER
611	198833	RETAINER RING OUTER
605	198844	CHUTE LOWER



MODEL 96194000200

REPAIR PARTS HANDLE


Key No.	Part No.	Description
720	400046X479	HANDLE, UPPER
724	198711	SCREW, 5/16-18X2.75
725	198662	WASHER, FLAT
726	10040500	WASHER, SPTLK .31X.58X.08
727	198683	NUT, 5/16-18 REGHEX
728	198709	STOP, RED PLASTIC
730	400045X479	CLUTCH HANDLE, RIGHT
731	400044X479	CLUTCH HANDLE, LEFT
733	400048	PIN, PIVOT CLUTCH
734	400049	NUT, PUSH ON CAP
739	198702	BUMPER, RECTANGLE
740	406165	CABLE, CLUTCH 28.44L
741	400050	CABLE, AUGER CLUTCH
743	198692	BRACKET, CABLE ADJUSTER
744	198690	SPRING, AUGER CLUTCH
745	73600400	NUT, 1/4-20
746	198670	BOOT, CLUTCH SPRING
750	400151X479	HANDLE, LOWER
751	150078	SCREW, TAP 5/16-18 X 0.75
755	198699X479	BRKT, GEAR SELECTOR
756	198574	SCREW, 1/4-20 X 0.63
759	198678	SPOOL-CABLE, AUGRT CLUTCH
760	198677X004	BRACKET, CABLE SPOOL YZ
762	406164	CABLE, LOWER DRIVE 12"
763	198673	BOLT, HEX 1/4-20 X 1.50
766	400047	GRIP




MODEL 96194000200

REPAIR PARTS CHUTE ROD

Key No.	Part No.	Description
852-1	198853x008	ASSEMBLY, YOKE & ROD
852-2	198861	SPRING
852-3	198862	GEAR, CHUTE ROTATION 9T
852-4	400026	WASHER
852-5	400192	PIN, COTTER
852-6	405339	BRACKET, CHUTE GEAR
852-7	198863	PIN, HAIR
852-8	198788	ASSEMBLY, YOKE ADAPTER YZ
852-9	198678	PIN, HAIR
852-10	198878	PIN, UNIVERSAL JOINT
852-11	198860	PIN, CLEVIS
852-13	198570	HOUSING, UNIVERSAL
854	198836x428	KNOB, SLEEVE
855	198837	FLATWASHER
856	198839	NUT, PUSH ON 3/8"
860	198869	EYE BOLT 3/8-16X6.00
861	198841	GROMMET, EYE BOLT
863	198845	NUT, 3/8-16 HEXJAM
864	198733	FLATWASHER .406X.81X.066
867	73600600	NUT, 3/8-16 HEXNYL
868	198729	BOLT, CARRIAGE 1/4-20 X 1.00
869	73800400	NUT, 1/4-20
870	198846	CRANK, ASSY CHUTE



Key No.	Part No.	Description
790	198725x479	ROD, SHIFT
791	198727	SCREW, 1/4-20X.75
792	73800400	NUT, 1/4-20
796	198736	KNOB, SLIP
800	198737	LEVER, SPRING
801	198727	SCREW, 1/4-20X.75
812	198732x008	ROD ASSY., SPEED SELECT
813	198945	RETAINER, RING
814	198791	BEARING, FLANGED



Key No.	Part No.	Description
620	404467	HOUSING, HEADLIGHT UPPER
621	406471	HEADLIGHT, ASSY *
622	406465	HOUSING, HEADLIGHT LOWER
623	406472	SCREW, #8X1.75
624	406470	WIRING HARNESS, HALOGEN
625	406473X008	BRACKET, HEADLIGHT
626	402420	BOLT, CARRIAGE - 5/16-18X2.00
627	401354	WASHER, SADDLE
628	11050500	WASHER, EXLK .32X.60X.040
629	10040500	WASHER, SPTLK .31X.58X.08
630	198683	NUT, 5/16-18 REGHEX
631	198685	SCREW, 5/16-18X2.00
632	10040500	WASHER, SPTLK
633	198683	NUT, 5/16-18 REGHEX
634	66426	TIE, CABLE

* For replacement bulb, use Standard GE or Phillips #894.

