


SECTION 10: PARTS LIST FOR MODEL SERIES 410 THROUGH 419



#46 & #56 are Invalid Part No.'s

Correct Part No.=

#56 682-0515LH- Handle Bracket Assy LH

682-0516RH- Handle Bracket Assy RH

Model Series 410 Through 419

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	747-1161A	Control Handle	34.	738-0507B	Shoulder Screw
2.	749-1092A	Upper Handle	35.	736-0105	Bell Washer .375 x .870
3.	747-04080	Grass Catcher Frame	36.	‡	Front Wheel
7.	749-0928A	Lower Handle	37.	738-0102	Shoulder Screw .498 x 1.4
8.	720-0279	Wing Nut	38.	782-5004A	Rear Baffle RH
9.	710-1205	Rope Guide	39.	746-0957	Control Cable 37.25"
10.	710-1174	Carriage Bolt 5/16-18 x 2		746-1130	Control Cable 40"
11.	764-0309	Grass Bag Assembly		746-0554	Control Cable 40.5"
	764-0650	Grass Bag Assembly w/ Bag-Fill Ind.†		746-1137	Control Cable 53"
12.	720-0284	Hand Knob	40.	720-0295	Foam Grip † (not shown)
13.	736-0451	Saddle Washer	41.	731-1236	Trailshield
14.	726-0240	Cable Tie	42.	732-0700	Trailshield Wire
15.	710-0703	Carriage Bolt 1/4-20	43.	731-1506	Deck: Front Cover †
16.	731-04134	Rear Discharge Door	44.	712-0397	Wing Nut 1/4-20
17.	750-04162	Spacer	45.	710-0654A	Hex L-Washer Hd. Screw 3/8-16 x 1.0
18.	732-04071	Torsion Spring LH	46.	687-02020	Lever Assembly: Rear Height Adj.
	732-04072	Torsion Spring RH	47.	14765	Pivot Bar: 9 Position RH
19.	787-01016	Handle Bracket RH		14766	Pivot Bar: 9 Position LH
	787-01015	Handle Bracket LH	48.	710-0896	AB Screw 1/4-14 x .625
20.	‡	Rear Wheel	49.	712-0431	Flange Lock Nut 3/8-16
21.	782-5003	Rear Baffle LH	50.	714-0104	Hairpin Clip
22.	731-0981A	Hubcap †	51.	710-0654A	TT Sems Screw 3/8-16 x 1.0
23.	787-01103	Cutting Deck: Rear Discharge	52.	14578	Handle Bracket Assy. Front LH
24.	710-1017	AB Screw 1/4-14 x .625"		14579	Handle Bracket Assy. Front RH
25.	782-5002	Front Baffle	53.	687-02037	Handle Bracket Assy. Rear LH
26.	748-0376C	Blade Adapter		687-02036	Handle Bracket Assy. Rear RH
27.	742-0741	Mulching Blade	54.	738-0213	Rear Axle Bolt†
28.	710-1044	Hex Bolt 3/8-24 x 1.5	55.	750-0535	Spacer †
29.	736-0524A	Blade Bell Support	56.	736-0504	Wave Washer †
30.	15261A	Front Adjustment Plate	57.	731-1405	Chute Deflector †
31.	15262B	Pivot Bar	58.	711-0996	Rod †
32.	720-0426	Knob: Adjustment Lever	59.	726-0201	Push Speed Nut†
33.	732-0404	Spring Lever Assembly			

† If equipped

‡ Refer to Wheel Chart

‡ Wheel Chart

Type	Part No.	Tread
Wheels w/o bearing	734-1781, Slot Hub	Bar
	734-1987, 8 x 1.8	Bar
	734-1988, 7 x 1.8	Bar
	634-0020, Disc Hub	Bar
Wheels w/ BB	734-2004A, Disc Hub	Zag
	734-2005A	Zag