


Model 54M




Ref.	Part No.	Description
1	747-1161A	Blade Control
2	731-04859 †	Bail Cover
3	712-04064	Flange Lock Nut 1/2-20
4	726-0240	Cable Tie
5	664-04027	Grass Bag Assembly
6	747-04080	Grass Bag Frame
7	731-05401	Engine Shroud
8	731-05642	Trailshield
9	747-04588	Pivot Rod
10	631-04225	Rear Discharge Door
11	687-02280	Rear Handle Brkt. Assy. - LH
	687-02279*	Rear Handle Brkt. Assy. - RH
12	787-01279	Deck 21-inch
13	687-02099A	Frnt. Hgt. Adj. Assy-LH (7" Wheel)
	687-02075A	Frnt. Hgt. Adj. Assy-LH (8" Wheel)
	687-02100A*	Frnt. Hgt. Adj. Assy-RH (7" Wheel)
	687-02074A*	Frnt. Hgt. Adj. Assy-RH (8" Wheel)
14	782-5002B	Front Baffle
15	738-0377C	Blade Adapter
16	742-0741	21-inch Mulching Blade
17	736-0524B	Bell Blade Support
18	710-1257	Hex Screw, 3/8-24 x 2.5
19	731-1950A †	Deck Cover
20	17032A	Chute Deflector Adapter
21	732-1014	Torsion Spring
22	747-0710	Hinge Pin
23	687-02055	Hinged Mulch Plug Assembly
24	712-04065	Flange Lock Nut 3/8-16
25	787-01290	Height Adjustment Plate
26	687-02076A	Frnt Pivot Arm Ass'y-RH (7" Wheel)
	687-02077A	Frnt Pivot Arm Ass'y-RH (8" Wheel)
	687-02077A*	Frnt Pivot Arm Ass'y-LH (7" Wheel)
	687-02076A*	Frnt Pivot Arm Ass'y-LH (8" Wheel)
27	734-04211	Front Wheel, 7 x 1.8, K2 Bar

Ref.	Part No.	Description
	734-1987	Front Wheel, 8 x 1.8, Bar
28	738-0507B	Shoulder Screw, .5D x .434
29	732-0404	Front Spring Lever
30	720-0426	Height Adjust Knob
31	710-0599	TT Screw, 1/4-20 x .500
32	736-0270	Bell Washer
33	710-0654A	TT Screw, 3/8-16 x 1.0
34	710-0216	Hex Screw, 3/8-16 x .75
35	710-1652	TT Screw, 1/4-20 x .625
36	720-0312	Foam Grip
37	734-04216	Rear Wheel, 12 x 1.8, K2 Bar
	734-04082	Rear Wheel, 12 x 1.8, Bar
38	736-0182 †	Spring Washer
39	732-0866	Rear Hi-Wheel Spring Lever
40	687-02039A	Rear Pivot Arm Assy - RH
	687-02040A*	Rear Pivot Arm Assy - LH
41	714-0104	Hairpin Clip
42	731-04177	Side Discharge Chute
43	710-0703	Carriage Bolt ,1/4-20 x .75
44	731-04150C	Rear Baffle
45	710-1241	Screw HL, 1/4-15 x 1.00
46	732-04090A	Torsion Spring - RH
47	731-0981A †	Hub Cap, Radial Spoke
48	712-0397	Wing Nut
49	749-0928A	Lower Handle
50	710-1174	Carriage Bolt, 5/16-18 x 2
51	720-04072	Star Knob
52	720-0279	Handle Knob
53	710-1205	Eye Bolt
54	749-1092A	Upper Handle
55	710-0606	Hex Screw, 1/4-20 x 1.50
56	746-04239A	Cable, Choke 38-inch
57	746-04299	Cable, ERS 48-inch
58	710-04577	Machine Screw M4-.7x10.00

† If Equipped

* Not Pictured

Engine 1P65



Ref.	Part No.	Description
1.	951-10337	Fuel Tank
2.	951-10336	Flywheel Shroud
3.	951-10335	Rubber Fuel Tank Mounting Washer
4.	951-10334	Oil Filler Tube Assembly
5.	951-10333	Dipstick Assembly
6.	951-10406	Cylinder Head Complete
7.	951-10407	Short Block Assembly
8.	951-10320	Stop Switch and Brake Assembly
9.	951-10319	Recoil Spring and Pulley Assembly
10.	951-10314	Push Rod Kit
11.	951-10313	Valve Kit
12.	951-10370	Oil Drain Plug and Washer Assembly
13.	951-10367	Ignition Coil
14.	951-10309	Carburetor Assembly
15.	951-10307	Flywheel Key
16.	951-10405	Air Cleaner Housing Assembly Complete
17.	951-10304	Muffler Stud Assembly
18.	951-10363	Fuel Line Kit – Inc. hoses, clamps & filter
19.	951-10358	Fuel Filter
20.	951-10300	Fuel Cap Assembly
21.	951-10299	Recoil Starter Assembly
22.	951-10298	Air Cleaner Kit
23.	951-10297	Air Cleaner Thumb Screw
24.	951-10404	Muffler Guard
25.	951-10403	Muffler
26.	951-10402	Muffler Gasket /Heat Shield
27.	951-10293	Governor Return Spring
28.	951-10292	Spark Plug
–	952Z1P65FU	Engine – Complete
–	951-10325	Carburetor Kit – Major
–	951-10322	Carburetor Kit – Minor
–	951-10409	Gasket Kit – Complete
–	951-10410	Gasket Kit – External
–	951-10351	Spark Arrestor

NOTE: Illustrated parts without a numeric call-out are *not* servicable components.