



Ref #	Part Number	Qty	Description
1	17347		Deck Stabilizer
2	17264		Diagonal Brace
6	17218D		46" Deck Ass'y.
	17455		46" Deck Ass'y. Comp.
7	710-0258		Hex Bolt 1/4-20 x .62" Lg.
8	711-0792		Hinge Pin
9	712-0298		Hex Jam Nut 1/4-20 Thd.
10			UNKNOWN
12	736-0270		Bell-Wash. 1/4" I.D.
13	738-0392		Deck Connecting Rod
15	710-0604		Hex TT-Tap Scr. 5/16-18 x .62"
16	17261		Idler Mtg. Brkt.
17	710-0888		Hex Bolt 5/16-24 x 1" Lg.
18	710-0157		Hex Bolt 5/16-24 x .75" Lg.
19	712-0123		Hex Nut 5/16-24 Thd.
20	736-0119		L-Wash. 5/16" I.D.
21	736-0242		Bell-Wash. 5/16" I.D.
22	717-0912		Spindle Ass'y. (R.H. & Center)
23	717-0913		Spindle Ass'y. (L.H.)
26	710-0888		Hex Bolt 5/16-24 x 1.0" Lg.
27	710-0877		Hex Cl-Bolt 3/8-24 x .88" Lg.
28	712-0123		Hex Nut 5/16-24 Thd.
29	736-0119		L-Wash. 5/16" I.D.
30	736-0217		L-Wash. 3/8" I.D. - H.D.
31	742-0486		High Lift Blade 14.88" Lg.
32	742-0487	2 Req'd	High Lift Blade 16.28" Lg.
33	748-0300		Blade Adapter
35	17116		Deck Brake Brkt. Ass'y.
36	17213		Idler Bracket
37	17258		Belt Cover Brkt. - R.H.
38	17260		Belt Keeper Bracket
39	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.
40	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
41	710-0559		Hex Bolt 1/4-28 x 1.75" Lg.
42	710-0599		Hex Wash. Hd. Tap-Scr. 1/4-20 x .5" Lg.
43	710-0624		Hex Bolt 5/16-24 x 1.5" Lg. (Grade 5)
44	710-0698		Hex Bolt 1/4-28 x 1.5" Lg.
46	711-0747		Belt Guard Pin 1/4" Dia.
47	712-0117		Hex Cent. L-Nut 1/4-28 Thd.
48	712-0123		Hex Nut 5/16-24 Thd.
49	712-0138		Hex Nut 1/4-28 Thd.
50	712-0241		Hex Nut 3/8-24 Thd.
51	712-0287		Hex Nut 1/4-20 Thd.
52	712-0318		Hex Jam Nut 5/8-18 Thd.
53	727-0426		Brake Cable Ass'y.
	727-0445		Brake Cable Ass'y.
54	732-0594A		Extension Spring 6.17" Lg.
55	732-0429A		Extension Spring 3.97" Lg.
56	736-0105		Bell-Wash. .38" I.D. x .88" O.D.
57	736-0331		Bell-Wash. .39" I.D. x 1.13" O.D.
60	736-0158		L-Wash. 5/8" I.D.
61	736-0329		L-Wash. 1/4" I.D.
62	736-0416		FI-Wash. 5/16" I.D. x 3" O.D.
63	738-0347		Shld. Spacer .625" I.D.
64	748-0234		Shld. Spacer
65	750-0214		Spacer .34" I.D.
66	750-0470		Spacer .326" I.D.
67	754-0349		V-Belt
68	754-0350		V-Belt
69	756-0365		FI-Idler w/Flanges 3.5" O.D.

Ref #	Part Number	Qty	Description
69	756-0365		FI-Idler w/Flanges 3.5" O.D.
70	756-0519		Pulley 5.0" Dia.
71	756-0520		Pulley 5.0" Dia.
72	711-0701		Clevis Pin 1/4" Dia. x .53" Lg.
73	712-0798		Hex Nut 3/8-16 Thd.
74	714-0104		Intern. Cotter Pin 5/16" Dia.
75	714-0145		Intern. Cotter Pin 3/8 Dia.
76	734-0973		Deck Wheel 5" Dia.
77	734-3058B		Deck Wheel w/Insert 5" Dia.
78	736-0169		L-Wash. 3/8" I.D.
79	736-0192		FI-Wash..531" I.D.
80	738-0533		Shoulder Bolt .498" Dia. x 1.64" Lg.
81	738-3056		Shoulder Bolt
82	710-0653		Hex Wash. Hd. Tap-Scr. 1/4-20 x .38" Lg.
83	732-0602		Torsion Spring
84	703-1693		Hinge Mtg. Brkt.
85	726-0106		Push Nut
86	731-1032		Chute Ass'y. Comp.
87	750-0757		Spacer 5/8" I.D. x 7/8" O.D.




Ref #	Part Number	Qty	Description
1	720-0233		Grip
2	17282		Lift Handle Ass'y.
3	710-0442		Hex Bolt 5/16-18 x 1.5" Lg.
4	748-0274A		Lift Shaft Drive
5	741-0225		Plastic Hex Brg. 5/8" I.D.
6	14231		Index Brkt. Deck Lift
7	737-0164		Pipe Nipple 3/8-18 Npt.
8	737-0143		Pipe Cap 3/8-18 Npt.
9	714-0118		Sq. Key 1/4" x 1/4" x 1.50" Lg.
10	736-0188		FI-Wash. .76" I.D. x 1.49" O.D.
11	736-0171		L-Wash. 7/16" I.D.
12	710-0757		Hex Scr. 7/16-20 x 1.50" Lg.
13	731-1086		Sleeve .75" I.D. x 1" O.D.
14	13889		Lift Shaft Ass'y.
15	13895		Lift Pivot Brkt. Ass'y.
16	17303		Adj. Deck Lift Link
17	736-0192		FI-Wash. 1/2" I.D. x 1.00" O.D. x .090"
18	714-0101		Hairpin Cotter
19	741-0295		Nyliner 5/8" I.D. x .88" Lg.
20	738-0445		Shld. Bolt 5/8" Dia. x .96" Lg. 3/8-16
21	13790		Connecting Link
22	710-0627		Hex Bolt 5/16-24 x .75" Lg.
23	736-0322		Flat Wash. .44" I.D. x 1.25" O.D. x .17"
24	756-0531A		Two-Step Engine Pulley
25	710-0502A		Hex Wash. Hd. Scr. 3/8-16 x 1.25" Lg.
26	710-0726		Hex Thd. Rolling Scr. 5/16-18 x .75" Lg.
27	738-0435		Running Board Rod
28	726-0272		Clamp
29	734-0255		Air Valve
30	734-1705		Rear Wheel Ass'y. Comp.
	734-1701		Tire Only
31	734-0603A		Rear Wheel Rim Only
32	736-0346		Flat Wash. .34" I.D. x 2" O.D.
33	710-0258		Hex Bolt 1/4-20 x .62" Lg.
34	711-0817		Eye Bolt Adj. Link 1/2-13 Thd.
36	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
37	710-0237		Hex Bolt 5/16-24 x .62" Lg.
38	736-0119		L-Wash. 5/16" I.D.
39	712-0181		Hex Top L-Nut 3/8-16 Thd.
40	732-0369		Compression Spring
41	738-0777		Deck Connecting Rod
42	712-0287		Hex Nut 1/4-20 Thd.
43	14170		Index Brkt. Reinforcement Plate
46	726-0273		Mounting Clamp
47	731-0556		Hub Cap
	734-1504		Hub Cap (5 Spoke)
48	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
49	736-0242		Bell-Wash. .39" I.D.
50	714-0111		Cotter Pin .09 Dia. x 1.0" Lg.
51	714-0149B		Int. Cotter Pin
52	736-0231		Flat Wash. .34" I.D. x 1.12" O.D. x .125"
53	710-0600		Hex Wash. Hd. AB-Tap Scr. 5/16-24 x .5" Lg.
54	712-0206		Hex Nut 1/2-13 Thd.
55	14399		Deck Link
56	736-0264		FI-Wash. .344" I.D.
57	736-0219		Bell-Wash. .4" I.D. x 1.13" O.D.
?60	710-0118		Hex Bolt 5/16-18 x .75" Lg.
63	736-0329		L-Wash. 1/4" I.D.
65	751-0535-46		Fuel Line 46" Lg.
66	726-0205		Hose Clamp

Ref #	Part Number	Qty	Description
66	726-0205		Hose Clamp
67	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
68	17424		Fuel Tank Strap
69	751-0566		Gas Tank
70	751-0531B		Gas Gauge
71	16848C		Seat Plate
72	17342C		Hitch Plate
73	738-0482		Hitch Rod
74	726-0272		Hose Clamp
75	727-0425A		Spring Clip
?77	710-0604		Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .62" Lg.
?78	17839		Speed Control Brkt.
?79	732-0525		Comp. Spring Clip




Ref #	Part Number	Qty	Description
1	725-1635		Battery (275 Cold Crank Amps)
2	725-1426		Solenoid
3	725-1625		Fuse 7.5 Amp
4	725-0925		Ammeter
5	725-0267		Ignition Switch
6	725-0634		Light Switch
7	725-3169A		Safety Switch (Clutch)
8	725-0465A		Safety Switch (PTO)
9	725-0561		Electric Wire 14" Lg.
11	725-0996		Ground Wire 7.5" Lg.
12	725-0963		Lamp
13	725-1649		Socket
	725-1650		Socket
14	629-0082		Wire Harness w/Ammeter
	629-0075		Wire Harness w/o Ammeter
15	725-1643		Spring Switch (Reverse)
16	725-1303		Spring Switch (Seat)
17	725-1439		Spring Switch (Seat)
18	725-1399		Ext. Wire




Ref #	Part Number	Qty	Description
1	17551A		Hood
2	738-0724		Shld. Bolt .375" Dia. x .125" Lg.
3	736-0175		Spr. Wash..265" I.D. x .562" O.D.
4	710-0258		Hex Bolt 1/4-20 x .62" Lg.
5	736-0329		L-Wash. 1/4" I.D.
6	712-0287		Hex Nut 1/4-20 Thd.
7	749-08134		Grille Support Rod
8	731-1099A		Headlight Lens
9	712-0380		Flange L-Nut 1/4-28 Thd.
10	731-1097A		Grille
11	736-0119		L-Wash. 5/16" I.D.
12	712-0267		Hex Nut 5/16-18 Thd.
13	725-0963		Lamp
14	725-1649		Socket
15	710-0932		Carriage Bolt 1/4-20 x 1.0" Lg.
16	710-07764		Hex AB-Tap Scr. 1/4 x .62" Lg.
17	736-0173		FI-Wash..281" I.D. x .73" O.D.
18	726-0233		Bolt Retainer 1/4" I.D.
19	712-0185		Speed Nut 1/4-20 Thd.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.
21	17634		Support Brkt.
22	731-1094A		Dash - w/Ammeter & Light Switch Holes
	731-1095A		Dash - w/o Ammeter & Light Switch Holes
23	725-0267		Ignition Switch
24	725-0201		Ignition Key
25	746-0614A		Choke Control
26	725-0634		Light Switch
27	725-0925		Ammeter
28	720-0218		Shift Knob
29	720-0166		Knob
31	17395		Shift Cover
	17399A		Shift Cover
32	710-0167		Carriage Bolt 1/4-20 x .5" Lg.
34	17428		Fender
	17426A		Fender
37	710-0166		Truss Mach. Scr. #1/4-20 x 1" Lg.
38	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
41	831-0823A		Throttle Box Ass'y.
42	710-0779A		Truss Mach. AB-Tap Scr. 010 x .5" Lg.
43	746-0634		Throttle Control Wire
45	731-1360		6-Speed Selector Plate
	731-1071		7-Speed Selector Plate
46	16934		Front Heat Shield
47	751-0474		Muffler
48	731-0511-12		Trim Strip 12" Lg.
49	732-0626		Ext. Spring 5.06" Lg.
50	747-0750		Deck Control Rod
51	726-0106		Speed Nut 1/4" Rod
52	710-1017		Torx Mach. Scr. 1/4 x .62" Lg.
54	720-0165		PTO Knob
55	17500		PTO Lever
56	17496		PTO Bracket
57	738-0155		Shld. Bolt .437" Dia. x .162"
58	712-3009		Hex L-Nut 5/16-18 Thd.
59	725-0465A		Safety Switch (PTO)
?60	710-1066		Hex Wash. Hd. B-Tap Scr. #10 x .38" Lg.
61	777-9206		Grille Reflector Label
62	17782		Retainer Clip
63	731-1276		Forward/Reverse Index Brkt.
64	710-0924		Truss Mach. Scr. 1/4-20 x .75" Lg.

Ref #	Part Number	Qty	Description
64	710-0924		Truss Mach. Scr. 1/4-20 x .75" Lg.
65	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .5" Lg.
66	726-0320		Insulator Nut Plate
67	725-1643		Reverse Safety Switch
68	730-3000		Reflector
69	710-1066		Hex Wash. Hd. 8 - Tap Scr. #10 x .38" Lg.
70	736-3078		FI-Wash..344" I.D. x 1" O.D.
71	736-0342		FI-Wash..28" I.D. x .75" O.D.
72	736-0170		Spec. L-Wash. 5/16" I.D.




Ref #	Part Number	Qty	Description
1	17342A		Hitch Plate
2	710-0726		Hex AB-Tap Scr. 5/16" x .75"
3	738-0482		Hitch Rod
4	714-0147		Hitch Pin Clip
5	712-0267		Hex Nut 5/16-18 Thd.
6	736-0119		L-Wash. 5/16" I.D.
7	710-0195		Hex Bolt 1/4-28 x .62" Lg.
8	710-0604		Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .62" Lg.
9	732-0693		Brake Extension Spring
10	711-0723A		Adjustment Ferrule 3/8-24 Thd.
11	736-0267		Fl-Wash. .385" I.D. x .87"
12			UNKNOWN
13	747-0729		Speed Control Link (Rear)
14	736-0192		Fl-Wash. .531" I.D. x.94"
15	16906		Speed Selector Lever Ass'y.
16	738-0155		Shld. Bolt .437" Dia. x .162"
17	710-0672		Hex Bolt 5/16-24 x 1.25" Lg.
18	732-0429A		Extension Spring 3.9" Lg.
19	712-3057		Hex Nut 5/16-24 Thd. (Gr. 5)
20	710-0620		Hex Bolt 3/8-24 x 4.5" Lg.
21	732-0603		Extension Spring 11" Lg.
22	738-0779		Shld. Bolt .625" Dia. x 3.5" Lg.
23	747-0726		Speed Control Link (Front)
24	710-0157		Hex Bolt 5/16-24 x .75" Lg.
25	735-0196		Foot Pad
26	747-0722		Parking Brake Link
27	17914		Variable Speed Torque Brkt. Ass'y.
28	732-0568		Extension Spring 2.59" Lg.
29	17908		Pulley Plate Ass'y.
30	741-0591		Flanged Brg. .630" I.D.
31	732-0395		Extension Spring 2.51" Lg.
32	710-0528		Hex Bolt 5/16-18 x 1.25" Lg.
33	750-0214		Spacer .34" I.D. x .88"
34	16980		Brake Lockout Bracket
35	16924A		Clutch Ass'y. Mtg. Bracket
36	741-0225		Hex Flange Brg. .634" I.D.
37	748-0234		Shld. Spacer .5" Dia.
38	736-0187		Fl-Wash. .64" I.D. x 1.24"
39	710-0118		Hex Bolt 5/16-18 x .75" Lg.
40	710-0436		Hex B-Tap Scr. #10 x 5/8 Lg.
41	736-0185		Fl-Wash. .406" I.D. x .75" O.D.
42	714-0115		Cotter Pin 1/8" Dia.
43	736-0275		Fl-Wash. .34" I.D. x .68" O.D.
44	714-0111		Cotter Pin 3/32" Dia.
45	17910		Foot Pedal Ass'y.
46	736-0169		L-Wash. 3/8" I.D.
47	712-0241		Hex Nut 3/8-24 Thd.
48	736-0329		L-Wash. 1/4" I.D.
49	712-0287		Hex Nut 1/4-20 Thd.
50	17349		Brake Link Bracket
51	747-0724		Front Brake Rod Link
52	712-0375		Hex Cent. L-Nut 3/8-16 Thd.
53	710-0501		Hex Bolt 1/4-20 x 2.0" Lg.
54	711-0828		Belt Guard Pin
55	720-0218		Shift Knob
56	712-3035		Hex Jam Nut 9/16-18 Thd.
57	17912		Foot Pedal Brkt. Ass'y.
58	17962		Switch Plate
59	732-0698		Ext. Spring 5.2" Lg.
60	748-0331		Shld. Spacer .318" I.D. x 1.125"

Ref #	Part Number	Qty	Description
60	748-0331		Shld. Spacer .318" I.D. x 1.125"
61	736-0156		Fl-Wash, .635" I.D. x 1.12" O.D.
67			Deck Control Rod
68	720-0166		Ball Knob Brake
69	736-0427		Belt-Wash. 9/16" I.D. x 1.25"
70	756-0534		V-Pulley 9 1/4" O.D.
71	710-0539		Hex Bolt 3/8-24 x 1.75" Lg.
73	17902		Transaxle Torque Brkt.
74	17903		Idler Brkt. Ass'y.
75	756-0542		Flat Idler 3.5" O.D.
76	732-0673		Extension Spring 6.12" Lg.
77	754-0361		V-Belt
78	736-0414		Teflon Washer 1.20" O.D.
79	717-0945		Variable Speed Pulley 6" Dia.
80	754-0358		V-Belt
81	738-0778		Pivot Bushing
82	736-0355		Fl-Wash. .56" I.D. x 1.0" O.D.
83	741-0405		Thrust Brg. .56" I.D. x 1.25"
84	17485		Retainer Cup
85	13887		Deck Control Pivot Brkt.
86	13833		Parking Brake Mtg. Brkt.
87	736-0105		Bell-Wash. .38" I.D. x .88" O.D.
88	738-0129		Shld. Bolt .498" Dia. x 2.05"
89	732-0478		Extension Spring 6.12" Lg.
90	732-0308		Extension Spring 6.37" Lg.
91	731-0483		Convolute Conduit 4" Lg.
92	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
93	756-0293A		V-Belt Idler
94	714-0104		Internal Cotter Pin
95	748-0278		Spacer
96	14076A		Idler Brkt. Deck Ass'y.
97	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
98	710-0599		Hex TT-Tap Scr. 1/4-20 x .5"
99	756-0531A		Engine Pulley
100	714-0118		Sq. Key 1/4 x 1.5" Lg.
101	736-0242		Bell-Wash. .345" I.D. x .88"
102	710-0833		Hex Bolt 5/16-18 x 5.25" Lg.
103	17358C		Belt Keeper Brkt. Ass'y.
104	683-0008		Shift Lever Link Ass'y.
105	710-3056		Hex Bolt 5/16-18 x 3.25" Lg.
106	16888		Deck Idler Support Brkt.
?107	736-0264		Fl-Wash. .344" I.D. x .62" O.D.
110	683-0007		Shift Lever Ass'y.
?112	710-1048		Socket Hd. Cap Scr. #10 x 24
113	618-0003		Transmission Comp.
114	736-0258		Fl-Wash. 3/8" I.D. x 1.0" O.D.
118	741-0419		Nyliner Flanged Brg.
119	17180		Variable Speed Support Brkt.
120	725-3169A		Safety Switch (Clutch)
121	711-0832		Adjustment Ferrule 3/8-24 Thd.
122	736-0204		Fl-Wash. .344" I.D. x .62" O.D.
123	736-0270		Bell-Wash. .265" I.D. x .75" O.D.
124	783-0015		Shift Lever Support Brkt.
125	747-0820		Shift Lever Rod
126	717-0772A		Actuating Arm
127	714-0507		Cotter Pin 3/4" Lg.
128	714-0149B		Internal Cotter Pin
129	710-0909A		Hex Wash. Hd. TT-Tap Scr. 5/16-18 x 1.75" Lg.



Ref #	Part Number	Qty	Description
1	738-0296		Shld. Bolt .437" Dia. x .162"
2	736-0141		Spr. Wash. .445" I.D.
3	732-0581B		Ext. Spring 5.31" Lg.
4	736-0119		L-Wash. 5/16" I.D.
5	712-0267		Hex Nut 5/16-18 Thd.
6	710-0601		Hex Wash. Hd. Tap Scr. 5/16-18 x .7" Lg.
7	736-0159		Fl-Wash. .344" I.D.
8	722-0160		Bushing
9	732-0588		Compression Spring
10	17702		Seat Pivot Brkt. Support - R.H.
11	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
12	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .5" Lg.
13	710-1228		Torx Hd. AB-Tap Scr. 5/16-18 x .75" Lg.
14	725-1303		Spring Switch
15	726-0279		Insulator Plate
16	738-0155		Shld. Bolt .437" Dia. x .162"
17	17701		Seat Pivot Brkt. Support - L.H.
18	16848C		Seat Plate
19	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
20	731-0405		Snap Bushing
22			Shift Cover
23	736-0329		L-Wash. 1/4" I.D.
24	712-0287		Hex Nut 1/4-20
25	710-0118		Hex Bolt 5/16-18 x .75" Lg.
26	15846		Fender Bracket - R.H.
	15847		Fender Bracket - L.H.
	17406		Fender Bracket - R.H.
	17407		Fender Bracket - L.H.
27	736-0242		Bell-Wash. .345" I.D. x .88"
28	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg.
29	710-1012		Rib Neck Bolt 5/16-24 x .75" Lg.
30	738-0435		Running Board Rod
31	16922		Running Board - R.H.
	16921		Running Board - L.H.
32	712-0123		Hex Nut 5/16-24 Thd.
33	726-0139		Speed Nut #10Z
34	17360		R.H. Side Frame
35	17361A		L.H. Side Frame
36	17359A		Lower Frame
37	731-1052		Rubber Foot Pad
38	757-0345		Seat Ass'y. (8-7/8" High)
	757-0338		Seat Ass'y. (10-5/8" High)
	757-0350		Seat Ass'y. (14-1/4" High)
39	15607D		Seat Pivot Bracket
40	710-0623		Hex Tap Scr. 3/8-36 x .75" Lg.
41	831-0823A		Throttle Control Box Ass'y.
42	746-0634		Throttle Control Wire 35" Lg.
43	17239A		Seat Lift Bracket
44	725-1439		Seat Spring Switch
45	726-0278		Insulator Boss Plate



Ref #	Part Number	Qty	Description
1	16512		Steering Column Ass'y.
2	738-0763		Lower Steering Shaft
3	710-0958		Hex Bolt 1/4-20 x 1.31" Lg.
4	712-0324		Hex L-Nut 1/4-20 Thd.
5	712-0318		Hex Jam Nut 5/8-18 Thd.
6	717-0943A		Steering Gear Segment
7	736-0317		Bell-Wash. 5/8" I.D. x 1.25" O.D.
8	712-0241		Hex Nut 3/8-24 Thd.
9	712-0711		Hex Jam Nut 3/8-24 Thd.
10	736-0169		L-Wash. 3/8" I.D.
11	738-0768		Steering Gear Segment Shaft
12	736-0187		FI-Wash. .64" I.D. x 1.24" O.D.
13	748-0227A		Hex Flange Brg. .63" I.D.
14	723-3018		Ball Joint Ass'y.
15	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
16	16888		Deck Idler Support Brkt.
17	736-0343		FI-Wash. .33" I.D. x 1.25" O.D.
18	750-0532		Spacer .985" I.D. x 1.25" O.D.
19	736-0119		L-Wash. 5/16" I.D.
20	712-0123		Hex Nut 5/16-24 Thd.
21	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
22	16894		Bearing Retainer Brkt.
23	710-0157		Hex Bolt 5/16-24 x .75" Lg.
24	710-0793		Ribbed Neck Bolt 3/8-24 x .8" Lg.
25	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
26	747-0579		Steering Drag Link
27	16896		Pivot Bar Side Plate - R.H.
28	16897		Pivot Bar Side Plate - L.H.
29	710-0538		Hex Bolt 5/16-18 x .62" Lg.
30	16918		Steering Arm
31	738-0777		Deck Connecting Rod
32	738-0775		Pivot Bar Shld. Bolt 3/8-16 x 5/8" Lg.
33	731-0484A		Cap
34	714-0121		Cotter Pin 5/32" Dia.
35	736-0316		Flat Washer
36	741-0523		Flange Brg. .757" I.D.
37	747-0721		Tie Rod 20.25" Lg. (Adjustable)
	747-0862		Tie Rod 21.83" Lg. (Non-Adjustable)
38	16843		Pivot Bar Assy.
39	16889		Pivot Bar Support Brkt.- Front
40	16890		Pivot Bar Support Brkt.- Rear
41	736-0188		FI-Wash. .76" I.D. x 1.49" O.D.
42	16913		Front Axle Ass'y.- L.H.
43	16912		Front Axle Ass'y.- R.H.
44	736-0286		Bowed Washer
45	748-0160		Spacer .755" I.D. x 1.25" O.D.
46	710-0331		Hex Bolt 3/8-24 x 2.25" Lg.
47	712-0798		Hex Nut 3/8-16 Thd.
48	741-0516		Flange Brg. .75" I.D.
49	736-0316		FI-Wash. .71" I.D. x 1.5" O.D.
50	634-0061		Wheel Ass'y. Comp.
	734-0427		Tire Only
51	634-0023		Rim Only
52	726-0271		Push Nut
53	711-0222		Battery Hold Down Rod
54	17635		Battery Plate
	17634		Battery Plate
55	710-0258		Hex Bolt 1/4-20 x .62" Lg.
56	736-0329		L-Wash. 1/4" I.D.
57	712-0287		Hex Nut 1/4-20 Thd.

Ref #	Part Number	Qty	Description
57	712-0287		Hex Nut 1/4-20 Thd.
58	725-1635		Battery (275 Cold Crank Amps)
59	731-1132		Battery Cover
60	712-0113		Wing Nut Plastic 1/4-20 Thd.
61	731-0954		Steering Bellow
	731-0559		Steering Bellow
62	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
64	731-0805		Steering Wheel (3 Spoke)
	731-0806A		Steering Wheel (4 Spoke)
65	731-0220		Steering Wheel Cap
66	712-0237		Hex L-Nut 5/16-24 Thd.
67	17359A		Lower Frame
68	731-1049		Pivot Bar End Cap
69	737-0280		Grease Fittings
70	714-0149B		Internal Cotter Pin
71	731-0484A		Hub Cap
	734-1503		Hub Cap (5 Spoke)
72	727-0425A		Spring Clip
73	710-0837		Oval Hd. Cr.-Sunk Scr. #10 x 5/8" Lg.
74	741-0356		Flange Brg. .89" I.D. x 1.36" O.D.
75	734-0255		Air Valve
76	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
77	712-0446		Hex Jam L-Nut 3/8-24 Thd.
78	737-0280		Grease Fitting

Ref #	Part Number	Qty	Description
1	717-0682		Puck Plate
2	761-0200		Brake Puck
3	717-0772A		Actuating Arm
4	736-0371		FI-Wash. 11/32" I.D. x 7/8" O.D.
5	17841A		Brake Stop Brkt.
6	710-0433		Hex Bolt 1/4-20 x .62" Lg.
7	710-0809		Hex Tap Scr. 1/4-20 x 1.25" Lg.
8	732-0863		Spring Detent
9	712-0335		Castle Nut 5/16-24 Thd.
10	714-0111		Cotter Pin 3/32" Dia. x 1" Lg.
11	718-0184		Brake Disc
12	717-1102		Shifter Ass'y.
13	717-1217		Brake Puck Holder
14	716-0175		Retaining Ring
15	717-1093		Shaft Drive
16	717-1268		Shift Collar
17	710-0653		Hex Wash. Hd. Tap Scr. 1/4-20 x .38" Lg.
18	717-1184		Drive Pin
19	717-1275		Bevel Gear Ass'y.
20	717-1269		Spring Retaining Plate
21	732-0590		Drive Spring
22	736-0444		FI-Wash. .915" I.D. x 1.5" O.D.
23	736-0454		FI-Wash. .915" I.D. x 1.37" O.D.
24	710-0862A		Pan Hd. Scr. 1/4-20 x .5" Lg.
25	716-0184		Snap Ring
26	711-0918		Cross Shaft
27	717-1020		Miter Gear 15T
28	717-1252		Differential Can Assembly
29	717-1254		Differential Gear Ass'y. w/Bearing
30	712-0200A		Hex Ins. L-Nut 1/2-20 Thd.
31	717-1019		Miter Gear
32	711-0865		Axle
33	750-0787		Differential Thrust Spacer
34	716-0171		Retainer Ring
35	619-0001		Input Bearing Housing
36	732-0614		Wire Ring
37	716-0108		Retaining Ring
38	717-0633		Pinion Input 14T
39	711-0864		Input Shaft
40	721-0178		Seal 5/8" I.D.
41	736-0419		Thrust Wash. .621" I.D. x 1.12"
42	741-0469		Thrust Bearing
43	736-0335		FI-Wash. 5/8" I.D. x 1.25" O.D.
44	741-0335		Needle Brg. 5/8" x 1/2" Lg.
45	715-0209		Dowel Pin
46	717-1235		R.H. Housing
47	741-0340		Sleeve Bearing 3/4" I.D.
48	741-0548		Flange Bearing .906" I.D.
49	717-0796		Sq. Head Bolt 5/16-24 Thd.
50	717-1234		L.H. Housing
51	741-0124		Ball Bearing .669" I.D.
52	710-3006		Set Screw 5/16-18 x 3/8" Lg.
53	736-0445		FI-Wash. .76" I.D. x 1.5" O.D.
54	741-0343		Brake Actuating Pin
55	741-0862		Ball Detent
56	732-0545		Ext. Spring 1.14" Lg.
57	741-0552		Differential Flange Brg.
58	618-0013		Axle Horn Ass'y.
59	721-0179		Oil Seal 3/4" I.D.
60	736-0217		L-Wash. 3/8" I.D. (H.D.)

Ref #	Part Number	Qty	Description
60	736-0217		L-Wash. 3/8" I.D. (H.D.)
61	710-0191		Hex Bolt 3/8-24 x 1.25" Lg.
62	710-0689		Nylon Hex Cap Scr. 1/2-13 x .75" Lg.
	618-0003		Transaxle Complete