





Ref #	Part Number	Qty	S/P/F	Description
1	618-0624	1	S	Pulley/ Spindle Assembly
2	683-04138	1	S	Deck Brake Assembly
3	683-04162	1	S	42" Deck Assembly
4	683-04167	1	S	Deck Brake Assembly
5	683-0254B	1	/P	Deck Hanger Bracket Assembly
6	710-0751	1	/P	Screw, 1/4-20 x.620
7	710-0650	1	/P	Screw, 5/16-18 x.875
8	710-0528	1	/P	Screw, 5/16-18 x 1.25
9	710-0726	1	/P	Screw, 5/16-12 x.750
10	710-1260A	1	/P	Screw, 5/16-18 x.750
11	710-0778	1	/P	Screw, 1/4-20 x 1.500
12	710-3085	1	/P	Screw, 3/8-16 x 3.50
13	711-04069	1	S	Grass catcher Pin
14	712-3006	1	/P	Hex Nut, 1/4-20
15	712-0417A	1	/P	Flange Nut, 5/8-18
16	712-04064	1	/P	Flange Lock Nut, 1/4-20
17	712-04063	1	/P	Flange Lock Nut, 5/16-18
18	712-04065	1	/P	Flange Lock Nut, 3/8-16
19	712-0641	1	S	Hex Nut, M16-1.5
20	712-3083	1	/P	Hex Lock Nut, 1/2-13
21	712-0206	1	S	Hex Nut, 1/2-13
22	714-0470	1	S	Cotter Pin, 1/8 x 1.25
23	714-0104	1	S	Cotter Pin,.072 Dia. x 1.13 Lg.
24	717-04074	1	S	Deck Adjustment Gear
25	726-0233	1	/P	Push Nut,.25 ID x.50 OD
26	732-0306A	1	S	Compression Spring,.531 OD x 1.75 Lg.
27	732-0308A	1	/P	Extension Spring,.50 Dia. x 6.37 Lg.
28	734-0973	1	/P	Deck Wheel
29	736-0119	1	S	Lock Washer, 5/16
30	736-0270	1	/P	Bell Washer,.265 x.75 x.062
31	736-0289	1	S	Shoulder Bushing,.320 ID x.135 Lg.
32	736-0267	1	S	Flat Washer,.385 x.87 x.06
33	736-0225	1	/P	Lock Washer, 5/8
34	736-0187	1	/P	Flat Washer,.64 x 1.24 x.06
35	738-0373	1	S	Shoulder Screw,.498 x 1.53 x 3/8-16
36	738-04162	1	S	Shoulder Spacer,.8540 x.200
37	738-04146	1		Plug
38	742-0616A	1	S	Blade, 21.23", Star 3-in-One
39	747-1116	1		Deck Release Handle Rod
40	747-04269A	1	/P	Front Deck Adjustment Rod
41	747-04379	1	S	Brake Control Rod
42	748-04069	1		Deck Lift Pivot Cup
43	750-0566A	1	/P	Spacer,.260 x.372 x 1.030 Lg.
44	754-04060B	1	S	V-Belt, 96.3 Lg.
45	756-04129	1	/P	Idler Pulley, 4.25" Dia.
46	783-04327	1		Belt Cover
47	N/A	1		Chute Stop not used
48	710-3144	1	/P	Screw, 3/8-16 x 2.00
49	712-0431	1	S	Flange Lock Nut, 3/8-16
50	712-0229	1		Push Nut, 3/8
51	732-04287	1		Extension Spring,.500 Dia. x 6.375 Lg
52	750-04446	1		Spacer, 3/8 ID x.68 OD x 1.46 Lg
53	731-1032B	1	S	Discharge Chute





Ref #	Part Number	Qty	S/P/F	Description
54	710-0134	1	/P	Carriage Screw, 1/4-20 x.62 If Equipped
55	710-0599	1	/P	Screw, 1/4-20 x.500 If Equipped
56	712-3087	1	/P	Wing Nut, 1/4-20 If Equipped
57	731-2363	1	/P	Mulch Plug If Equipped
58	783-1146A	1	S	Deck Skirt If Equipped




IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Ref #	Part Number	Qty	S/P/F	Description
1	17840	1	S	Transmission Mounting Bracket
2	618-0319	1	S	Hydrostatic Transmission
3	629-0949A	1		Harness Assembly (Not Shown)
4	710-0227	1	/P	AB Screw #8-18 x 0.5
5	710-0344	1	/P	Hex Bolt 3/8-16 x 1.5
6	710-0599	1	/P	TT Screw 1/4-20 x 0.5
7	710-0726	1	/P	AB Screw 5/16-12 x 0.75
8	710-0502A	1	/P	TT Sems Screw 3/8-16 x 1.250
9	710-1266	1	/P	Hex Bolt 5/16-18 x 3.5
10	710-3007	1	/P	Carriage Screw
11	710-3011	1	/P	Hex Bolt 3/8-16 x 2.25
12	710-0809	1		Screw, 1/4-20 x 1.250
13	711-0832	1	S	Ferrule
14	736-0320	1	/P	Flat Washer,.38 x 1.38 x.125
15	712-0291	1	S	Hex Lock Nut 1/4-20
16	712-3066	1	S	Hex Nut, 1/2-20
17	712-04063	1	/P	Flange Lock Nut, 5/16-18
18	712-0431	1	S	Flanged Lock Nut 3/8-16
19	750-0566A	1	/P	Spacer,.260 x.372 x 1.030 Lg
20	712-3017	1	S	Hex Nut 3/8-16
21	714-0104	1	S	Cotter Pin
22	714-0111	1	S	Cotter Pin
23	725-0157	1	/P	Cable Tie (Not shown)
24	725-1644	1		Switch
25	726-0154	1	S	Cable Tie (Not shown)
26	726-0320	1	S	Insulator Nut Plate
27	731-04682	1		Sleeve, 0.758 x 0.821 x 1.5
28	731-1449A	1	S	Blade Fan
29	732-0209	1	S	Extension Spring
30	732-0429A	1	S	Extension Spring
31	732-0716	1	S	Extension Spring
32	732-0729	1	/P	Wire Ring
33	732-0994	1		Extension Spring
34	732-3118	1		Extension Spring
35	736-0169	1	S	Lock Washer
36	736-0866	1		Flat Washer
37	736-0921	1	S	Lock Washer
38	736-3010	1		Flat Washer
39	738-0372B	1	/P	Shoulder Spacer
40	747-04139	1		Brake Rod
41	747-1149	1		Bypass Rod
42	747-1151	1		Control Rod
43	748-0334	1	S	Transaxle Spacer
44	731-2290A	1	/P	Hub Cap
45	754-0461	1	S	V Belt, A x 78" Lg
46	756-0116A	1	S	Idler Pulley
47	756-0981B	1	S	Flat Idler Pulley
48	756-04111	1		Input Pulley
49	783-04442	1		Idler Bracket
50	783-0810B	1	S	Torq Bracket
51	783-1019	1	S	Actuator Bracket
52	647-0031B	1	S	Brake Control Assembly
53	647-0049A	1	S	Hydrostatic Control Assembly

Ref #	Part Number	Qty	S/P/F	Description
54	683-0267C	1	/P	Pedal Assembly
55	710-0650	1	/P	TT Screw 5/16-18 x 0.875
56	736-0187	1	/P	Flat Washer,.64 x 1.24 x.06
57	710-1260A	1	/P	LD Screw 5/16-18 x 0.75
58	710-1611B	1	/P	TT Screw 5/16-18 x 0.75
59	711-04159B	1		Pin
60	712-04065	1	/P	Flange Lock Nut, 3/8-16
61	712-3004A	1	/P	Flange Lock Nut, 5/16-18
62	714-0104	1	S	Cotter Pin
63	714-0111	1	S	Cotter Pin
64	732-0335	1		Compression Spring
65	732-0955	1		Extension Spring
66	732-0963	1		Extension Spring
67	735-0662	1		Control Pedal
68	735-3049	1	S	Brake Control Pedal
69	736-3008	1	S	Flat Washer
70	738-0155	1	S	Shoulder Screw
71	738-0380	1	S	Shoulder Screw
72	741-0225	1	S	Hex Flange Bearing
73	741-3065B	1	/P	Hex Flange Bearing
74	747-04093	1		Brake Lock Control Rod
75	747-04096	1		Cruise Control Rod
76	748-04039B	1	/P	Cruise Latch
77	783-04612	1	S	Steering Support Bracket
78	683-04185	1		Lockout Bracket
79	783-0773A	1		Brake Pedal
80	710-0224	1	S	Screw, #10-16 x.500
81	17962	1		Switch Plate
82	725-04039	1	S	Interlock Switch
83	783-04707	1		Parking Brake Switch Bracket
84	736-0430	1	/P	Flat Washer,.350 x 1.59 x.062
85	736-0242	1	/P	Bell Washer,.340 x.872 x.060
86	710-0627	1	/P	Screw, 5/16-24 x.750
87	634-0104	1		Wheel Complete, 20 x 8 x 8
	734-1730	1		Tire Only, 20 x 8 x 8
	734-0603A	1	S	Rim Only




Ref #	Part Number	Qty	S/P/F	Description
1	710-0227	1	/P	Self-tapping Screw, #8-18 x.50
2	710-0599	1	/P	Self-tapping Screw, 1/4-20 x.50
3	710-0726	1	/P	Self-tapping Screw, 5/16-18 x.625
4	710-1237	1		Screw, #10-32 x.625 (B&S OHV V-Twin/ Single)
5	710-1314A	1		Screw, 5/16-18 x.625 (B&S OHV V-Twin/ Single)
6	710-1315	1	/P	Self-tapping Screw, 3/8-16 x 1.25
7	712-3017	1	S	Hex Nut, 3/8-16
8	721-0460	1		Exhaust Gasket (B&S OHV V-Twin)
9	726-0205	1	/P	Hose Clamp
10	751B213146	1	/P	Casing Clamp (B&S OHV Single)
11	736-0300	1	S	Lock Washer,.406 x.875 x.059
12	751B221535	1	/P	Casing Clamp (B&S OHV V-Twin)
13	751-0535	1		Fuel Line Hose
14	751-0564A	1	S	Muffler Deflector
15	751-0616A	1	S	Muffler, Twin Inlet (B&S OHV V-Twin)
	751-0805	1	S	Muffler, Twin Inlet (Kohler V-Twin)
16	751-0650B	1		RH Exhaust Pipe (B&S OHV V-Twin)
	751-0645A	1	/P	RH Exhaust Pipe (Kohler V-Twin)
17	751-0651B	1	/P	LH Exhaust Pipe (B&S OHV V-Twin)
	751-0644B	1		LH Exhaust Pipe (Kohler V-Twin)
18	751-3140	1	S	Oil Drain Valve
19	751-3141	1	S	Oil Drain Hose
20	751-3142	1	S	Oil Drain Cap
21	783-0615D	1	S	Muffler Heat Shield
22	783-0625C	1	/P	Engine Heat Shield (B&S OHV V-Twin)
23	712-0271	1	/P	Hex Sems Nut, 1/4-20 (B&S OHV V-Twin/ Single)
24	725-0157	1	/P	Cable Tie
25	751-10047	1		Exhaust Pipe (Kohler)
	751-0619A	1	/P	Exhaust Pipe (B&S OHV Single)
26	726-0272	1	/P	Clamp (Kohler)
27	751-0617A	1	S	Muffler, Single Inlet
28	710-0654A	1	/P	Screw, 3/8-16 x 1.00 (Kohler)
29	736-0277	1		Flat Washer (Kohler)
30	721-0208	1	S	Exhaust Gasket (B&S OHV Single)
31	746-1084	1		Throttle Cable (B&S OHV Single)
32	732-0966	1		Extension Spring,.275 x 1.25 (B&S OHV Single)




Ref #	Part Number	Qty	S/P/F	Description
1	710-1268	1	/P	Screw, #10-16 x.375
2	712-04063	1	/P	Nut, Flange Lock, 5/16-18, Gr F, Nylon
3	712-3027	1	S	Nut, Flange Lock, 1/4-20
4	720-0309A	1	/P	Seat Adjuster Grip
5	726-0201	1		Nut, Speed,.3125 ID
6	731-04074	1		Spacer
7	732-0499	1		Compression Spring,.41 x 1.5
8	732-1184	1		Spring, Extension,.84 Dia. x 4.6
9	736-0275	1	S	Wash, Flat,.344 x.688 x.065
10	736-3019	1		Wash, Flat,.531x 1.062 x.134
11	738-0137A	1	S	Screw, Shoulder,.340 x.285,1/4-20
12	738-0296	1	S	Screw, Shoulder,.437 x.268, 5/16-18
13	738-0966	1	S	Screw, Shoulder,.50 x.925, 3/8-16
14	783-0209C	1	S	Seat Bracket, Lift
15	783-0611	1		Seat Stop
16	783-0738B	1	S	Seat Pivot Bracket
17	783-0739A	1	S	Seat Adjustment Lever
18	783-0753	1		Seat Adjustment Selector
19	757-04020A	1	S	Medium Back Seat
	757-04003	1		High Back Seat
20	726-3046	1	/P	Ratchet Clip
21	735-0672	1		RH Foot Pad, Rubber
22	735-0673	1		LH Foot Pad, Rubber
23	710-0260A	1	/P	Bolt, Carriage, 5/16-18,.62, Gr1
24	710-0599	1	/P	Screw, 1/4-20, 0.500
25	710-0726	1	/P	Screw, 5/16-12, 0.750
26	710-1611B	1	/P	Screw, 5/16-18 x.750
27	783-04081A	1		Seat Pivot Bracket, Manually Adjusted
28	731-04591A	1	/P	Cup Holder
29	736-3078	1	/P	Washer, Flat,.344 x 1.0 x.063
30	783-04437A	1	/P	Fender
31	783-1010A	1	S	Plate, Deck Lift
32	783-1489A	1	/P	Mounting Bracket, Seat
33	710-0227	1	/P	Screw, #8-18 x.50
34	726-0279	1		Plate, Insulator
35	725-1303	1	S	Spring Switch, Outer
36	725-1439	1		Spring Switch, Inner
37	726-0278	1		Plate, Insulator Boss
38	683-04079	1		Shaft Assembly, Lift
39	712-04065	1	/P	Nut, Flange Lock, 3/8-16, Gr F, Nylon
40	714-0104	1	S	Pin, Cotter,.072 Dia. x 1.13
41	714-0111	1	S	Pin, Cotter, 3/32, 1.0
42	716-0106A	1		Ring, E Type,.625 Dia.
43	720-0311	1		Grip, Handle, 1/2
44	732-0874	1		Spring, Torsion
45	738-0138A	1	/P	Screw, 5/16-18 x.620 Gr2
46	738-04130	1		Screw, Shld,.625 x.165, 3/8-16 (42" Deck)
	738-0380	1	S	Screw, Shld,.50 x.27, 3/8-16 (46" Deck)
47	741-0225	1	S	Bearing, Hex Flange
48	746-0968	1		Cable, Lift, 16.16
49	747-04155	1		Handle, Lift
50	756-1154	1		Pulley, Roller
51	783-04711	1		Arm, Lift - LH (42" Deck)

Ref #	Part Number	Qty	S/P/F	Description
	783-04494	1		Arm, Lift - RH (42" Deck)
	783-0678A	1		Arm, Lift (46" Deck)
52	736-0607	1	/P	Lock Washer, 5/16
53	738-04012	1	S	Shoulder Screw
54	720-04009	1	S	Knob, 3/8-16
55	736-0101	1	S	Flat Washer,.406 x 1.00 x.030
56	710-0870	1	/P	Hex Head Washer Screw, 3/8-16 x.625




Ref #	Part Number	Qty	S/P/F	Description
1	17962	1		Plate, Switch
2	647-04036	1	S	Lever Assembly, Engagement
3	710-0809	1		Screw, 1/4-20 x 1.250
4	710-0859	1	/P	Screw, 3/8-16, 2.50
5	710-0276	1	/P	Screw, Carriage, 5/16-18, 1.00
6	710-1260A	1	/P	Screw, 5/16-18 x.750
7	710-3157A	1	/P	Screw, 7/16-20, 3.25, Gr5
8	710-0726	1	/P	Screw, 5/16-12, 0.750
9	714-0145	1	S	Click Pin
10	732-04248	1		Extension Spring,.38OD x 3.9LG
11	736-0171	1	S	Lock Washer, 7/16
12	746-04092	1		Deck Engagement Cable
13	712-04065	1	/P	Nut, Flange Lock, 3/8-16, Gr F, Nylon
14	750-0566A	1	/P	Spacer,.260 x.372 x 1.030LG
15	714-0470	1	S	Pin, Cotter, 1/8 x 1.25
16	726-0201	1		Nut, Speed,.3125 ID
17	731-2111A	1	S	Knob, PTO
18	783-04590	1	S	Cable Bracket
19	736-0322	1	/P	Washer, Flat,.450 x1.250 x.164
20	741-0708	1		Bearing, Flange, Hex Split.500 ID
21	747-04307	1		Keeper Rod, Belt
22	747-1112D	1	S	Engagement Handle, Deck
23	748-0415B	1	/P	Spacer,.385 ID x.635 OD x 1.54
24	750-0956	1		Spacer, 1.010 x 1.400 x.825
25	756-04067A	1	S	Pulley, Engine, 3.56 x 6.12 Diameter
26	783-0744A	1		Stop Bracket, Engagement
27	683-04173	1	S	Frame Assembly, Lower
28	710-0607	1	/P	Screw, 5/16-18, 0.500
29	710-0642	1	/P	Screw, 1/4-20, 0.750
30	710-3005	1	/P	Screw, 3/8-16, 1.25, Gr5
31	712-04064	1	/P	Nut, Flange Lock, 1/4-20, Gr F, Nylon
32	712-3006	1	/P	Nut, Hex, 1/4-20, Gr5
33	732-04035	1		Spring, Compression, 1.28 OD x 3.125
34	736-0222	1	S	Washer, Lock, 1/4, External
35	736-0329	1	S	Washer, Lock, 1/4
36	738-04058	1		Spacer, Shoulder,.38 x 1.0 x.70
37	747-04121A	1		Hold Rod, Battery
38	783-0349	1		Battery Tray
39	783-04329A	1		Seat Bracket, Frame
40	783-04375A	1		Frame, Upper
41	710-0599	1	/P	Screw, 1/4-20, 0.50
42	725-1426A	1	S	Solenoid, 12V, 100 Amp
43	725-04039	1	S	Switch, Interlock
44	710-0224	1	S	Screw, #10-16,.50
45	712-3004A	1	/P	Nut, Flange, Lock Nut, 5/16-18
46	712-0271	1	/P	Nut, Sems, 1/4-20
47	725-1737A	1	S	Battery, 190 CCA
48	738-1132	1		Screw, Shoulder,.250 x.15, 1/4-20
49	710-0703	1	/P	Screw, Carriage, 1/4-20,.75
50	712-3087	1	/P	Nut, Wing, 1/4-20
51	736-0275	1	S	Flat Washer,.344 x.688 x.065



Ref #	Part Number	Qty	S/P/F	Description
1	710-0726	1	/P	Screw, 5/16-12 x.750
2	710-0599	1	/P	Self-tapping Screw, 1/4-20 x.5
3	710-0751	1	/P	Hex Cap Screw, 1/4-20 x.62
4	746-1084	1		Throttle/Choke Cable (Kohler Courage)
	746-1086	1		Throttle Cable (Kohler/ B&S Twin)
5	746-1085A	1	/P	Choke Knob/Cable (Kohler/ B&S Twin)
6	731-04949	1	S	Headlight Lens
7	738-04091	1		Shoulder Screw,.43 x.29
8	783-04551	1		Hood, 1 Style
9	783-04552	1		Grill, 1 Style
10	783-04578	1	S	Pivot Bracket - RH
	783-04577	1	S	Pivot Bracket - LH
11	783-04621	1	S	Grill Pivot Bracket
12	712-04064	1	/P	Flange Lock Nut, 1/4-20
13	751-0659C	1	S	Fuel Tank, Two Gallon (shown)
	751-0658E	1	/P	Fuel Tank, Three Gallon
14	751-0603	1	S	Fuel Cap (fits either tank)
15	710-1017	1	/P	Screw, 1/4-14 x.625
16	710-0895	1		Self-tapping Screw, 1/4-15 x.75
17	710-3217	1	/P	Truss Phillips Screw, #8-32 x.375
18	712-0142	1	/P	Hex Nut, #8-32
19	731-1857	1		Throttle Control Knob
20	731-05001	1	S	Dash Panel (Models w/ Manual PTO)
	731-05005	1		Dash Panel (Models w/ Electric PTO)
21	731-04215	1	S	Cruise Control Button
22	731-04217	1	S	Parking Brake Button
23	736-0142	1	S	Flat Washer, 9/32 x 1/2 x 1/16
24	747-1196	1		Brake/Cruise Pivot Rod
25	629-04083	1	S	Headlight Wire Harness Not Shown
26	731-05165	1		Hood Plenum
27	725-1752	1	S	Electric PTO Switch (If Equipped)
28	710-0642	1	/P	Self-tapping Screw, 1/4-20 x.75
29	783-0462	1	/P	Switch Brkt., Electric PTO (If Equipped)
30	725-0963	1	S	Lamp
31	736-0270	1	/P	Bell Washer,.265 x.75 x.062
32	710-1611B	1	/P	Screw, 5/16-18 x.75
33	725-1649	1	S	Headlight Socket
34	710-1652	1	/P	Hex Index Screw, 1/4-20 x.625
35	731-1999	1		Choke Plug (Kohler Courage)
36	725-1745	1	S	Ignition Key w/ plastic cover
	725-1744	1	S	Ignition Key w/o plastic cover
37	725-04227	1	S	Ignition Switch
38	725-04036A	1	S	Systems Ind. Monitor w/ Hour Meter
	725-04156	1	S	Systems Ind. Monitor w/ Ammeter
39	783-04323B	1	S	LH Dash Support Plate
40	783-04285B	1	S	RH Dash Support Plate
	629-04144	1		Jumper Harness (Models w/ Manual PTO) Not Shown
	629-04137	1		Wire Harness (models w/ Electric PTO & Hour Meter) Not Shown

Ref #	Part Number	Qty	S/P/F	Description
	629-04105	1		Wire Harness (models w/ Manual PTO & Hour Meter) Not Shown
	629-04103	1		Wire Harness (models w/ Manual PTO & Ammeter) Not Shown



Ref #	Part Number	Qty	S/P/F	Description
1	710-04095	1		Hex Screw, 3/8-16, 1.00, Gr5
2	710-0514	1	/P	Hex Screw, 3/8-16, 1.00, Gr5
3	710-0643	1	/P	Hex Screw, 5/16-18, 1.00, Gr5
4	711-1408	1		Link, Drag, RH
5	711-1409A	1	/P	Link, Drag, LH
6	712-0214	1	S	Nut, Hex Lock, 3/8-24
7	712-04065	1	/P	Nut, Flange Lock, 3/8-16, Grf, Nylon
8	712-0459	1	/P	Nut, Flange Lock, 7/16-20
9	712-3004A	1	/P	Nut, Flange Lock, 5/16-18, Gr5
10	712-0240	1	S	Nut, Jam, 7/16-20, Gr2
11	717-1550E	1	S	Gear, Steering, 11/90 Ratio
12	717-1554	1		Gear, Pinion, Steering
13	723-0448A	1	S	Ball Joint, 7/16-20, Lock
14	736-3004	1	S	Washer, Flat,.406 x.875 x.105
15	736-3084	1	/P	Washer, Flat,.51 x 1.12 x.06
16	710-0726	1	/P	Screw, 5/16-12, 0.750
17	738-04154	1		Spacer, Shoulder,.38 x 1.00 x.31
18	738-1001A	1	/P	Shaft, Steering,.625 OD x 24.25 Lg
19	741-0475	1	S	Plastic Bushing.380 ID
20	738-0143	1	/P	Screw, Shoulder,.498 x.340, 3/8-16
21	783-0726D	1	/P	Pivot Bracket, Support RH
22	783-0727C	1	/P	Pivot Bracket, Support LH
23	783-0728	1		Pivot Bracket, Bar
24	631-04028	1		Steering Wheel
25	731-04039	1		Steering Wheel Cap
26	738-04128	1		Shlder Screw,.5 x 2.380, 3/8-16 (42H)
	738-1011A	1	/P	Shlder Screw,.5 x 2.2, 3/8-16 (46H)
27	731-2290A	1	/P	Deluxe Hub Cap
28	736-0316	1	S	Flat Washer,.78 x 1.589 x.06
29	714-04039	1		Cotter Pin, 5/32 x 1.25
30	719-04105	1	S	Cast Iron Pivot Bar
31	726-0341	1	/P	Push Cap
32	638-04006	1	S	LH Axle Assembly,.750 (42H)
	638-04003	1	S	LH Axle Assembly,.750 (46H)
33	638-04005	1	S	RH Axle Assembly,.750 (42H)
	638-04004	1	S	RH Axle Assembly,.750 (46H)
34	711-0332	1	S	Pin, Clevis,.50 x.78 (46H)
35	714-04023	1	S	Cotter Pin, Inter,.080 x 1.5625 (46H)
36	783-0720A	1	/P	Front Adjustment Bracket (46H)
37	783-04568	1		Deck Hanger Bracket, Front (42H)
38	741-0656A	1	S	Hex Flange Bearing
39	634-04086	1		Wheel Assembly Complete, 15 x 6
	734-1731	1		Tire Only 15 x 6 x 6
	634-04081	1	S	Rim Only w/Valve Stem