




Ref. No.	Part No.	Description
1	710-1268	Screw, #10-16 x.375
2	712-04063	Nut, Flange Lock, 5/16-18, GrF
3	712-04064	Nut, Flange Lock, 1/4-20
4	720-0309A	Seat Adjuster Grip
5	736-0204	Washer, Flat .344 x .62 .033
6	731-04074	Spacer
7	732-0499	Compression Spring,.41 x 1.5
8	732-1184	Spring, Extension,.84 Dia. x 4.6
9	736-0242	Wash, Flat, .340 x .688 x .065
10	736-3019	Wash, Flat,.531x 1.062 x.134
11	738-0137A	Screw, Shld, .340 x.285, 1/4-20
12	738-0296	Screw, Shoulder,.437 x.268
13	738-0966A	Screw, Should,.50 x.925, 3/8-16
14	783-0209D	Seat Bracket, Lift
15	783-0611	Seat Stop
16	783-0738C	Seat Pivot Bracket
17	783-0739A	Seat Adjustment Lever
18	783-0753	Seat Adjustment Selector
19	757-04001A	Low Back Seat
	757-04037	Medium Back Seat
	757-04003A	High Back Seat
20	726-3046	Ratchet Clip
21	735-0657	LH Foot Pad (<i>shown</i>)
	735-0673	LH Foot Pad, Rubber
22	735-0656	RH Foot Pad (<i>shown</i>)
	735-0672	RH Foot Pad, Rubber
23	710-0528	Hex Screw, 5/16-18 x 1.25
24	710-0599	Screw, 1/4-20, 0.500
25	710-0604A	Screw, 5/16-18, 0.625
26	710-0895	Screw, 1/4-15, 0.750
27	731-1990	Cover, Lift Lever
28a	731-04591A	Cup Holder
28b	731-1993A	Cover, w/ Cup Holder
29	736-3078	Washer, Flat,.344 x 1.0 x.063
30	783-04333A	Fender (4-Style) <i>shown</i>
	783-04437A	Fender (10-Style) <i>not shown</i>

Ref. No.	Part No.	Description
31	783-1010A	Adjust. Brkt, Lift (10-Style) <i>shown</i>
	783-0677B	Adjust. Brkt., Lift (4-Style)
32	783-1489C	Mounting Bracket, Seat
33	710-0227	Screw, #8-18 x.50
34	726-0279	Plate, Insulator
35	725-1303	Spring Switch, Outer
36	725-1439	Spring Switch, Inner
37	726-0278	Plate, Insulator Boss
38	683-04223	Deck Lift Shaft Assembly
39	712-04065	Nut, Flange Lock, 3/8-16, GrF
40	714-0104	Pin, Cotter,.072 Dia. x 1.13
41	714-0111	Pin, Cotter, 3/32, 1.0
42	716-0106A	Ring, E Type,.625 Dia.
43	720-0311	Grip, Handle, 1/2
44	732-0874	Spring, Torsion
45	738-0138A	Bolt, Shldr, 3/8-16 .496 x 2.50
46	738-04130	Scr.,Shldr, .625 x.165,(42" Deck)
	738-0380	Screw, Shld,.50 x.27, (46" Deck)
47	741-0225	Bearing, Hex Flange
48	746-0968	Cable, Lift, 16.16
49	747-04447	Handle, Lift
50	756-1154	Pulley, Roller
51	783-04711	Arm, Lift - LH (42" Deck)
	783-04494	Arm, Lift - RH (42" Deck)
	783-04963A	Arm, Lift (46" Deck) <i>shown</i>
52	736-0607	Lock Washer, 5/16
53	710-04593	Scr5/16-18 x.750 (10-Style)
	710-0604A	Screw, 5/16-18, 0.625 (4-Style)
54	738-04012A	Shoulder Screw
55	720-04061	Knob, 3/8-16
56	736-0300	Flat Washer, .406 x .875 x .059
57	783-04081B	Seat Pivot Bracket, Manual Adj.
58	710-04482	Hex Head Flange Screw, 3/8-16
59	735-0690	Grommet, .4375 x .750
60	750-3310	Flanged Spacer
61	710-0451	Carriage Bolt, 5/16-18 x .750

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Model Series 610




Ref. No.	Part No.	Description
1	710-04095	Hex Screw, 3/8-16, 1.00, Gr5
2	710-0514	Hex Screw, 3/8-16, 1.00, Gr5
3	710-0643	Hex Screw, 5/16-18, 1.00, Gr5
4	711-1408	Link, Drag, RH
5	711-1409A	Link, Drag, LH
6	712-0214	Nut, Hex Lock, 3/8-24
7	712-04065	Nut, Flange Lock, 3/8-16, Grf
8	712-0459	Nut, Flange Lock, 7/16-20
9	712-3004A	Nut, Flange Lock, 5/16-18, Gr5
10	712-0240	Nut, Jam, 7/16-20, Gr2
11	717-1550E	Gear, Steering, 11/90 Ratio
12	717-1554	Gear, Pinion, Steering
13	723-0448A	Ball Joint, 7/16-20, Lock
14	736-3004	Washer, Flat, .406 x .875 x .105
15	736-3084	Washer, Flat, .51 x 1.12 x .06
16	710-1260A	Screw, 5/16-18, 0.750
17	738-04154	Spacer, Shoulder, .38 x 1.00 x .31
18	738-1001A	Shaft, Steering, .625 OD x 24.25
19	741-0475	Plastic Bushing .380 ID
20	731-1291A	Pivot Bar End Cap
21	783-0726E	Pivot Bracket, Support RH
22	783-0727D	Pivot Bracket, Support LH
23	783-0728B	Pivot Bracket, Bar
24	631-04028	Steering Wheel
25	731-04039	Steering Wheel Cap

Ref. No.	Part No.	Description
	731-04040	Steering Wheel Cap, Sprig Logo
	731-04681	Steering Wheel Cap, Tine Logo
26	738-04128	Shoulder Bolt .5 x 2.38 3/8-16 42"
	738-1011A	Shoulder Bolt .5 x 2.23 3/8-16
27	731-05674	Hub Cap, Standard
28	736-04228	Flat Washer, .781 x 1.59
29	714-04039	Cotter Pin, 5/32 x 1.25
	736-0316	Washer, Flat .78 x 1.59 x .060
30	719-04105	Cast Iron Pivot Bar
31	726-0341	Push Cap
32	638-04003A	LH Axle Assembly, .750
33	638-04004A	RH Axle Assembly, .750
34	714-04023	Cotter Pin, .080 x 1.5625 Internal
35	741-0660A	Flange Bearing
36	731-04057A	Axle End Cap, Standard
37	741-0656A	Hex Flange Bearing
38	634-04086	Wheel Assembly Complete, 15x6
	734-1731	Tire Only 15 x 6 x 6
	634-04081	Rim Only w/ Valve Stem
39	783-04568	Frt. Deck Hang Bracket (42" Deck)
	783-0720A	Frt. Deck Hang Bracket (46" Deck)
40	638-04006	LH Axle Assembly, .750
41	638-04005	RH Axle Assembly, .750
42	683-0128B	Pivot Bar Axle Assembly
43	711-0332	Clevis Pin, .50 x .78 lg.

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Model Series 610




Ref. No.	Part No.	Description
1	710-0726	Screw, 5/16-12 x .750
2	710-0599	Self-tapping Screw, 1/4-20 x.5
3	710-0751	Hex Cap Screw, 1/4-20 x.62
4	746-04364	Throttle/Choke Control Cable
	746-04365	Throttle Control/Cable
5	731-1999	Choke Plug
6	731-04949	Headlight Lens
7	738-04091	Shoulder Screw,.43 x.29
8	783-04551	Hood, 1 Style
9	783-04552	Grill, 1 Style
10	783-04578	Pivot Bracket - RH
	783-04577*	Pivot Bracket - LH
11	783-04621	Grill Pivot Bracket
12	712-04064	Flange Lock Nut, 1/4-20
13	751-0659D	Fuel Tank, Two Gallon
	751-0658E	Fuel Tank, Three Gallon
14	751-0603	Fuel Cap
15	710-1017	Screw, 1/4-14 x.625
16	710-0895	Self-tapping Screw, 1/4-15 x.75
17	746-1085A	Choke Control Cable
18	725-04227B	Ignition Switch
19	731-05522	Hood Cover, 5 Style
20	731-05001B	Dash Panel

Ref. No.	Part No.	Description
21	731-04215	Cruise Control Button
22	731-04217	Parking Brake Button
23	736-0176	Flat Washer, .265 x .938 x 1.20
24	747-1196	Brake/Cruise Pivot Rod
25	629-04083A*	Headlight Wire Harness
26	731-05165A	Plenum, Kohler Twin
	731-05566	Plenum, Kohler Courage Single
27	783-04285E	RH Dash Support Plate
28	710-0607	Screw, 5/16-18 x .500
29	783-04323D	LH Dash Support Plate
30	725-0963	Lamp
31	736-0270	Bell Washer,.265 x.75 x.062
32	710-1611B	Screw, 5/16-18 x.75
33	725-1649	Headlight Socket
34	710-1652	Hex Index Screw, 1/4-20 x.625
35	725-1745	Ignition Key w/ plastic cover
	725-1744	Ignition Key w/o plastic cover
36	725-04036C	Systems Ind. Monitor w/Hr. Mtr.
	725-04156	Systems Ind. Monitor w/ Amtr.
—	725-04403*	Wire Harness (w/Hour Meter)
—	725-04411*	Wire Harness (w/Ammeter)
—	777X41984	Headlight Reflective Insert

* Not Shown

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.


Model Series 610



REF.	PART NO.	DESCRIPTION
1	17840	Transmission Mounting Bracket
2	618-0319	Hydrostatic Transmission
3	629-0949A	Harness Assembly
4	710-0227	AB Screw #8-18 x 0.375
5	710-0520	Hex Bolt 3/8-16 x 1.5
6	710-0653	TT Screw 1/4-20 x 0.5
7	710-0726	AB Screw 5/16-12 x 0.75
8	710-0502A	TT Sems Screw 3/8-16 x 1.250
9	710-1266	Hex Bolt 5/16-18 x 3.5
10	710-3007	Carriage Screw
11	710-3011	Hex Bolt 3/8-16 x 2.25
12	710-0778	Screw, 1/4-20 x 1.50
13	711-0832	Ferrule
14	736-0258	Flat Washer,.385 x 1.0 x .135
15	712-0291	Hex Lock Nut 1/4-20
16	712-3066	Hex Nut, 1/2-20
17	712-04063	Flange Lock Nut, 5/16-18
18	712-0431	Flanged Lock Nut 3/8-16
19	750-0566A	Spacer,.260 x.372 x 1.030 Lg
20	712-3017	Flanged Lock Nut 3/8-16
21	714-0507	Cotter Pin
22	714-0111	Cotter Pin
23	725-0157	Cable Tie <i>(Not shown)</i>
24	725-1644	Switch
25	726-0154	Cable Tie <i>(Not shown)</i>
26	726-0320	Insulator Nut Plate
27	731-05299	Sleeve, 0.765 x 1.5
28	731-1449A	Blade Fan
29	732-0209	Extension Spring
30	732-04323B	Extension Spring
31	732-0716	Extension Spring
32	732-0729	Wire Ring
33	732-0994	Extension Spring
34	732-3118	Extension Spring
35	736-0169	Lock Washer
36	736-0300	Flat Washer
37	736-0921	Lock Washer
38	736-3010	Flat Washer
39	738-0372B	Shoulder Spacer
40	747-04139	Brake Rod
41	747-1149	Bypass Rod
42	747-1151	Control Rod
43	748-0334	Transaxle Spacer
44	731-05674	Hub Cap
45	754-0461	V Belt, A x 78" Lg

REF.	PART NO.	DESCRIPTION
46	756-04209	Idler Pulley
47	756-04224	Flat Idler Pulley
48	756-04111	Input Pulley
49	783-04442	Idler Bracket
50	783-0810B	Torq Bracket
51	783-1019B	Actuator Bracket
52	647-04100	Brake Control Assembly
53	647-0049A	Hydrostatic Control Assembly
54	683-0267C	Pedal Assembly
55	710-0650	TT Screw 5/16-18 x 0.875
56	736-0187	Flat Washer,.64 x 1.24 x.06
57	710-1260A	LD Screw 5/16-18 x 0.75
58	710-1611B	TT Screw 5/16-18 x 0.75
59	711-04159B	Pin
60	712-04065	Flange Lock Nut, 3/8-16
61	712-3004A	Flange Lock Nut, 5/16-18
62	712-0240	Jam Nut 7/16-20
63	736-0119	Lock Washer 5/16
64	732-0335	Compression Spring
65	732-0955	Extension Spring
66	732-0963	Extension Spring
67	735-0662	Control Pedal
68	735-3049A	Brake Control Pedal
69	736-3008	Flat Washer
70	738-0155	Shoulder Screw
71	738-0380	Shoulder Screw
72	741-0225	Hex Flange Bearing
73	741-3065B	Hex Flange Bearing
74	747-04093A	Brake Lock Control Rod
75	747-04096	Cruise Control Rod
76	748-04039C	Cruise Latch
77	783-04612	Steering Support Bracket
78	783-0663E	Hydro Lockout Bracket
79	747-04521	Brake Pedal
80	710-0224	Screw, #10-16 x.500
81	17962	Switch Plate
82	725-04039	Interlock Switch
83	710-1007	Screw, 3/8-16 x 1.50
84	736-0242	Bell Washer,.340 x.872 x.060
85	710-0627	Screw, 5/16-24 x.750
86	634-0104	Wheel Complete, 20 x 8 x 8
	734-1730	Tire Only, 20 x 8 x 8
	634-0070	Rim Only
	734-0255	Tubeless Air Valve
87	714-0104	Pin, Cotter

Kohler Courage Single Cylinder Engine




Ref. No.	Part No.	Description
1	710-0227	AB Screw #8-18 x 0.5
2	710-0599	TT Screw 1/4-20 x 0.5
3	710-0654A	TT Screw 3/8-16 x 1.00
4	710-0726	AB Screw 5/16-12 x 0.5
5	710-1314A	Screw, 5/16-18 x .750
6	736-0277	Flat Washer, 1.03 x 1.620 x .095
7	725-0157	Cable Tie
8	726-0205	Hose Clamp .490 dia.
9	726-0272	Hose Clamp 9/16

Ref. No.	Part No.	Description
10	751-0564B	Muffler Deflector
11	751-0617B	Single Inlet
12	751-10047	Exhaust Pipe
13	751-10349	Fuel Line Hose
14	751-3141	Oil Drain Extension Hose
15	751-3140	Oil Drain Valve
16	783-0615D	Muffler Bracket
17	751-3142	Oil Drain Cap

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Kohler Twin Cylinder Engine




Ref. No.	Part No.	Description
1	710-0227	AB Screw #8-18 x 0.5
2	710-0599	TT Screw 1/4-20 x 0.5
3	710-0654A	TT Screw 3/8-16 x 1.00
4	710-0726	AB Screw 5/16-12 x 0.5
5	710-1314A	Screw, 5/16-18 x .750
6	712-3005	Flange Lock Nut, 3/8-16
7	725-0157	Cable Tie
8	726-0205	Hose Clamp
9	736-0300	Flat Washer, .406 x .875 x .059

Ref. No.	Part No.	Description
10	751-0564B	Muffler Deflector
11	751-0644B	LH Exhaust Pipe
12	751-0645A	RH Exhaust Pipe
13	751-0805A	Dual Inlet Muffler
14	751-10349	Fuel Line Hose
15	751-3141	Oil Drain Extension Hose
16	751-3140	Oil Drain Valve
17	783-0615D	Muffler Bracket
18	751-3142	Oil Drain Cap

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Model Series 610




Ref. No.	Part No.	Description
1	17962	Plate, Switch
2	647-04036A	Lever Assembly, Engagement
3	714-0145	Click Pin
4	710-0224	Screw, #10-16, 0.500
5	710-0276	Screw, Carriage, 5/16-18, 1.00
6	732-04248	Extension Spring, .38 OD x 3.9 Lg
7	710-04608	Screw, 7/16-20, 2.75 46" Deck
	710-04607	Screw, 7/16-20, 3.25 42" Deck
8	710-0726	Screw, 5/16-12, 0.750
9	710-0778	Screw, 1/4-20 x 1.50
10	711-1428	Pin, Belt Guard, 5/16 x 5.80
11	710-3011	Screw, 3/8-16 x 2.25
12	712-04063	Nut, Flange Lock, 5/16-18, GrF
13	712-04065	Nut, Flange Lock, 3/8-16, GrF
14	712-3004A	Nut, Flange Lock, 5/16-18, Gr5
15	714-0115	Pin, Cotter, 1/8 x 1.00
16	726-0201	Nut, Speed, .3125 ID
17	731-2111B	Knob, PTO
18	746-04092	Deck Engagement Cable
19	750-0566A	Spacer, .260 x .372 x 1.030 Lg.
20	783-04590B	Cable Bracket
21	736-0108	Washer, Flat, .510 x .750 x .033
22	736-0119	Washer, Lock, 5/16
23	736-0242	Washer, Bell, .340 x .872 x .060
24	736-0171	Washer, Lock, 7/16
25	736-0322	Washer, Flat, .450 x 1.250 x .164
26	741-0708	Bearing, Flange, Hex Split .500 ID
27	747-1286A	Keeper Rod, Belt
28	747-04470	Engagement Handle, Deck
29	748-0415B	Spacer, .385 ID x .635 OD x 1.54

Ref. No.	Part No.	Description
30	710-1260A	Screw, 5/16-18 x .750
31	756-04196	Pulley, Engine, 42" Deck
	756-04208	Pulley, Engine, 46" Deck
32	783-04467	Stop Bracket, Deck-Up
33	783-0744A	Stop Bracket, Engagement
34	683-04173B	Frame Assembly, Lower
35	710-0607	Screw, 5/16-18, 0.500
36	710-0642	Screw, 1/4-20, 0.750
37	710-3005	Screw, 3/8-16, 1.25, Gr5
38	712-04064	Nut, Flange Lock, 1/4-20, GrF
39	732-04035	Spring, Compr., 1.28 OD x 3.125
40	736-0222	Washer, Lock, 1/4, External
41	783-04612	Support Bracket, Steering
42	738-04058	Spacer, Shoulder, .38 x 1.0 x .70
43	747-04121A	Hold Rod, Battery
44	783-0349	Battery Tray
45	783-04329A	Seat Bracket, Frame
46	783-04809D	Frame, Upper
47	710-0599	Screw, 1/4-20, 0.50
48	725-04439	Solenoid, 12V, 100 Amp
49	725-04039	Switch, Interlock
50	738-1132	Screw, Shoulder, .250 x .150
51	725-1737A	Battery, 190 CCA
	725-1750A	Battery, 235 CCA
52	710-04666	Hex Head Flange Screw
53	712-0271	Nut, Sems, 1/4-20
54	712-3087	Nut, Wing, 1/4-20
55	710-0604A	Screw, 5/16-18 x 0.625
56	736-0173	Washer, Flat, .28 x .74 x .063

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.


42" Manual PTO Deck



Ref. No.	Part No.	Description
1	618-04456	Spindle Assembly Pulley 6.3 Dia
2	683-0254B	Deck Hanger Bracket Assy. LH
3	683-04138B	Brake Assembly, 42" Deck
4	683-04167	Brake Assembly, 42" Deck
5	683-04261	Deck Assembly 42" W/Whl Brkt.
6	710-0216	Screw, 3/8-16 x .75 GR5
7	710-0347	Screw, 3/8-16 x 1.75 GR5
8	710-0510	Screw, 7/16-20 x 3.00 GR5
9	710-0528	Screw, 5/16-18 x 1.25 GR5
10	710-0604A	Screw, 5/16-18 x 0.625
11	710-0623	Screw, 3/8-16 x 0.750
12	710-0653	Screw, 1/4-20 x 0.375
13	710-0726	Screw, 5/16-12 x 0.750
14	710-0778	Screw, 1/4-20 x 1.500
15	710-1260A	Screw, 5/16-18 x 0.750
16	710-3005	Screw, 3/8-16 x 1.25
17	710-3015	Screw, 1/4-20 x .75
18	710-3144	Screw, 3/8-16 x 2.00
19	712-0206	Hex Nut, 1/2-13
20	712-04063	Flange Lock Nut, 5/16-18
21	712-04064	Flange Lock Nut, 1/4-20
22	712-04065	Flange Lock Nut, 3/8-16
23	712-0417A	Flange Nut, 5/8-18
24	712-0459	Flange Lock Nut, 7/16-20
25	712-0641	Hex Nut, M16-1.5
26	712-3006	Hex Nut, 1/4-20
27	712-3083	Hex Lock Nut, 1/2-13
28	714-0104	Cotter Pin, .072 Dia. x 1.13 Lg.
29	714-0470	Cotter Pin, 1/8 x 1.25
30	717-04074	Deck Gear Adjustment
31	719-04233	Idler Bracket, Cast 42" Deck
32	721-04041	Water Nozzle Adapter
33	726-0233	Push Nut, .25 ID x .50 OD
34	732-0306A	Compression Spring .531 x 1.75
35	732-04287	Extension Spring, .500 x 6.375
36	732-0459C	Extension Spring, .94 x 6.74

Ref. No.	Part No.	Description
37	732-0470A	Extension Spring, .53 x 4.75
38	734-0973	Deck Wheel, 5.0 x 1.38
39	735-0271A	Bumper, .62 Dia. x .3
40	736-0119	Lock Washer, 5/16
41	736-0173	Flat Washer, .28 x .74 x .063
42	736-0225	Lock Washer, 5/8
43	736-0270	Bell Washer, .265 x.75 x .062
44	736-0300	Flat Washer, .406 x .875 x .059
45	736-0322	Flat Washer, .450 x 1.250 x .164
46	737-04003C	Deck Water Nozzle
47	738-0373	Shoulder Bolt, .496 x 1.525
48	738-04162A	Shoulder Spacer, .8840 x .190
49	738-04166	Shoulder Spacer, .5000 X .1475
50	738-04272	Shoulder Screw, .374 x 1.16
51	742-0616A	3 in 1 Star Blade 21.23"LG
52	747-04269A	Adjustable Front Deck Rod,
53	747-04307	Belt-Keeper Rod, 42"
54	747-04501	Brake Control Ride, 42"
55	747-04530	Belt Keeper Rod, 42" Idler
56	747-1116	Deck Release Handle Rod
57	748-04069	Deck Lift Pivot Cup
58	750-04637A	Spacer, .455 X .697 X 1.585
59	750-0566A	Spacer, .260 x .372 x 1.030
60	754-04045	V-Belt
61	756-04129	Idler Pulley, 4.25"Dia.
62	783-04327B	Belt Covers, 6.00 Dia.
63	783-04740	Cable Deck Engage Bracket
64	783-05490	Support Bracket
65	736-0187	Flat Washer, .64 x 1.24 x .06
66	738-04146	Bolt Plug, M16 x 1.5
67	710-0134	Carriage Screw, 1/4-20 x .62
68	710-0599	Screw, 1/4-20, 0.500
69	712-3087	Wing Nut, 1/4-20
70	731-2363	Mulch Plug
71	783-1146A	Deck Skirt, 42" Deck
72	731-1032B	Discharge Chute Assembly

46" Manual PTO Deck



Ref. No.	Part No.	Description
1	17116	Brake Assembly, Deck
2	17258E	RH Belt Cover, Deck 46"
3	618-0240A	Spindle Assembly, 5.00 Dia.
4	618-04134B	Spindle Ass'y, Double Pulley
5	683-0254B	Hanger Bracket Assembly
6	683-04250A	Idler Bracket Assembly - LH
7	683-04251A	Idler Bracket Assembly - RH
8	683-04254	Deck Weldment
9	710-0514	Screw, 3/8-16, 1.00, Gr5
10	710-0528	Screw, 5/16-18, 1.25, Gr5
11	710-0599	Screw, 1/4-20, 0.500
12	710-0778	Screw, 1/4-20, 1.500
13	710-0805	Screw, 5/16-18, 1.50, Gr5
14	710-1026	Screw, 1/4-20 x 1.75
15	710-1260A	Screw, Ld, 5/16-18, 0.750
16	710-1315	Screw, 3/8-16 x 1.250
17	710-3015	Screw, 1/4-20, .75, Gr5
18	711-04636	Pin, 1/4-20, 3/8 x 2.0
19	711-04669	Clevis Pin, 3/8 x 2.75
20	711-0993	Belt Guard Pin 1/4 Dia x 1.43
21	712-0206	Nut, Hex, 1/2-13, Gr5
22	712-04063	Nut, Flange Lock, 5/16-18, GrF
23	712-04064	Nut, Flange Lock, 1/4-20, GrF
24	712-04065	Nut, Flange Lock, 3/8-16, GrF
25	712-0417A	Nut, Flange, 5/8-18
26	712-0641	Nut, Hex, M16-1.5
27	712-3006	Nut, Hex, 1/4-20, Gr5
28	712-3083	Nut, Hex Lock, 1/2-13
29	714-04043	Bow Tie Cotter Pin 1/8 x 1.25
30	717-04074	Adjustment Gear, Deck
31	737-04003C	Water Nozzle Adapter
32	726-0233	Nut, Push, .25 ID x .50 OD
33	731-1032B	Chute Assembly
34	732-0429A	Spring, Extension, .50 x 3.97
35	732-04400	Spring, Extension, .75 x 6.835
36	732-0594A	Spring, Extension, .91 x 7.33
37	732-0814	Spring, Extension, .56 x 5.52

Ref. No.	Part No.	Description
38	734-0973	Wheel, Deck 5.0 x 1.38
39	736-0119	Washer, Lock, 5/16
40	736-0211	Washer, Flat, .285 x 1.25 x .06
41	736-0225	Washer, Lock, 5/8
42	736-0258	Washer, Flat, .385 x 1.0 x .135
43	736-0270	Washer, Bell, .265 x .75 x .062
44	736-0418A	Washer, Flat, .34 x 2.25 x .10
45	738-04146	Plug
46	738-0347	Spacer, Shoulder, .625 ID x .169
47	738-0373	Spacer, Shoulder, .498 x 1.53
48	738-04091	Shld, Screw, .43 x .29, 5/16-18
49	738-04216A	Shld. Screw, .625 x 2.515 x .875
50	742-0611A	Blade, 16.28", Star 3-in-One
51	742-0612A	Blade, 14.88", Star 3-in-One
52	747-1130B	Rod, Deck Adjustment
53	748-0234	Shoulder Spacer
54	736-0187	Washer, Flat, .64 x 1.24 x .06
55	750-04456	Spacer, .260 x .372 x 1.420 Lg.
56	750-0566A	Spacer, .260 x .372 x 1.030
57	750-1320	Spacer, .375 x .63 x .595
58	754-0349	Belt, V-Type, Poly, A x 79.10 Lg.
59	754-04122	Belt, V-Type, A x 90.24
60	756-04129	Pulley, Idler, 4.25" Dia.
61	783-0141	Deck Skirt, Center
62	783-0142	Deck Skirt, RH
63	783-04641A	Bracket, Idler
64	783-05321	Brake Bracket, 46"
65	783-1348D	Belt Cover, LH
66	731-05264	Mulch Plug
67	712-3087	Wing Nut
68	710-0134	Carriage Screw, 1/4-20 x .62
69	721-04041	Deck Water Nozzle
70	747-04307	Belt-Keeper Rod
71	736-0300	Washer, Flat, .406 x .875 x .059
72	710-1007	Sems Screw, 3/8-16 x 1.500
73	747-04530	Idler Belt-Keeper Rod

NOTE: Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.