


PARTS LIST

Craftsman Revolution Model 247.28933




PARTS LIST

Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	683-04269-0637	Frame Assembly
2.	710-04377	Screw, Hex Cap Lock, 7/16-20 x 2.75
3.	710-04484	Screw, Hex Wash., 5/16-18 x .75
4.	710-04666	Screw, Hex Flange Hd. , 1/4-20 x .75
5.	710-0599	Screw, Hex Wash., 1/4-20 x .5
6.	710-0642	Screw, Hex Wash., 1/4-20 x .75
7.	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
8.	712-0271	Nut, Hex Sems, 1/4-20
9.	712-04064	Nut, Hex Flange Insert Lock, 1/4-20
10.	712-04065	Nut, Hex Flange Insert Lock, 3/8-16
11.	712-3087	Nut, Wing, 1/4-20
12.	917-04526	Clutch, Electric PTO
13.	725-0157	Cable Tie
14.	725-04439	Solenoid, Start
15.	925-1707D	Battery
16.	731-05659	Bushing, Steering Shaft
17.	936-0171	Washer, Lock, 7/16
18.	738-04058	Spacer, Shoulder, .38 x 1.0 x .7
19.	738-1132	Screw, Shoulder, .25 x .15:1/4-20
20.	747-04215-0637	Strap, Battery
21.	750-04763	Spacer, 1.37 x 1.00 x .25
22.	756-04354	Pulley, Engine
23.	747-05056	Rod, Belt Keeper
24.	783-04806-0637	Bracket, Pivot Bar
25.	783-04844-0637	Bracket, Pivot Support RH
26.	783-04845-0637	Bracket, Pivot Support LH
27.	783-04868-0637	Bracket, Steering Support
28.	783-04910A-0637	Bracket, Support Fender
29.	783-05469-0637	Bracket, Battery Support
30.	783-05617B-0637	Bracket, Running Board Support - LH
	783-06193-0637	Bracket, Running Board Support - RH
31.	783-05760-0637	Bracket, Pivot Bar Support
32.	783-05850-0637	Plate, Seat Frame
33.	710-04484	Screw, Hex Wash., 5/16-18 x .75

PARTS LIST

Craftsman Revolution Model 247.28933



PARTS LIST


Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	710-0192	Screw, Truss Hd. Mach., 10-24 x .375
2.	710-0599	Screw, Hex Wash, 1/4-20 x .5
3.	710-0604A	Screw, Hex Wash, 5/16-18 x .625
4.	710-04484	Screw, Hex Wash, 5/16-18 x .75
5.	710-0642	Screw, Hex Wash, 1/4-20 x .75
6.	710-0895	Screw, Hex Wash, 1/4-15 x .75
7.	710-3217	Screw, Truss Hd. Mach., #8-32 x .375
8.	712-0142	Nut, Hex, 8-32
9.	725-0157	Tie, Cable
10.	925-04022B	Meter, Indicator/Service Monitor
11.	925-04174	Switch, PTO
12.	925-04227B	Switch, Ignition/Module
13.	925-1745A	Key, Ignition, w/ Plastic Cover
	925-1744A	Key, Ignition, w/o Plastic Cover
14.	720-3025	Plug
15.	925-0963	Bulb, 12V Light
16.	925-1649	Receptacle, Light
17.	726-3046	Clip, Ratchet
18.	731-04213	Lever, Dash Brake
19.	731-05406	Panel, Dash
20.	731-06830	Hood
21.	731-05935	Plenum, Hood
22.	731-05525	Lens, Head Light LH
23.	731-05526	Lens, Head Light RH
24.	731-1857	Knob, Throttle Control

Ref. No.	Part No.	Description
25.	935-0149	Bushing, Fuel Tank
26.	735-0271A	Bumper
27.	735-04076	Net, Storage
28.	936-0463	Washer, Flat, .25 x .63 x .0515
29.	738-04091A	Screw, Shoulder, .43 x .29:TT5/16-18
30.	746-04132	Cable, Choke Control
31.	746-1100	Cable, Throttle Control
32.	747-1155	Rod, Brake Lock Pivot
33.	751-10442	Fitting, Fuel Pick Up
34.	751-10692	Tank, Fuel
35.	751-10703	Cap, Fuel Tank
36.	783-04285F-0637	Support, Dash, R.H.
37.	783-04323F-0637	Support, Dash, L.H.
38.	683-04536	Bracket, Hood Pivot
39.	783-04840-0637	Bracket, Hood Pivot RH
40.	783-04841-0637	Bracket, Hood Pivot LH
41.	783-05162-0637	Bracket, Hood Support
42.	777X42426	Label, Reflector
43.	777X42427	Label, Reflector
44.	783-05140-0637	Brkt., Strg. Support, RH
45.	783-04798-0637	Brkt., Strg. Support, LH
46.	783-04799-0637	Brkt., Support, Upper Strg.
47.	725-2003	12V Power Receptacle
—	925-04375A	Harness, Main Wire
—	937-04050	Grease Gun Kit

PARTS LIST

Craftsman Revolution Model 247.28933



PARTS LIST


Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	647-04095A-0637	Shaft, Lift
2.	710-04187	Screw, Hex Wash Hd. H/L, 1/4-15 x .5
3.	710-04484	Screw, Hd. Tapp, 5/16-18 x .75
4.	710-0451	Screw, Carriage, 5/16-18 x .75
5.	710-0599	Screw, Hd. Tapp, 1/4-20 x .5
6.	710-1260A	Screw, Hd. Tapp, 5/16-18 x .75
7.	710-0895	Screw, Hd. Tapp, 1/4-15 x .75
8.	712-04063	Nut, Hex Flange Insert Lock, 5/16-18
9.	712-04065	Nut, Hex Flange Insert Lock, 3/8-16
10.	914-0104	Pin, Internal Cotter
11.	914-0111	Pin, Cotter, 3/32 x 1.0
12.	716-0106A	E-ring, .625 Shaft
13.	720-0311	Grip, Handle
14.	726-0135	Nut, Speed, .3125 Dia.
15.	726-0221	Nut, Speed, .5
16.	726-3046	Clip, Ratchet
17.	731-06836	Cover, Rear Fender RH
18.	731-06835	Cover, Rear Fender LH
19.	731-06208	Spacer, Seat Adjust
20.	732-04459	Spring, Lift Handle Torsion
21.	732-04491	Spring, Seat Adjust
22.	732-04508	Spring, Compress., 1.71 x 3.25 x .23
23.	732-0826A	Spring, Extension, .865 x 4.68
24.	735-04078A	Pad, Foot RH

Ref. No.	Part No.	Description
25.	735-04109	Pad, Foot LH
26.	936-0192	Washer, Flat, .535 x .93 x .09
27.	736-3078	Washer, Flat, .344 x 1.0 x .063 HT
28.	738-0138A	Bolt, Shoulder, .496 x 2.5:3/8-16
29.	938-0373	Bolt, Shoulder, .496 x 1.525:3/8-16
30.	738-04130	Bolt, Shoulder, .625 x .175:3/8-16
31.	941-0225	Bearing, Hex Flange,
32.	946-04546	Cable, Lift, 16.64 Lg
33.	946-04436	Cable, Lift, 16.64 Lg
34.	747-04701	Handle, Lift
35.	747-04821	Rod, Seat, 5/16 x 11.62
36.	750-04945	Spacer, .51 x .75 x 1.0
37.	756-04331	Pulley, Roller
38.	757-04104	Seat, High Back
39.	783-04977A-0637	Plate, Deck Lift Index
40.	783-04494B-0637	Arm, Deck Lift RH
41.	783-04711B-0637	Arm, Deck Lift LH
42.	783-05816-0637	Bracket, Seat Pivot
43.	783-05817-0637	Plate, Seat Mounting
44.	783-05865A-0637	Fender, Rear
45.	925-04040	Switch, Seat
46.	725-04658	Harness, Seat Switch Jumper
47.	757-04040	Arm Rest, Seat

PARTS LIST

Craftsman Revolution Model 247.28933



PARTS LIST


Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	918-04414	Steering Assembly, Synchro
2.	631-04331	Wheel Assembly, Steering
3.	634-04415	Wheel Assembly, 15 x 5 x 6
	734-04347-0901	Tire, 15 x 5 x 6
	634-04104	Rim Assembly
	737-0224	Grease Fitting
	941-04137	Bearing
	934-0255	Valve, Tubeless Air
4.	683-04439	Axle Assembly, RH
5.	683-04440	Axle Assembly, LH
6.	647-04080A-0637	Rod, Fender Support
7.	683-04285-0637	Link, Steering, IVT
8.	710-04006	Screw, Hex Wash, 5/16-18 x 2.0
9.	710-04187	Screw, Hex Wash, Hi/Lo, 1/4-15 x .5
10.	710-04389	Screw, Hex Wash, 5/16-18 x 2.25
11.	710-04484	Screw, Hex Wash, 5/16-18 x .75
12.	710-04692	Screw, Hex Cap, 3/8-16 x 7.25 Gr5
13.	710-0513	Screw, Hex Cap Lock, 1/4-28 x .625
14.	710-0520	Screw, Hex Cap, 3/8-16 x 1.5 Gr5
15.	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
16.	710-0106	Screw, Hex Cap, 1/4-20 x 1.25
17.	710-0599	Screw, Hex Wash, 1/4-20 x .5
18.	710-0642	Screw, Hex Wash, 1/4-20 x .75
19.	710-0650	Screw, Hex Wash, 5/16-18 x .875
20.	710-3015	Screw, Hex Cap, 1/4-20 x .75 Gr5
21.	710-3119	Screw, Hex Cap Lock, 3/8-16 x .75
22.	710-3144	Screw, Hex Cap, 3/8-16 x 2.0 Gr5
23.	710-3296	Screw, Hex Cap Lock, 1/4-20 x .75
24.	711-04472	Link, Drag
25.	711-04562	Shaft, Steering Pivot Gear
26.	711-04722	Pin, Clevis, .375 x .969 HT
27.	712-0312A	Nut, Jam, 3/8-24 LH Thrd
28.	741-04280	Brg., Ball
29.	712-0375	Nut, Hex Lock, 3/8-16
30.	712-04063	Nut, Hex Insert Flange Lock, 5/16-18
31.	712-04064	Nut, Hex Insert Flange Lock, 1/4-20
32.	712-04065	Nut, Hex Insert Flange Lock, 3/16-16
33.	912-3001	Nut, Hex Jam, 3/8-24 Gr2
34.	913-04037	Link, Connecting
35.	914-0104	Pin, Internal Cotter

Ref. No.	Part No.	Description
36.	714-04039	Pin, Cotter, 5/32 x 1.25
37.	717-04274A	Gear, Spur, 12T
38.	717-04275A	Gear, Spur, RH 13T
39.	717-04282A	Gear, Spur, LH 13T
40.	719-04170A	Axle, Pivot Bar
41.	719-04287-0637	Arm, Steering, LH
42.	719-04288-0637	Arm, Steering, RH
43.	723-04035	End, Ball Joint Rod
44.	723-04036	End, Ball Joint Rod, LH Thrd.
45.	738-1011A	Bolt, Shoulder, .5 x 2.23:3/8-16
46.	731-05476	Cover, Steering Gear, RH
47.	731-05618	Cover, Steering Gear, LH
48.	731-06825	Cap, Steering Wheel
49.	936-0185	Washer, Flat, .375 x .738.063
50.	736-0270	Washer, Bell, .265 x .75 x .062
51.	936-0300	Washer, Flat, .406 x .875 x .059
52.	736-0315	Washer, Flat, .76 x 1.5 x .12
53.	936-0452	Washer, Bell, .396 x 1.14 x .095
54.	736-0866	Washer, Flat, .755 x 1.92 x .060
55.	936-3004	Washer, Flat, .406 x .875 x .105
56.	736-3052	Washer, Flat, .406 x 1.0 x .105
57.	931-3020	Hub Cap
58.	937-3000	Fitting, Grease
59.	738-04189	Shaft, Steering, .625 x 17.281
60.	738-04240	Nut, Shoulder, .375 x .5
61.	747-04496	Rod, 3/8-24 x 14.4 Lg
62.	748-04139	Block, Steering Shaft
63.	750-04676	Spacer, .385 x .63 x .75
64.	750-04776	Spacer, .380 x .625 x .265
65.	736-04299	Washer, Flat, .281 x .50 x .04
66.	750-04855	Spacer, .385 x .75 x 3.47
67.	783-04798-0637	Bracket, Steering Support, LH
68.	783-04799-0637	Bracket, Steering Support, Upper
69.	783-05140-0637	Bracket, Steering Support, RH
70.	783-05184-0637	Plate, Base Cover, RH
71.	783-05185-0637	Plate, Base Cover, LH
72.	783-05956	Link, Cont., IVT
73.	783-05957	Bracket, IVT/Steering Adjustment
74.	783-05706	Bracket, Support Arm

PARTS LIST

Craftsman Revolution Model 247.28933



PARTS LIST

Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	783-04904-0637	Plate, Transmission
2.	918-04228	Hub, Wheel
3.	647-04174	Assembly, Control, Pedal, IVT
4.	647-04103B	Assembly, Control, Brake, IVT
5.	683-04473-0637	Assembly, Hub, IVT Speed
6.	783-06385	Brkt., Brake, Neut., Brake Rod
7.	707-05194	Lever, Brake, Release, RH
8.	710-04484	Screw, Hex Wash, 5/16-12 x .75
9.	707-05196	Lever, Brake, Release, LH
10.	710-0627	Hhcs, 5/16-24 x .750
11.	710-0599	Screw, Hex Wash., 1/4-20 x .5
12.	710-0919	Screw, B, #10-16 x .440
13.	710-0641	Screw, Hex Cap, 1/4-20 x 2.25 Gr5
14.	710-1008	Screw, tt, 3/8-16 x 1.875
15.	710-1189	Screw, C, #12-24 x .625
16.	710-1208	Screw, tt, 5/16-18 x 3.50
17.	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
18.	710-0703	Screw, Crg, 1/4-20 x .75
19.	710-3144	Screw, Hex Cap, 3/8-16 x 2.0 Gr5
20.	710-1325	Screw, tt, 1/4-20 x 1.625
21.	911-0832	Ferrule, 3/8-24 x .375 Dia.
22.	710-3195	Hhcs, 5/16-18 x 4.50
23.	912-0298	Nut, Jam, 1/4-20
24.	712-3004A	Nut, Hex Flange Lock, 5/16-18 Gr5
25.	712-0365	Nut, Hex Lock, M8 x 1.25
26.	712-3050	Nut, Lug, 7/16-14
27.	712-04063	Nut, Hex Flange Insert Lock, 5/16-18
28.	712-04065	Nut, Hex Flange Insert Lock, 3/8-16
29.	914-0104	Pin, Internal Cotter
30.	914-0111	Pin, Cotter, 3/32 x 1/0
31.	718-04597	Plate, Brake, Lever
32.	915-0143	Pin, Spirol, .25 x 1.25
33.	727-0626A	Cyl, Damper
34.	731-05846	Fan, Hydro
35.	747-04935	Rod, Brake, IVT
36.	732-0335	Spring, Compression, .405 x 1.17

Ref. No.	Part No.	Description
37.	932-04262	Spring, Extension, .429 OD x 2.515
38.	732-0814	Spring, Extension, .56 x 5.52
39.	735-0239	Pad, Foot, 4.0 in. Lg
40.	735-04117	Pad, Reverse Pedal
41.	735-04175	Pad, Forward Pedal
42.	736-0242	Washer, Bell, .340 x .872 x .060
43.	938-0974	Scr, Shldr, .375 x .380 x 1/4-20
44.	736-3010	Washer, Flat, .407 x .812 x .135 HT
45.	750-05063	Spcr, Brake, IVT
46.	932-0429A	Spring, Ext, .50 Dia. x 3.97 Lg.
47.	712-04064	Nut, Flglk, 1/4-20
48.	736-3052	Washer, Flat, .406 x 1.00 x .105
49.	738-04356	Screw, Shoulder, .31 x .75 x 1/4-20
50.	938-0155	Bolt, Shoulder, .435 x .160 : 5/16-18
51.	938-0347	Spacer, Shoulder, .625 ID x .169
52.	738-04240	Nut, Shoulder, .375 Dia x .5
53.	941-0225	Bearing, Hex Flange
54.	741-3065B	Bearing, Hex Flange, .625 ID Split
55.	747-04562A	Rod, Park Brake
56.	747-04598A	Rod, Drive Engage
57.	747-05088	Rod, Dump, IVT
58.	747-04951	Rod, Brake RH
59.	747-04932	Rod, Brake LH
60.	750-04686A	Spacer, .325 x .500 x 2.480
61.	750-04456	Spacer, .26 x .372 x 1.42
62.	750-04776	Spacer, .38 x .625 x .265
63.	750-05026	Spacer, .375 x .5 x 2.0
64.	954-04139	V-Belt, 72.2
65.	756-04224	Pulley, Flat Idler, 2.75
66.	783-06140-0637	Brkt, Mt, Cyl
67.	756-04325	Pulley, V Type Idler, 3.06
68.	783-04570A-0637	Arm, Idler
69.	783-06373	Pedal, Fwd, IVT
70.	783-04981	Bracket, Park Brake
71.	783-05976-0637	Bracket, Support, IVT Pedal
72.	783-05290-0637	Belt Keeper, IVT


PARTS LIST

Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
73.	911-0677	Frl, 5/16-18 x .312 Dia.
74.	783-06377	Bracket, Pivot, IVT Rev
75.	783-06213	Pedal, Rev, IVT
76.	783-06224-0637	Bracket, Brace, Neutral Brake Rod
77.	618-04429	Transmission, IVT
78.	725-04363	Switch, Interlock (Brake)
79.	725-04374	Harness, Reverse Jumper
80.	725-1644	Switch, Reverse
81.	926-0320	Plate, Insulator Nut
82.	738-04237A	Screw, Shoulder, #10-32 : .5
83.	634-04239	Wheel Assembly, 20 x 8 x 8
	734-1730	Tire, 20 x 8 x 8
	934-0255	Valve, Tubeless Air
	934-0246A	Rim Assembly, Rear
84.	647-04168	Assembly, Pedal, Rev, IVT
85.	710-0227	Screw, Hd. Tapp., #8-18 x .5
86.	710-0642	Scr., TT, 1/4-20 x .750
87.	714-04023	Pin, Cotter
88.	726-0214	Cap, Push
89.	736-0116	Washer, Flat, .635 x .93 x .06

PARTS LIST

Craftsman Revolution Model 247.28933




Ref. No.	Part No.	Description
1.	683-04256-0637	Shield, Muffler
2.	710-0227	Screw, Hex Wash Hd. Tapp, #8-18 x .5
3.	710-04683	Screw, Hex Sems Tapp, 3/8-16 x 1.0
4.	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
5.	710-0642	Screw, Hd. Tapp, 1/4-20 x .75
6.	710-3008	Screw, Hex Cap, 5/16-18 x .75 Gr5
7.	912-3005	Nut, Hex Flange Lock, 3/8-16 Gr5
8.	725-0157	Tie, Cable
9.	726-0205	Clamp, Hose
10.	728-04000	Rivet, Pop, .188 x .3
11.	936-0300	Washer, Flat, .406 x .875 x .059
12.	751-0564B	Deflector, Muffler

Ref. No.	Part No.	Description
13.	751-10004	Pipe Exhaust, RH
14.	751-10161	Muffler, Dual Inlet
15.	751-10349-54	Hose, Fuel ; Low Permeation, 51 inches
16.	751-10353	Deflector, Muffler
17.	951-10517A	Valve, Oil Drain
18.	751-3141-14	Hose, Oil Drain Extension
19.	783-04870-0637	Bracket, Muffler LH
20.	783-04872-0637	Bracket, Muffler RH
21.	721-0460	Gasket, Exhaust
22.	926-0154	Tie, Push Mount
23.	751-10005	Pipe, Exhaust, LH
24.	783-04783A	Shld., Heat, Twin

PARTS LIST

Craftsman Revolution Model 247.28933



PARTS LIST

Craftsman Revolution Model 247.28933

Ref. No.	Part No.	Description
1.	918-04512A	Spindle Assembly - Drive
2.	918-04516	Spindle Assembly - Driven
3.	638-04012A	Bolt Assembly, Shoulder
4.	983-04379A-0721	Deck Assembly
5.	683-04425-0721	Bracket, Idler
6.	710-0520	Screw, Hex Cap, 3/16-18 x 1.5 Gr5
7.	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
8.	710-0599	Screw, Hex Wash., 1/4-20 x .5
9.	710-04484	Screw, Hex Wash., 5/16-18 x .75
10.	710-1325	Screw, Hex Wash., 1/4-20 x 1.625
11.	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
12.	710-3144	Screw, Hex Cap, 3/8-16 x 2.0 Gr5
13.	710-3178	Screw, Carriage, 3/8-16 x .75
14.	912-0206	Nut, Hex, 1/2-13 Gr5
15.	712-0229	Nut, Push, 3/8
16.	712-0290	Nut, Hex Lock, 7/16-14
17.	712-04065	Nut, Hex Flange Insert Lock, 3/8-16
18.	712-0417A	Nut, Hex Flange, 5/8-18
19.	912-0641	Nut, Hex, M16-1.5
20.	712-3083	Nut, Hex Insert Lock, 1/2013
21.	914-0470	Pin, Cotter, 1/8 x 1.25
22.	917-04074	Gear, Deck Adjust
23.	731-06291A	Cover, Belt
24.	932-0306A	Spring, Compression, .531 x 1.75
25.	732-04469	Spring, Torsion, 1.10 x 1.3
26.	732-0826A	Spring, Extension, .865 x 4.68
27.	734-04155	Wheel, Deck Ball, 5.0
28.	936-0119	Washer, Lock, 5/16
29.	936-0176	Washer, Flat, .265 x .938 x .12
30.	736-0225	Washer, Internal Tooth Lock, 5/8
31.	736-0258	Washer, Flat, .385 x 1.0 x .135
32.	936-0300	Washer, Flat, .406 x .875 x .059
33.	736-0322	Washer, Flat, .45 x 1.38 x .134
34.	936-3039	Washer, Flat, .406 x 2.5 x .164
35.	737-04003D	Nozzle, Deck Wash

Ref. No.	Part No.	Description
36.	938-0785	Spacer, Shoulder, 1.38 x .445 x .36
37.	738-04162A	Spacer, Shoulder, .884 x .190
38.	738-04316	Bolt, Shoulder, .435 x 1.76:5/16 -24
39.	938-3056	Bolt, Shoulder, .496 x 2.5:3/8-16
40.	942-04217	Blade, Timing 2 in 1, 22.0
41.	747-04530	Rod, Belt Keeper
42.	747-04863	Rod, Deck Front Hanger
43.	747-1116	Rod, Deck Release
44.	750-0566A	Spacer, .26 x .372 x 1.03
45.	954-04167	Belt, Timing, .189T
46.	954-04185	V-Belt, Type A x 89.24
47.	756-04129	Pulley, Idler, 4.25 Dia
48.	783-05627-0637	Bracket, Deck Hanger/Adjust LH
49.	783-05802-0637	Bracket, Idler
50.	911-0332	Pin, Clevis, .5 x .78
51.	914-04023	Pin, Internal Cotter
52.	783-0720C-0637	Bracket, Front Deck Rod
53.	631-04254	Deflector Assembly, Chute
54.	711-04847A	Pin, Hinge
55.	732-04372	Spring, Torsion, .44 x 2.0
56.	783-05823	Bracket, Chute Mounting
57.	619-04199	Housing, Spindle
58.	710-04065	Screw, Tri-Plask, 1/4-10 x .625
59.	913-04040A	Pulley, Timing, 56T
60.	936-0287	Washer, Flat, .793 x 1.24 x .06 HT
61.	937-3000	Fitting, Lube
62.	941-0919	Bearing, Ball
63.	750-04936	Spacer, .792 x 1.06 x 1.86
64.	787-01520	Plate, Timing Pulley
65.	938-04292	Shaft, Spindle, 5.46 Long
66.	938-04291	Shaft, Spindle, 4.44 Long
67.	750-04724	Spacer, .735 x 1.375 x 1.066
68.	756-04372	Pulley, Deck, Timing, 6.67 Dia
69.	736-0315	Washer, Flat, .76 x 1.5 x .12
70.	756-04280	Pulley, Idler, 3.50 Dia.

PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933











48 SHORT BLOCK

10 






1058 OPERATOR'S MANUAL

1329 REPLACEMENT ENGINE

1330 REPAIR MANUAL




358 ENGINE GASKET SET







PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933



PARTS LIST











Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933



PARTS LIST


Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933

1036 EMISSIONS LABEL



PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933



PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933

Ref. No.	Part No.	Description
1	795118	Cylinder Assembly
2	499585	Kit-Bushing/Seal (Magneto Side)
3•	391086s	Seal-Oil (Magneto Side)
4	796230	Sump-Engine
5	796231	Head-Cylinder (Cylinder #1)
5A	796232	Head-Cylinder (Cylinder #2)
7•+	693997	Gasket-Cylinder Head
8	792185	Breather Assembly
9	690937	Gasket-Breather
10	697551	Screw (Breather Assembly)
11	792184	Tube-Breather
12•	697227	Gasket-Crankcase
13	793988	Screw (Cylinder Head)
15	690946	Plug-Oil Drain
16	796540	Crankshaft
20•	795387	Seal-Oil (PTO Side)
22	694966	Screw (Crankcase Cover/Sump)
23	691053	Flywheel
24	222698s	Key-Flywheel
25	793647	Piston Assembly (Standard)
	793648	Piston Assembly (.020" Oversize)
26	791787	Ring Set (Standard)
	791792	Ring Set (.020" Oversize)
27	690975	Lock-Piston Pin
28	696581	Pin-Piston
29	796209	Rod-Connecting
32	690976	Screw (Connecting Rod)
33	697576	Valve-Exhaust
34	792200	Valve-Intake
35	694865	Spring-Valve (Intake)
36	694865	Spring-Valve (Exhaust)
40	690964	Retainer-Valve
42	499586	Keeper-Valve
45	690977	Tappet-Valve
46	792555	Camshaft
48	698172	Short Block
50	695241	Manifold-Intake
51 Ø•+	795123	Gasket-Intake

Ref. No.	Part No.	Description
51A Ø•+	690950	Gasket-Intake
53	690951	Stud (Carburetor)
54	699816	Screw (Intake Manifold)
73	494439	Screen-Rotating
74	698425	Screw (Rotating Screen)
75	691056	Washer (Flywheel)
95	690718	Screw (Throttle Valve)
98 Ø	699721	Kit-Idle Speed
104 Ø	694918	Pin-Float Hinge
105 Ø	698537	Valve-Float Needle
108	699723	Valve-Choke
117	792296	Jet-Main (Standard) (Left Jet)
117A	842627	Jet-Main (Standard) (Right Jet)
118	699457	Jet-Main (High Altitude) (Left Jet)
118A	699733	Jet-Main (High Altitude) (Right Jet)
121	792455	Kit-Carburetor Overhaul
125	792295	Carburetor
130	690993	Valve-Throttle
131	499805	Kit-Throttle Shaft
133	699724	Float-Carburetor
135	699729	Tube-Fuel Transfer
137 Ø	690994	Gasket-Float Bowl
141	699722	Kit-Choke Shaft
142	699726	Nozzle-Carburetor
146	690979	Key-Timing
150	690995	Gasket-Nozzle
163	691001	Gasket-Air Cleaner
165	693148	Nut (Ring Gear)
187	791766	Line-Fuel (Cut To Required Length)
188	697551	Screw (Control Bracket)
192	690083	Adjuster-Rocker Arm
197	697820	Screw (Back Plate)
209	796224	Spring-Governor (Yellow/Black)
211	691019	Spring-Governed Idle (Orange)
212	695238	Link-Throttle
213	691021	Bracket-Choke Control
216	691022	Link-Choke
219	793338	Gear-Governor

- Included in Engine Gasket Set, Key Number 358.
- Ø Included in Carburetor Overhaul Kit, Key Number 121.
- + Included in Valve Gasket Set, Key Number 1095.

PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933

Ref. No.	Part No.	Description
220	690412	Washer (Governor Gear)
221	841026	Cup-Governor
222	796630	Bracket-Control
227	796223	Lever-Governor Control
231	690718	Screw (Choke Valve)
239	792028	Switch-Oil Pressure
240	695666	Filter-Fuel
250	690957	Retainer-Breather
252	794389	Collector-Oil
265	691024	Clamp-Casing
267	695314	Screw (Casing Clamp)
276	695410	Washer-Sealing
278	792651	Washer (Governor Control Lever)
287	697551	Screw (Dipstick Tube)
304	796678	Housing-Blower
305	691005	Screw (Blower Housing)
305A	790690	Screw (Blower Housing to Intake Elbow)
306	794953	Shield-Cylinder
309	497595	Motor-Starter
310	690323	Screw (Starter Motor)
311	497608	Brush Set
332	691059	Nut (Flywheel)
333	691060	Armature-Magneto
334	691061	Screw (Magneto Armature)
337	491055s	Plug-Spark
358	694012	Gasket Set-Engine
385	697551	Screw (Fuel Pump)
387	808656	Pump-Fuel
404	690442	Washer (Governor Crank)
415	690283	Plug (Crankcase Cover/Sump)
418	690999	Plate-Carburetor
431	792297	Elbow-Intake
445	792105	Filter-Air Cleaner Cartridge
447	691003	Screw (Air Guide Cover) (Short)
447A	697551	Screw (Air Guide Cover) (Long)
467	790697	Knob-Air Cleaner
474	696457	Alternator

Ref. No.	Part No.	Description
501	691188	Regulator
505	691029	Nut (Governor Control Lever)
510	696541	Drive-Starter
513	692024	Clutch-Drive
523	691036	Dipstick
524	691032	Seal-Dipstick Tube
525	691037	Tube-Dipstick
526	691129	Screw (Regulator)
544	692034	Armature-Starter
552	690552	Bushing-Governor Crank
552A	690553	Bushing-Governor Crank
559	695314	Screw (Remote Choke)
562	690311	Bolt (Governor Control Lever)
573	790444	Plate-Back
579	691029	Nut (Starter Cable)
601	691038	Hose-Clamp (Black)
601A	791850	Hose-Clamp (Green)
615	698290	Retainer-Governor Shaft
616	691045	Crank-Governor
617	697891	Seal-O Ring (Intake Manifold) (Red)
628	697551	Screw (Fuel Pump Bracket)
633	690998	Seal-Choke/Throttle Shaft
635	66538s	Boot-Spark Plug
654	690958	Nut (Carburetor)
668	691500	Spacer (Rotating Screen)
668A	691215	Spacer (Rotating Screen)
672	690234	Gasket-Carburetor Plate
691	790574	Seal-Governor Shaft
695	693149	Screw (Ring Gear)
697	690372	Screw (Drive Cap)
703	691010	Clip
718	690959	Pin-Locating (Cylinder)
726	499612	Gear-Ring
729	694123	Clip-Wire
741	690980	Gear-Timing
742	690328	Retainer-E Ring
750	796208	Screw (Oil Pump Cover)

- Included in Engine Gasket Set, Key Number 358.
- Ø Included in Carburetor Overhaul Kit, Key Number 121.
- + Included in Valve Gasket Set, Key Number 1095.

PARTS LIST

Craftsman Engine Model 407777-0717-B1 For Revolution Model 247.28933

Ref. No.	Part No.	Description
783	695708	Gear-Pinion
788	793145	Bracket-Fuel Pump
789	698330	Harness-Wiring
797	693167	Nut (Brush Retainer)
798	697890	Screw (Rocker Arm)
801	691283	Cap-Drive
802	691286	Cap-End
803		Housing-Starter (Serviced by 497595
		Starter Motor Only, Reference 309)
842	691031	Seal-O Ring (Dipstick Tube)
847	499602	Dipstick/Tube Assembly
850	100106	Sealant-Liquid (Liquid Sealant is inter
		changeable with the Rocker Cover
		Gasket and Breather Gasket)
851	493880s	Terminal-Spark Plug
865	691012	Cover-Air Guide (Cylinder #1)
865A	796541	Cover-Air Guide (Cylinder #2)
865B	792286	Cover-Air Guide (Valley)
868•+	690968	Seal-Valve
877	790544	Wire/Connector-Alternator
883•	690970	Gasket-Exhaust
914	691127	Screw (Rocker Cover)
918	793147	Hose-Vacuum
929	695239	Screw (Choke Control Bracket)
943	796222	Seal-O Ring (Oil Pump Cover)
947	841546	Solenoid-Fuel
965	796221	Cover-Oil Pump
967	792303	Filter-Pre Cleaner
968	795120	Cover-Air Cleaner
975	793592	Bowl-Float
987	691000	Seal-Throttle Shaft

Ref. No.	Part No.	Description
1005	791236	Fan-Flywheel
1013	690954	Nipple-Oil Filter
1017	796214	Screen-Oil Pump
1022•+	690971	Gasket-Rocker Cover
1023	793146	Cover-Rocker (Cylinder #1)
1023A	499600	Cover-Rocker (Cylinder #2)
1024	796220	Pump-Oil
1026	690981	Rod-Push (Steel)
	690982	Rod-Push (Aluminum)
1027	795890	Filter-Oil
1029	690972	Arm-Rocker
1036		Label-Emissions (Available from a Briggs
		& Stratton Authorized Dealer)
1040	791237	Plate-Trim
1051	691265	Ring-Retaining (Starter Motor)
1054	280275	Tie-Cable
1058	277103	Operator's Manual
1059	698516	Kit-Screw/Washer (Alternator)
1070	791680	Screw (Flywheel Fan)
1090	691293	Retainer-Brush
1095	694013	Gasket Set-Valve
1100	791959	Pivot-Rocker Arm
1119	691183	Screw (Alternator)
1123	841653	Seal-O Ring (Solenoid Retainer)
1124	690988	Seal-O Ring (Fuel Transfer Tube)
1126	690991	Screw (Fuel Transfer Tube)
1127	695407	Screw (Float Bowl)
1128	690990	Screw (Carburetor Nozzle)
1169	690990	Screw (Carburetor Cover Plate)
1329	44L7770037	Replacement Engine
1330	273521	Repair Manual

- Included in Engine Gasket Set, Key Number 358.
- Ø Included in Carburetor Overhaul Kit, Key Number 121.
- + Included in Valve Gasket Set, Key Number 1095.