


PARTS LIST

MODEL 316-29260

ELECTRIC CULTIVATOR



PARTS LIST

MODEL 316-29260 ELECTRIC CULTIVATOR

<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	625-04027	Switch Assembly
2	710-04213	Screw, T27, 1/4-20, 1.75"
3	710-0572	Bolt, Carriage, 5/16-18, 2.50, Gr1
4	710-0805	Hex Screw, 5/16-18, 1.50, Gr5
5	712-0324	Nut, Hex Lock, 1/4-20, Gr8, Nylon
6	712-04063	Nut, Flange Lock, 5/16-18, GrF, Nylon
7	720-04052	Knob, Nut, 5/16-18
8	726-0368	Cord Retainer
9	731-05178	Insulator, Upper Handle
10	731-05186	Insulator, Lower Handle
11	731-1820	Guide Cable
12	736-0451	Washer, Saddle, 320 x .93 x .060
13	747-04375	Control Bail
14	747-04376A	Guide Rod
15	749-04210	Handle, Upper
16	749-1295A	Handle, Lower
17	10055-20	Flex Shaft, 4.5"
18	11A6798	Gearbox
19	4150	Washer, Flat
20	4278	Sleeve
21	686-0176	Tine Assembly, Outer
22	686-0177	Tine Assembly, Inner
23	686-0178	Tine Assembly, Outer
24	686-0179	Tine Assembly, Inner
25	710-0597	Hex Screw, 1/4-20, 1.00, Gr5
26	4543	Bolt, Hex Washer 1/4-20 x .50
27	712-04064	Nut, Flange Lock, 1/4-20, GrF, Nylon
28	714-0220	Lynch Pin, .1875
29	750-04441	Tube, .922 x 1.0 x 3.0
30	731-04321	Bushing, Cord
31	786-04000	Tine Shield
32	1625	Washer, Lock, #10
33	1A2679	Tube w/ Spacers
34	1948	Screw, .750
35	50004	Fan
36	50545	Motor Pad, 1"
37	624-04008	Motor Assembly, 120 V
38	1926	Screw, #8-32 x .312
39	731-05207	Motor Cover, Front
40	731-05208	Motor Cover, Rear
41	748-04085	Motor Hub
42	786-04268	Motor Strap
43	686-0181	Bracket Assembly, Tail Piece
44	686-0182A	Support Bracket Assembly, Wheel
45	710-04468	Hex Flange Screw, 1/4-20, .50, Gr5
46	711-0993	Belt Guard Pin 1/4 Dia. x 1.43
47	711-1017	Clevis Pin, .250 x 1.53
48	714-0104	Cotter Pin, .072 Dia. x 1.13
49	726-0299	Push Cap, 1/2"
50	734-1988	Wheel, 7 x 1.8 Spoke Bar Gray