



SECTION 7: PARTS LIST FOR MODEL SERIES 020



Ref. No.	Part No.	Part Description
1.	725-1700	Switch Cover
2.	725-3166	Safety Switch
3.	710-0224	Hex Washer Screw #10-16 x.50
4.	629-0920	Wire Harness
5.	710-0604A	Hex Washer Screw 5/16-18 x.625
6.	714-0104	Cotter Pin
7.	736-0264	Flat Washer.330 ID x.630 OD
8.	732-0962	Compression Spring
9.	781-0778A	Mounting Bracket
10.	747-1153	Lock Rod
11.	710-3008	Hex Cap Screw 5/16-18 x.75
12.	681-0122	Chipper Chute Assembly
13.	726-0454	U-Clip Lock Nut 5/16-18
14.	736-0607	External Lock Washer 5/16
15.	710-0502A	Hex Washer Screw 3/8-16 x 1.25
16.	710-0969	Screw #12-16 x 1.0
17.	710-3195	Hex Cap Screw 5/16-18 x 4.5
18.	710-3025	Hex Cap Screw 5/16-18 x.625
19.	710-0604A	Hex Washer Screw 5/16-18 x.625
20.	781-1085	Upper Housing
21.	710-1054	Hex Screw 5/16-24 x 1.0
22.	781-0490	Chipper Blade
23.	736-0119	Lock Washer 5/16
24.	712-0411	Hex Lock Nut 5/16-24
25.	719-0530A	Impeller Weldment
26.	719-0329	Flail
27.	781-0735	Pin Clip
28.	711-1401	Clevis Pin
29.	715-0166	Spiral Pin
30.	736-0247	Flat Washer.375 ID x 1.25 OD
31.	736-0217	Lock Washer 3/8
32.	710-0818	Hex Cap Screw 3/8-24 x 2.0
33.	681-0154	Screen Assembly
34.	710-1238	Hex Cap Screw 5/16-18 x.875
35.	781-0721A	Lower Housing
36.	712-3004A	Lock Nut 5/16-18
37.	731-1905	Nozzle Cover
38.	681-0152	Impeller Assembly (Includes Ref. 21– Ref. 29)
39.	731-1613	Safety Switch Cover
—	723-0400	Safety Glasses (Not Shown)

Model Series 020



Model Series 020

Ref. No.	Part No.	Part Description
1.	749-0438D	Upper Handle
2.	720-0241	Handle Knob 5/16-18
3.	710-1174	Carriage Bolt
4.	749-0907B	Lower Handle
5.	664-0095	Bag Assembly
6.	711-1293	Studs
7.	712-0397	Wing Nut 1/4-20
8.	710-0703	Carriage Screw 1/4-20 x.75
9.	726-0453	Lock U-Clip Nut 3/8-16
10.	781-0777	Rear Wheel Support Brace
11.	712-3004A	Flange Lock Nut 5/16-18
12.	714-0104	Cotter Pin
13.	681-0155	Handle Bracket Ass'y LH
	681-0156	Hndle Brkt Ass'y RH (Not Shown)
14.	710-3025	Hex Cap Screw 5/16-18 x.625
15.	736-0105	Bell Washer.401 ID x.870 OD
16.	734-1987	Wheel 8 x 8.1
17.	738-1015	Shoulder Screw 3/8-16
18.	781-0725A	Front Wheel Support Brace
19.	781-0785	Height Adjustment Bracket
20.	738-1185	Stud 5/16-18 .56 x .75
21.	741-0751	Height Adjustment Bearing
22.	682-0113	Pivot Arm Assembly
23.	720-0426	Height Adjustment Knob
24.	732-1026	Spring Lever
25.	736-0741	Bell Washer .760 ID x .25OD
26.	738-1173	Shoulder Screw .750 ID x .625 OD
27.	712-0431	Flange Lock Nut 3/8-16
28.	736-0314	Thrust Washer .375 ID x .70 OD
29.	769-0451	Saddle Washer
30.	631-0090	Blower Chute Ass'y (if so equipped)
31.	764-0632	Bag
32.	631-0083	Chute Assembly
33.	710-3025	Hex Cap Screw 5/16-18 x.750