




PARTS LIST

Yard Vacuum — Model No. 247.770120



* Impeller (719-0530A) cannot be ordered separately. To order the impeller, entire assembly (681-0152) must be purchased.



PARTS LIST


Yard Vacuum — Model No. 247.770120

Ref. No.	Part No.	Description
1	725-1700	Switch Cover
2	725-3166	Safety Switch
3	710-0224	Hex Washer Screw, #10-16 x.50
4	629-0920A	Wire Harness
5	731-1613	Safety Switch Cover
6	714-0104	Cotter Pin
7	731-1905A	Nozzle Cover
8	732-0962	Compression Spring
9	781-0778A	Mounting Bracket
10	747-1153	Lock Rod
11	712-04063	Flange Lock Nut, 5/16-18
12	736-0607	External Lock Washer 5/16
13	710-0502A	Hex Washer Screw 3/8-16 x 1.25
14	710-1220	Screw, #12-16 x .750
15	710-3195	Hex Cap Screw 5/16-18 x 4.5
16	710-3025	Hex Cap Screw 5/16-18 x.625
17	710-0607	Screw, 5/16-18 x.500
18	710-0726	Screw, 5/16-12 x.75

Ref. No.	Part No.	Description
19	710-1054	Hex Screw 5/16-24 x 1.0
20	781-0490	Chipper Blade
21	736-0119	Lock Washer 5/16
22	712-0411	Hex Lock Nut 5/16-24
23	681-0152	Impeller Assembly
24	719-0329	Flail Blade
25	781-0735	Pin Clip
26	711-1401	Clevis Pin
27	715-0166	Spiral Pin
28	736-0247	Flat Washer.375 ID x 1.25 OD
29	736-0217	Lock Washer 3/8
30	710-0818	Hex Cap Screw 3/8-24 x 2.0
31	681-0154	Screen Assembly
32	710-1650	Shoulder Screw, .30 x .46
33	781-0721B	Lower Housing
34	664-0094	Bag Assembly
35	631-0083	Chute Assembly
—	723-0400	Safety Glasses (Not Shown)

PARTS LIST

Yard Vacuum — Model No. 247.770120



PARTS LIST

Yard Vacuum — Model No. 247.770120


Ref. No.	Part No.	Description
1	681-0122	Chipper Chute Assembly
2	749-04172	Upper Handle
3	720-0279	Knob
4	710-1205	Eye Bolt
5	720-04072	Star Knob, 5/16-18
6	710-1174	Carriage Bolt
7	749-04165	Lower Handle
8	781-04068	Upper Housing
9	711-1293	Studs
10	712-0397	Wing Nut 1/4-20
11	710-0703	Carriage Screw 1/4-20 x.75
12	710-0726	Screw, 5/16-12 x.750
13	781-04081	Rear Wheel Support Brace
14	712-04065	Flange Lock Nut, 3/8-16
15	714-0104	Cotter Pin
16	681-0155A	Handle Bracket Assy. LH

Ref. No.	Part No.	Description
	681-0156A	Hndle Brkt Assy. RH (Not Shown)
17	631-0090	Blower Chute Assembly
18	736-0105	Bell Washer.401 ID x.870 OD
19	734-2004A	Wheel, 8 x 2.125
20	738-1015	Shoulder Screw 3/8-16
21	731-0981A	Hubcap
22	781-04082	Front Wheel Support Brace
23	736-0314	Thrust Washer.375 ID x.70 OD
24	738-1172	Shoulder Screw, .750 ID x .500
25	741-0751	Height Adjustment Bearing
26	687-02094	Pivot Arm Assembly
27	736-0232	Wave Washer.531 ID x.781 OD
28	720-0426	Height Adjustment Knob
29	732-1026	Spring Lever
30	736-0741	Bell Washer.760 ID x.25OD

PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02

For Yard Vacuum Model 247.770120




1330 REPAIR MANUAL

1058 OPERATOR'S MANUAL


PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02



For Yard Vacuum Model 247.770120







843



365




188



PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02

For Yard Vacuum Model 247.770120



PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02

For Yard Vacuum Model 247.770120

Ref. No.	Part No.	Description
1	697322	Cylinder Assembly
2	399269	Kit-Bushing/Seal
3	299819S†	Seal-Oil (Magneto Side)
4	493279	Sump-Engine
5	691160	Head-Cylinder
7	692249†	Gasket-Cylinder Head
8	695250	Breather Assembly
9	696125	Gasket-Breather
10	691125	Screw (Breather Assembly)
11	691781	Tube-Breather
12	692232†	Gasket-Crankcase
13	690912	Screw (Cylinder Head)
15	691680	Plug-Oil Drain
16	694478	Crankshaft
20	399781S†	Seal-Oil (PTO Side)
22	691092	Screw (Engine Sump)
23	691987	Flywheel
24	222698S	Key-Flywheel
25	791097	Piston Assembly (Standard)
	791326	Piston Assembly (.020" Oversize)
26	791098	Ring Set (Standard)
	791324	Ring Set (.020" Oversize)
27	691866	Lock-Piston Pin
28	499423	Pin-Piston
29	499424	Rod-Connecting
32	691664	Screw (Connecting Rod)
32A	695759	Screw (Connecting Rod)
33	262651S	Valve-Exhaust
34	262652S	Valve-Intake
35	691270	Spring-Valve (Intake)
36	691270	Spring-Valve (Exhaust)

Ref. No.	Part No.	Description
37	694086	Guard-Flywheel
40	692194	Retainer-Valve
43	691997	Slinger-Governor/Oil
45	690548	Tappet-Valve
46	691449	Camshaft
48	790450	Short Block
50	497465	Manifold-Intake
51	272199S†	Gasket-Intake
54	691650	Screw (Intake Manifold)
55	691421	Housing-Rewind Starter
58	697316	Rope-Starter (Cut to Required Length)
60	281434S	Grip-Starter Rope
65	690837	Screw (Rewind Starter)
78	691108	Screw (Flywheel Guard)
81	691740	Lock-Muffler Screw
95	691636	Screw (Throttle Valve)
97	696565	Shaft-Throttle
104	691242‡	Pin-Float Hinge
108	691182	Valve-Choke
109	498593	Shaft-Choke
117	498981	Jet-Main (Standard)
118	494870	Jet-Main (High Altitude)
121	498260	Kit-Carburetor Overhaul
125	792253	Carburetor
127	694468‡	Plug-Welch
130	696564	Valve-Throttle
133	398187	Float-Carburetor
134	398188‡	Valve-Needle/Seat
137	693981‡*	Gasket-Float Bowl
159	691753	Bracket-Air Cleaner Primer
163	272653S†‡*	Gasket-Air Cleaner

PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02

For Yard Vacuum Model 247.770120

Ref. No.	Part No.	Description
187	691050	Line-Fuel (Cut to Required Length)
188	693399	Screw (Control Bracket)
190	690940	Screw (Fuel Tank)
202	691829	Link-Mechanical Governor
209	691291	Spring-Governor
222	692150	Bracket-Control
227	690783	Control Lever-Governor
276	271716†*	Sealing Washer
287	690940	Screw (Dipstick Tube)
300	692038	Muffler
304	493294	Housing-Blower
305	691108	Screw (Blower Housing)
306	690450	Shield-Cylinder
307	690345	Screw (Cylinder Shield)
332	690662	Nut (Flywheel)
333	802574	Armature-Magneto
334	691061	Screw (Armature Magneto)
337	802592S	Plug-Spark
356	496381	Wire-Stop
358	497316	Engine Gasket Set
363	19069	Flywheel Puller
365	692524	Screw (Carburetor)
383	89838s	Wrench-Spark Plug
404	690272	Washer (Governor Crank)
425	690670	Screw (Air Cleaner Cover)
443	692523	Screw (Air Cleaner Primer Base)
445	491588S	Filter-Air Cleaner Cartridge
455	791960	Cup-Flywheel
456	692299	Plate-Pawl Friction
459	281505	Pawl-Ratchet

Ref. No.	Part No.	Description
505	691251	Nut (Governor Control Lever)
523	495264	Dipstick
524	692296†	Seal-Dipstick Tube
525	495265	Tube-Dipstick
529	691923	Grommet
562	691119	Bolt (Governor Control Lever)
584	697734	Cover-Breather Passage
585	691879†	Gasket-Breather Passage
592	690800	Nut (Rewind Starter)
597	691696	Screw (Pawl Friction Plate)
601	791850	Clamp-Hose
608	497680	Starter-Rewind
613	691340	Screw (Muffler)
615	690340	Retainer-Governor Shaft
616	698801	Crank-Governor
617	270344S††*	Seal-O Ring (Intake Manifold)
621	692310	Switch-Stop
633	691321†*	Seal-Choke/Throttle Shaft
633A	693867†*	Seal-Choke/Throttle Shaft
635	66538S	Boot-Spark Plug
668	493823	Spacer
670	692294	Spacer-Fuel Tank
684	690345	Screw (Breather Passage Cover)
689	691855	Spring-Friction
692	690572	Spring-Detent
718	690959	Pin-Locating
741	790345	Gear-Timing
832	499034	Guard-Muffler
836	690664	Screw (Muffler Guard)
842	691031†	Seal-O Ring (Dipstick Tube)

PARTS LIST

Craftsman 6.5 H.P. Engine Model No. 124T02

For Yard Vacuum Model 247.770120

Ref. No.	Part No.	Description
843	691884	Sleeve-Lever
843A	691895	Sleeve-Lever
847	692017	Assembly-Dipstick/Tube
851	493880s	Terminal-Spark Plug
868	697338	Seal-Valve
869	691155	Seat-Valve (Intake)
870	690380	Seat-Valve (Exhaust)
871	262001	Bushing-Guide (Exhaust)
	63709	Bushing-Guide (Intake)
930	691919	Guard-Rewind
957	699985	Cap-Fuel Tank
966	496116	Base-Air Cleaner Primer
968	692298	Cover-Air Cleaner
970	691669	Screw (Air Cleaner Primer Bracket)
972	699374	Tank-Fuel
975	493640	Bowl-Float

Ref. No.	Part No.	Description
976	694395	Primer-Carburetor
977	498261	Set-Carburetor Gasket
1036		Label-Emissions (Available from a Briggs & Stratton authorized service dealer)
1058	MS3260	Operator's Manual
1059	692311	Kit-Screw/Washer
1210	498144	Assembly-Pulley/Spring (Pulley)
1211	498144	Assembly-Pulley/Spring (Spring)
1329	126T02-0005	Replacement Engine (Replacement Engine listed is not available in the State of California. Repair with individual parts. Transfer Rewind Assembly from original engine to replacement engine. Transfer Flywheel Assembly to replacement engine. Transfer Ground Wire Terminal and/or stop switch to replacement engine. Remove 694849 and add 694478.)
1330	272147	Repair Manual

†Included in Engine Gasket Set, Key. No. 358

‡ Included in Carburetor Overhaul Kit, Key. No. 121

* Included in Carburetor Gasket Set, Key. No. 977