



Blower Housing


Ref #	Part Number	Qty	Description
1	05931	1	Housing-Bearing
2	605-5189	1	Spiral Assembly - L.H. 24"
	605-5193-0662	1	Spiral Assembly - L.H. 26"
3	605-5188	1	Spiral Assembly - R.H. 24"
	605-5192-0662	1	Spiral Assembly - R.H. 26"
4	618-0120	1	Gear Assembly 24"
	618-0121	1	Gear Assembly 26"
5	684-0039A-0662	1	Housing Assembly 24"
	684-0040A	1	Housing Assembly 26"
6	684-0064	1	Arm-Idler Assembly
7	684-0065-0662	1	Impeller Assembly
8	705-5226	1	Reinforcement-Chute
9	710-0167	5	Screw-Carriage
10	710-0451	10	Screw-Carriage
11	710-0604	6	Screw-Hex
12	710-0890	2	Shear Bolt
13	712-0116	1	Nut-Hex Lock
14	712-0267	19	Nut-Hex
15	712-0429	2	Nut-Hex
16	712-0798	1	Nut-Hex
17	712-3027	5	Nut-Hex Lock
18	715-0114	2	Pin-Spring
19	731-1379	1	Adapter-Chute
20	732-0611	1	Spring
21	736-0119	9	Washer-Lock
22	736-0167	1	Washer-Flat
23	736-0169	1	Washer-Lock
24	736-0188	6	Washer-Flat
25	736-0242	16	Washer-Bell
26	738-0281	1	Screw-Shoulder
27	741-0245	2	Bearing Flange
28	741-0309	1	Bearing Ball
29	741-0475	1	Bushing-Plastic
30	741-0493A	4	Bushing-Flange
31	756-0178	1	Idler-Flat
32	784-5580-0662	2	Shoe-Slide
33	784-5581A-0662	1	Shave Plate 24"
	784-5579A-0662	1	Shave Plate 26"
34	784-5618	2	Housing-Bearing
35	784-5647	1	Bracket-Chute Crank



Ref #	Part Number	Qty	Description
1	05896A	1	Bracket-Idler
2	629-0071	1	Cord-Extension 110V
3	710-0117	1	Screw-Hex
4	710-0157	1	Screw-Hex
5	710-0230	1	Screw-Hex
6	710-0342	1	Screw-Hex
7	710-0459	1	Screw-Hex
8	710-0888	1	Screw-Hex
9	710-0896	2	Screw-Hex
10	712-0181	1	Nut-Hex
12	731-1324	1	Cover-Belt
13	732-0710	1	Spring
14	736-0119	1	Washer-Lock
15	736-0242	1	Washer-Bell
16	736-0247	1	Washer-Flat
17	736-0329	1	Washer-Lock
18	736-0331	1	Washer-Bell
19	736-0505	1	Washer-Flat
20	748-0234	1	Spacer
21	748-0360	1	Adapter-Pulley
22	754-0346	1	V-Belt
23	754-0430	2	V-Belt
24	756-0313	1	Idler-Flat
25	756-0620	3	Pulley Half
26	756-0621	1	Pulley Half
27	756-0967	2	Pulley-Auger
28	756-0986	1	Pulley Half
29	756-0987	1	Pulley Half




Ref #	Part Number	Qty	Description
1	618-0123	1	Housing - R.H.
2	618-0124	1	Housing - L.H.
3	710-0642	5	Screw
4	711-0909	1	Axle, Spiral 26"
	711-0908	1	Axle, Spiral 24"
5	714-0161	1	Key, Hi-Pro
6	715-0143	1	Pin, Spiral
7	717-0526	1	Worm, Shaft
8	717-0528	1	Gear, Worm
9	718-0186	1	Collar, Thrust
10	721-0325	1	Plug
11	721-0327	1	Seal, Oil
12	721-0328		Loctite 5699, Ultra
13	736-0351	2	Washer
14	736-0369	4	Washer
15	736-0445	1	Washer
16	737-0168	1	Grease
17	741-0662	1	Bearing Flange
18	741-0663	1	Bearing Flange



Handle Assembly



Ref #	Part Number	Qty	Description
1	629-0059	1	Harness-Light
2	684-0008	1	Arm-Shift
3	684-0032A	1	Panel Ass'y.-Handle w/Tilt
4	684-0036	1	Handle-Engagement - R.H.
5	684-0037	1	Handle-Engagement - L.H.
6	684-0053	1	Crank-Chute
7	710-0262	1	Bolt-Carriage
8	710-0451	1	Bolt-Carriage
9	710-0118	4	Screw-Hex
10	710-3015	8	Screw-Hex
11	710-0896	7	Screw-Washer Head-Hex
12	710-1003	2	Screw-Hex
13	710-1178	4	Bolt-Carriage
14	710-1250	4	Bolt-Carriage
15	711-0653	1	Pin-Clevis
16	711-0677	1	Ferrule
17	712-0116	1	Nut-Hex Lock
18	712-0267	6	Nut-Hex
19	712-3027	8	Nut-Hex Lock
20	712-3068	3	Nut-Hex Lock
21	714-0104	3	Pin-Cotter Internal
22	714-0145	1	Pin-Cotter
23	714-0507	4	Pin-Cotter
24	715-0138	2	Pin-Roll
25	720-0201A	1	Knob-Chute Crank
26	720-0232	2	Knob-Shift
27	720-0284	4	Knob-Wing Nut
28	725-1658	1	Lamp
29	725-1672	1	Housing-Lamp
30	726-0100	1	Cap-Push
31	726-0321A	2	Clip-Retaining
32	731-0851A	3	Keeper-Chute
33	731-1300A	1	Chute-Lower
34	731-1313B	2	Guide-Cable
35	731-1320	1	Chute-Upper
36	731-1545	1	Panel Handle
37	732-0145	1	Spring
38	732-0193	1	Spring
39	732-0705	1	Wire-Control
40	732-0746	1	Spring
41	735-0199A	2	Bumper
42	736-0105	1	Washer-Bell
43	736-0119	2	Washer-Lock
44	736-0140	2	Washer-Flat
45	736-0231	1	Washer
46	736-0242	9	Washer-Bell
47	736-0264	2	Washer-Flat
48	736-0271	1	Washer-Lock
49	736-0451	4	Washer-Saddle
50	736-0506	1	Washer
51	736-0509	2	Washer
52	737-0133		Lubricant
53	741-0475	1	Bushing-Plastic
54	746-0896	1	Cable-Chute Control
55	746-0901	1	Cable-Chute Control
56	747-0618	1	Crank-Chute

Ref #	Part Number	Qty	Description
57	747-0620A	1	Rod-Shift Upper
58	747-0621	1	Rod-Shift Lower
59	747-0877	2	Rod-Cam
60	748-0362	2	Cam-Handle Lock
61	748-0363	1	Pawl-Handle Lock
62	749-0951	1	Handle-Lower
63	749-0954	1	Handle - R.H.
64	749-0955	1	Handle - L.H.
65	750-0785	1	Spacer
66	750-0963	1	Connector
67	784-0309	1	Bracket
68	784-5594	1	Bracket-Cable
69	784-5604	1	Handle-Chute Tilt
70	784-5619	1	Handle-Shift
71	784-5679	1	Bracket-Handle Support - L.H.
72	784-5680	1	Bracket-Handle Support - R.H.
73	784-5681	1	Bracket-Handle Support - L.H.
74	784-5682	1	Bracket-Handle Support - R.H.



Ref #	Part Number	Qty	Description
1	611-0053	2	Axle Assembly
2	618-0043	1	Dog Assembly - R.H.
3	618-0044	1	Dog Assembly - L.H.
4	618-0169		Shaft Assembly
6	656-0012A	1	Disc Assembly
7	683-0024	2	Hub Assembly
9	684-0014A	1	Rod Shift Assembly
10	684-0021	1	Bracket Assembly
12	684-0031	1	Frame Assembly
14	684-0042A	1	Wheel Assembly Friction Rubber Only
	735-0243		
15	710-0118	2	Screw
18	710-0599	2	Screw
19	710-0602	8	Screw
20	710-0604	6	Screw
21	710-0642	2	Screw
22	710-0654A	4	Screw
23	710-0788	2	Screw
24	710-0896	10	Screw
25	710-1087	2	Screw
27	710-1233	2	Screw
28	711-0911	1	Shaft
29	711-1042	1	Shaft
30	712-0127	2	Nut Flange
35	712-0711	1	Nut Jam
36	713-0233	1	Chain
37	713-0413	1	Sprocket
38	713-0437	2	Chain
39	714-0474	1	Pin Cotter
40	719-0295A	1	Housing Track
42	725-0157	2	Cable Tie
45	732-0209	2	Spring
46	732-0264	1	Spring
47	736-0105	1	Washer-Bell
49	736-0160	1	Washer-Flat
50	736-0176	2	Washer-Flat
51	736-0242	5	Washer-Bell
52	736-0270	2	Washer-Bell
54	736-0287	4	Washer-Flat
56	737-0170		Lubricant
58	738-0924	3	Screw-Shoulder
59	741-0339	4	Bearing-Flange
60	741-0563	2	Bearing Ball
61	741-0597	2	Bearing-Hex Flange
62	746-0897	1	Cable-Auger Clutch
63	746-0898	1	Cable-Drive Clutch
64	746-0900	2	Cable with Trigger Lever
65	748-0190	1	Spacer
66	748-0234	2	Spacer-Shoulder
69	750-0903	2	Spacer-Split
70	750-0904	1	Spacer-Split
73	750-0997	1	Spacer
74	756-0625	3	Roller-Cable
75	784-5590	1	Bracket
76	784-5609	1	Bracket
79	784-5648	1	Cover-Frame

Ref #	Part Number	Qty	Description
80	784-5687	1	Bracket-Guide
81	784-5688	1	Bracket-Guide
82	784-5689	1	Bracket-Guide



Ref #	Part Number	Qty	Description
5	631-0032	2	Wheel Assembly Idler
8	684-0009	1	Rod Track Pivot
11	684-0024	1	Axle Assembly
13	684-0038	1	Handle Assembly
	735-0243		Rubber Only
16	710-0157	1	Screw
17	710-0459	1	Screw
20	710-0604	6	Screw
26	710-1231	2	Screw
31	712-0214	1	Nut Lock
32	712-0267	4	Nut Hex
33	712-0346	4	Nut Jam
34	712-0429	2	Nut Hex
41	720-0223	1	Grip
43	731-1292	2	Track
44	731-1538A	2	Wheel-Track Drive
48	736-0119	4	Washer-Lock
51	736-0242	5	Washer-Bell
53	736-0272	4	Washer-Flat
55	736-0406	4	Washer-Flat
56	737-0170		Lubricant
57	738-0140	4	Screw-Shoulder
67	748-0353A	1	Lift-Shaft Drive
68	750-0547	2	Spacer
71	750-0909	2	Spacer
72	750-0995	2	Spacer
77	784-5639	2	Plate-Track Side
78	784-5642	1	Plate-Track Lockout
83	717-1211	2	Gear Ring
84	717-1209	6	Gear 12-Tooth
85	717-1210	1	Gear 18-Tooth
86	741-0542	6	Pin Dowel
87	718-0188	2	Carrier