


REPLACEMENT PARTS - MODEL PS720 POLE SAW ATTACHMENT



Item	Part No.	Description
1	753-04352	Extension Boom
2	753-1190	Split Boom Coupler (includes 3-6)
3	791-182057	Screw
4	791-181617	Bolt
5	791-181981	Adjustment Knob
6	753-04386	Knob Retaining Nut
7	753-05724	Drive Shaft Housing
8	791-181166	Flexible Drive Shaft
9	791-180288	Screw
10	753-05586	Oil Tank Assembly
11	753-05587	Fuel Cap Assembly
12	753-05274	Screw
13	753-05588	Oil Line
14	753-05589	Screw
15	753-05591	Nut
16	753-05593	Chain Guard
17	753-05685	Chain
18	753-05684	Bar
19	753-05595	Sprocket Assembly
20	753-05596	Bolt
21	753-05597	Chain Tension Hardware Assembly
22	753-05686	Chain Cover
23	753-05599	Gearbox Assembly (includes 14 & 19)

* **Items not Shown**

- * 791-612605 Hanger
- * 753-05774 Allen Wrench