



Model Series 380



Model Series 380

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	710-0351	Screw Mach. B Tapp	30.	746-0713	Drive Cable
2.	712-0400	U-Nut	31.	710-1174	Cr.Hd. Bolt 5 / 16-18 x 2" Lg.
3.	731-1639	Baffle	32.	736-0451	Saddle Washer.320 ID x.830 OD
4.	710-1220	Screw HL 12-24	33.	720-0284	Wing Nut
5.	710-0653	Screw Tap 1/4-20	34.	746-1131	Control Cable-46"
6.	731-1714A	Belt Cover	35.	731-0904A	Upper Control Handle
7.	754-0271	Belt	36.	647-0004	Deluxe Control Handle Ass'y
8.	731-1685	Mulch Plug	37.	731-0620	Control Lever
9.	742-0741	21" Mulching Blade w/Star	38.	16864	6-Speed Rack Cable Bracket
10.	731-0981A	Hub Cap	39.	732-0627	Shift Lever Spring
11.	738-0137A	Shldr. Scr.340x.285	40.	712-0324	Top Lock Nut
12.	10622B	Spring, Ratchet	41.	731-0924	6-Speed Shift Lever
13.	748-0381	Pawl R.H.	42.	749-0439D	Upper Handle
	748-0188B	Pawl L.H. (Not Shown)	43.	731-0906	Cable Mounting Cap
14.	16855	Pawl Plate	44.	710-1667A	C-Sunk Tap Screw #10-x.75 Lg
15.	712-0414	Weld Top L. 1/4-20	45.	731-0905A	Lower Control Housing
16.	734-1979	Wheel Assembly	46.	746-0883	Control Housing
17.	710-1348	Screw AB 1/4-20	47.	710-1270	Oval C Sunk Screw
18.	782-3030	Handle Brkt. Ass'y - R.H.	48.	713-0397	Gear Insert
19.	732-04074	Torsion Spring L.H.	49.	736-0524A	Blade Bell Support
20.	750-1068	Spacer.385 I.D.	50.	710-1257	Hex Bolt 3/8-24 x 2.5 Lg.
21.	782-3029	Handle Brkt. Ass'y - L.H.	51.	748-0377C	Blade Adapter
22.	682-0075	21" Deck	52.	753-0609	Blade Adapter Kit w/Star
23.	747-0922	Pivot Rod	53.	710-0924	Mach. Screw 1/4-20
24.	731-1236	Rear Flap 17.77 Lg.	54.	747-0958	Mounting Rod
25.	782-7599B	Rear Chute Door	55.	731-1461	Rear Side Discharge Defl. Chute
26.	732-0700	Wire-47" Lg.	56.	720-0279	Handle Knob
27.	714-0104	Cotter Pin	57.	710-1205	Rope Guide
28.	749-0907B	Lower Handle	58.	782-7018	Pulley Cover
29.	726-0240	Cable Tie	59.	710-1652	Screw 1/4-14 x.825

Model Series 380



Model Series 380

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	720-0230	Grip	26.	782-0568	Hgt Adjustment Spring Bracket
2.	732-0803A	Spring Lever	27.	710-1652	Screw 1/4-14 x.825
3.	738-0529	Shoulder Nut.825 x.165 Lg.	28.	714-0474	Cotter Pin
4.	710-0751	Cap Screw 1/4-20 x.620	29.	712-3006	Hex Nut 1/4-20
5.	736-0270	Bell Washer.285 ID x.75 OD	30.	712-0138	Hex Nut 1/4-28
6.	748-0318	Wheel Ratchet	31.	736-0329	Lock washer1/4
7.	736-0369	Flat Washer.508 ID x 1.0 OD	32.	782-7575A	Cable Bracket MT
8.	782-0566B	Pivot Arm Assembly	33.	710-1652	Self Tapping Screw 1/4-20 x.625
10.	741-0978	Sleeve Bearing.504 ID x.830 OD	34.	738-0924	Screw 1/4-20 x.375
11.	750-1056	Shoulder	35.	710-0167	Screw 1/4-20 x.625
12.	710-0653	Tap Screw 1/4-20 x.375	36.	750-1071	Spacer Sleeve 88ID x 1.13 x.12
13.	682-7524	Chain Cover Assembly	37.	736-0270	Bell Washer.265 x.75 x.062
14.	741-0324	Flange Bearing.506 ID x.590 Lg	38.	746-0939	Cable - 6-Speed (53")
15.	682-7518	Transmission Axle Assembly	39.	656-0613	Pulley Assembly Complete
16.	618-0263A	Transmission Assembly Complete	40.	750-1070	Spacer Sleeve 88 ID x 1.00 x.48
17.	710-0604A	Hex Screw 5/16-18	41.	736-0526	Wave Washer 1.38 OD x.88 ID.029
18.	713-0421	Chain	42.	782-7597	Pivot Bracket 6-Speed
19.	638-0005	Rear Axle Assembly	43.	782-7574A	Bracket Adjustment 6-Speed
20.	741-0522	Flange Bearing.506 ID x.715 Lg	44.	732-0807	Torsion Spring
21.	732-0818	Torsion Spring - R.H.	45.	711-1114	Shaft Pivot 3/8OD x 7.75 LG
22.	750-1075	Slv. Spacer.520 ID x.950 Lg.	46.	664-0080	Grassbag - Black
23.	710-1315	Screw 3/8-16 x.25	47.	747-0919	Grassbag Frame
24.	711-0835	Clevis Pin.50 Dia x 4.82 Lg.	48.	782-7596	Control Arm 6-Speed
25.	750-0807	Spacer.385 ID x.624 OD	49.	756-0625	Cable Roller