


SECTION 9: PARTS LIST FOR MODEL SERIES 285




† If Equipped

Model Series 285

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	747-1214	Drive Control Handle	36.	736-0741	Bell Washer.401 ID x.870 OD
2.	747-1161A	Blade Control Handle	37.	734-04158	Front Wheel
3.	746-1114	Blade Control Cable - 50.56"	38.	682-02094	Pivot Arm Assembly
4.	746-1093A	Drive Control Cable	39.	741-0751	Height Adjuster Bearing
5.	749-1092A	Upper Handle	40.	720-0426	Height Knob
6.	710-1205	Eye Bolt	41.	732-1026	Spring Lever
7.	720-0279	Wing Nut 1/4-20	42.	738-1172	Shoulder Screw 3/8-16
10.	710-1174	Carriage Bolt 5/16-18 x 2.0	43.	17032A	Deflector Chute Adapter
11.	720-0284	Wing Nut 5/16-18	44.	710-0599	Hex Washer Screw 1/4-20 x.50
12.	736-0451	Shoulder Washer.320 ID x.93 OD	45.	736-0270	Bell Washer.265 ID x.75 OD
13.	731-0074	Transmission Cover	46.	682-3072	Handle Bracket Assembly - RH
14.	725-0157	Cable Tie	47.	732-1014	Torsion Spring
15.	749-04037	Lower Handle	48.	747-0710	Hinge Pin
16.	756-1169	Transmission Pulley	49.	731-1034B	Side Discharge Chute Assembly
17.	712-0240	Jam Nut 7/16-20	50.	734-2042	Rear Wheel
18.	736-0407	Bell Washer.45 ID x 1.00 OD	51.	717-1762	Spur Gear 14T RH
19.	754-0484	V-Belt		717-1761	Spur Gear 14T LH
20.	710-0642	Hex Washer Screw 1/4-20 x.75	52.	715-0221	Pin
21.	738-1002	Shoulder Screw.375 x.25	53.	731-04643	Wheel Cover
22.	732-0993	Extension Spring	54.	748-0455	Bearing Support
23.	782-9061	Transmission Belt Bracket	55.	728-0199	Plastic Rivet
24.	682-3073	Handle Bracket Assembly - LH	56.	710-1802	Screw 1/4-20
25.	618-0607A	Transmission Assembly	57.	741-0710	Sleeve Bearing
26.	710-0654A	Hex Washer Screw 3/8-16 x 1.0	58.	731-04859	Snap-On Bail Cover
27.	782-9063	Engine Belt Keeper Bracket	59.	716-0198	Retainer Ring
28.	687-02049	22" Deck Assembly	60.	731-04019	Trail Shield
29.	712-0431	Flange Lock Nut 3/8-16	61.	750-1210	Sleeve Spacer.550 ID x 9.0 OD
30.	731-0981A	Hub Cap	62.	750-1209	Sleeve Spacer.550 ID x 2.44 OD
31.	748-04016A	One Piece Blade Adapter	63.	631-04045	Snap Mulching Plug
32.	742-0742A	22" Mulching Blade	64.	748-0390	Bearing Spacer
33.	736-0524B	Bell Blade Support	65.	712-0431	Hex Lock Nut 3/8-16
34.	710-1044	Hex Cap Screw 3/8-24 x 2.5	66..	710-0216	Hex Cap Screw 3/8-16 x 1.0
35.	736-3013	Flat Washer 1/2 x 1.00 x.030	67.	716-0865	Snap Ring.500

Model Series 285



Ref. No.	Part No.	Part Description
1.	618-0392	Upper Housing Assembly
2.	721-0329	Oil Seal.500 ID x.687 OD
3.	741-0673	Flange Bearing.503 ID x.689 OD
4.	736-0520	Flat Washer.504 ID x.700 OD x.030
	736-0711	Flat Washer.504 ID x.700 OD x.035
	736-0712	Flat Washer.504 ID x.700 OD x.040
	736-0713	Flat Washer.504 ID x.700 OD x.045
5.	717-1723	Bevel Gear 44T
6.	715-0139	Roll Pin
7.	711-1649	Output Shaft
8.	719-0538	Lower Housing
9.	710-1276	Hex Washer Screw 1/4-20 x.75
10.	716-0231	E-Ring.750
11.	736-0336	Flat Washer.625 ID x 1.0 OD x.030
	736-0337	Flat Washer.625 ID x 1.0 OD
	736-0349	Flat Washer.63 ID x 1.0 OD x.020
	736-0494	Flat Washer.632 ID x 1.0 OD x.035
	736-0495	Flat Washer.632 ID x 1.0 OD x.035
12.	741-0735	Needle Bearing.625 x.813
13.	719-0537	Upper Housing
14.	736-0336	Flat Washer.625 ID x 1.0 OD x.030
	736-0494	Flat Washer.632 ID x 1.0 OD x.035
15.	711-1390A	Input Shaft
16.	750-1242	Spacer.505 x.75 x.9765