




Count on it.


Part's Catalog

LX500 Lawn Tractor

Model No. 13AP60RP744




Model P60RP




REF. NO.	PART NUMBER	DESCRIPTION
1	734-1873-0904	Turf Tire, 20 x 10.0 x 8
2	934-0070-4009	Rim, 8.0 x 7.0
3	634-0177-0994	Wheel Assembly, 20 x 10.0 x 8
4	734-04040-0904	Tire, 15.0 x 6.0 x 6.0
5	934-04081-4009	Rim Assembly, 6.0 x 4.5 (Includes Bearings and Valve)
6	634-04087-0994	Wheel Assembly, 15.0 x 6.0 x 6.0
7	731-2290A	Hub Cap
—	934-0255	Valve, Tubeless

Model P60RP



REF. NO.	PART NUMBER	DESCRIPTION
1	683-04079-0637	Shaft Assembly, Lift
2	911-0332	Pin, Clevis, .50 Dia x .78 Lg
3	783-0720A-0637	Bracket, Deck
4	712-04065	Nut, Nylon Lock, 3/8-16
5	712-04063	Nut, Nylon Lock, 5/16-18, Gr5
6	712-3083	Nut, Hex Lock, 1/2-13, Gr8, Nylon
7	914-0104	Pin, Cotter, .072 Dia. x 1.13 Lg
8	914-0111	Pin, Cotter, 3/32, 1.0
9	914-04023	Pin, Click, .092 x 1.64 Lg
10	716-0106A	E-ring, .625 Dia. Shaft
11	720-0311	Grip, Handle
12	732-0874	Spring, Torsion
13	747-04155	Handle, Lift
14	747-1324	Rod, Deck .5" Dia.
15	756-1154	Pulley, Roller
16	783-0678A-0637	Arm, Lift
17	912-0206	Nut, Hex, 1/2-13
18	738-0138A	Screw, Hex Cap, 5/16-18x.620 Gr2
19	938-0380	Shoulder Screw, 3/8-16
20	941-0225	Bearing, Hex Flange
22	746-0968	Cable, Lift, 16.16 Lg


Model P60RP



Model P60RP

REF. NO.	PART NUMBER	DESCRIPTION
1	710-0514	Hex Cap Screw, 3/8-16, 1.00, Gr5, Std
2	711-1408	Link, Drag, RH
3	711-1409A	Link, Drag, LH
4	910-0643	Screw, 5/16-18 x 1.00
5	912-0240	Nut, Jam, 7/16-20, Gr2
6	912-0214	Nut, Hex, 3/8-24, Gr5
7	712-04065	Nut, Nylon Lock, 3/8-16
8	712-0459	Nut, Flange Lock, 7/16-20
9	912-3004A	Nut, Flange Lock, 5/16-18
10	717-1550E	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20
13	710-04095	Hex Cap Screw, 3/8-16, 1.00
14	936-3004	Washer, Flat, .406 x .875 x .105
15	936-3084	Washer, Flat, .510 x 1.120 x .060
16	731-05542	Cover, Steering Wheel
17	738-04154	Spacer, Shoulder, 1.00 x .38 x .38
18	938-04075	Shaft, Steering, .625 OD x 25.00 Lg
19	941-0475	Bushing, Plastic, .380 ID
20	941-0656A	Bearing, Hex Flange, 5/8
21	638-04003P	Axle Ass'y, LH .750 Dia
22	938-04004	Axle Ass'y, RH .750 Dia
23	926-0341	Push Cap, .75
24	714-04039	Pin, Cot, 5/32, 1.25
25	919-04105	Axle, Pivot, Cast .750 Dia
26	736-0866	Washer, Flat, .755 x 1.92 x .060
27	738-1011A	Screw, Shoulder, .500 x 2.230, 3/8-16
28	631-04008A	Wheel, Steering, Three Spoke


Model P60RP



Model P60RP

REF. NO.	PART NUMBER	DESCRIPTION
1	17962	Plate, Switch
2	683-04173-0637	Frame Assembly, Lower
3	783-0349-0637	Tray, Battery
4	910-0224	Screw, Hex Washer, 10-16 x .5
5	910-0726	Screw, Self-tapping, 5/16-18, 0.75
6	910-1260A	Screw, Self-tapping, 5/16-12, 0.75
7	910-1652	Screw, Hex Washer, 1/4-20 x 0.625
8	747-04121A	Hold-down Rod, Battery
9	712-04065	Nut, Nylon Lock, 3/8-16
10	710-0607	Screw, Hex Wash. Tapp, 5/16-18 x .5
11	710-0703	Screw, Carriage, 1/4-20, .75,
12	925-04039	Switch, Interlock
13	732-04035	Spring, Compression, 1.28 OD x 3.125
14	936-0222	Washer, Lock, Ext 1/4
16	738-04058	Shoulder Spacer
17	738-0143	Shoulder Screw, 3/8-16
18	910-3005	Hex Screw 3/8-16 x 1.25
19	783-0726E-0637	Bracket, Pivot, Support RH
20	783-0727D-0637	Bracket, Pivot, Support LH
21	783-0728-0637	Bracket, Pivot, Bar
22	783-04811-0637	Frame, Upper
23	783-04329A-0637	Bracket, Frame, Seat
24	712-04064	Nut, Nylon Lock, 1/4-20
25	910-0599	Screw, Self-tapping, 1/4-20, 0.500
26	925-1426A	Solenoid, 12V, 100 Amp
27	936-0222	Washer, External Lock, 1/4
28	910-0642	Screw, Hex. 1/4-20 x .75
29	925-1707D	Battery, 235 CCA
30	912-0324	Nut, Sems, 1/4-20


Model P60RP



Model P60RP

REF. NO.	PART NUMBER	DESCRIPTION
1	910-0227	Screw, #8-18, 0.500
2	910-0451	Bolt, Carriage, 5/16-18, .750 Gr1
3	910-0599	Screw, /4-20, 0.500
4	710-0604A	Screw, 5/16-18, 0.625
5	710-0788	Screw, 1/4-20, 1.000
6	710-0895	Screw, 1/4-15, 0.750
7	910-0932	Screw, Carriage, 1/4-20, 1.00, Gr1
8	912-0271	Nut, Sems, 1/4-20
9	712-04063	Nut, Flange Lock, 5/16-18, GrF, Nylon
10	731-05498A	Cover, Lift Lever
11	731-05515A	Cover, w/ Cup Holder
12	726-0279	Plate, Insulator
13	925-1303	Spring Switch, Outer
14	725-1439	Spring Switch, Inner
15	726-0278	Plate, Insulator Boss
16	926-3046	Clip, Ratchet, .250 Dia
17	736-0607	Washer, Lock, 5/16 Ext. Tooth
18	936-3078	Washer, Flat, .344 x 1.0 x .063
19	783-04477A-4008	Fender
20	783-0677B-4008	Lift Bracket, Adjustment
21	783-1489B-4008	Seat Bracket
22	720-04061	Knob, 3/8-16, .875
23	732-1184	Spring, Extension, .80 Dia x 4.6 Lg.
24	938-0296	Shoulder Screw .437 x .286 Lg
25	738-04012A	Shoulder Screw, .625 x .145, 3/8-16
26	783-04081A-4008	Pivot Bracket, Seat
27	783-0209D	Bracket, Seat Lift
28	757-04044	Seat, <i>Toro</i> Medium Back
29	735-0656	RH Foot Pad
30	735-0657	LH Foot Pad


Model P60RP



Model P60RP

REF. NO.	PART NUMBER	DESCRIPTION
1	910-0599	Screw, 1/4-20, 0.500
2	910-0642	Screw, 1/4-20, 0.750
3	910-0726	Screw, 5/16-12, 0.750
4	710-0895	Screw, 1/4-15, 0.750
5	710-1017	Screw, 1/4-14, 0.625
6	710-1611B	Screw, 5/16-18, 0.750
7	710-3217	Screw, #8-32, 0.375
8	712-0142	Nut, Hex, #8-32
9	931-04215	Lever, Cruise
10	931-04217	Lever, Parking Brake
11	731-05492	Dash Panel
12	731-1857	Knob
13	936-0270	Washer, Bell, .265 x .75 x .062
14	747-1196	Rod, Lever
15	783-04285D-0637	Support, Dash, RH
16	783-04323D-0637	Support, Dash, LH
17	783-0462	Bracket, PTO
18	931-05461	Hood
19	910-0623	Screw, 3/8-16, 0.750
20	731-05478	Grill
21	738-04091	Screw, Shoulder, .43 x .29, 5/16-18
22	783-04606A-4008	Pivot Bracket
23	783-04840-4008	Pivot Bracket, Hood RH
24	783-04841-4008	Pivot Bracket, Hood LH
25	783-05119-4008	Support Bracket, Hood
26	747-04161	Tank Support Rod
27	951-3111	Fuel Cap
28	751-10283	Fuel Tank, 3 Gal.
29	731-05511	Hood Plenum
30	931-05469	Lens, RH
31	931-05471	Lens, LH
32	777X42200	Reflector, RH
33	777X42201	Reflector, LH
34	925-1649	Lamp Socket, 1/4 Turn
35	925-0963	Miniature Lamp, 12V
36	925-04174	Switch, PTO
37	925-04036B	Meter, Systems Indicator
38	746-1085A	Choke Control
39	746-1086	Throttle Control
40	725-04340	Module, Ignition Switch
41	925-1745	Key, Ignition
—	929-04083	Headlight Harness
—	929-04336	Wiring Harness


Model P60RP



Model P60RP

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	17840-0637	Mounting Bracket, Transaxle	47	910-0650	Screw, 5/16-18, 0.875
2	925-04039	Switch, Interlock	48	910-1260A	Screw, 5/16-18, 0.750
3	17962	Plate, Switch	49	710-1611B	Screw, 5/16-18, 0.750
4	647-04020	Lever Assembly, Shift	50	711-04159B	Pin, 3/8-16 x 2.68
5	710-0607	Screw, 5/16-18, 0.500	51	912-3004A	Nut, Flange Lock, 5/16-18, Gr5
6	910-0726	Screw, 5/16-12, 0.750	52	732-0335	Spring, Compression, .405 x 1.17
7	710-0809	Screw, 1/4-20, 1.250	53	732-0955	Spring, Extension, .50 OD x 1.41
8	710-1007	Screw, Sems, 3/8-16, 1.500	54	732-0963	Spring, Extension, .50 OD x 6.37
9	710-1266	Screw, 5/16-18, 3.50, Gr5	55	735-0662	Pad
10	910-3144	Screw, 3/8-16, 2.00, Gr5	56	735-3049	Pad, Brake
11	711-0736	Adjustment Ferrule 1/4-20 x 1.	57	936-0187	Washer, Flat, .64 x 1.24 x .06
12	912-0241	Nut, Hex, 3/8-24, Gr5	58	736-0262	Washer, Flat, .385 x .870 x .092
13	712-04063	Nut, Flange Lock, 5/16-18, GrF, Nylon	59	936-0300	Washer, Flat, .406 x .875 x .059
14	712-04065	Nut, Flange Lock, 3/8-16, GrF, Nylon	60	936-3008	Washer, Flat, .344 x .750 x .120
15	912-0700	Nut, Flange, 9/16-18, Gr2	61	938-0155	Screw, Shoulder .437 Dia x .162
16	914-0104	Pin, Cotter, .072 Dia. x 1.13	62	938-0380	Screw, Shoulder, .50 x .27 Lg, 3/8-16
17	914-0111	Pin, Cotter, 3/32, 1.0	63	941-0225	Bearing, Hex Flange
18	914-0209	Cotter Pin, Internal, .125 Dia.	64	741-3065B	Split Bearing, Hex Flange
19	914-0470	Pin, Cotter, 1/8 x 1.25	65	747-04093	Rod, Brake Lock
20	918-0758A	Pulley Hub, 5/8 Spline	66	747-04096	Rod, Cruise Control
21	720-04028	Knob, Shift	67	748-04039B	Latch, Cruise Control
22	923-3018	Ball Joint	68	683-04186	Bracket, Lockout
23	731-04602	Sleeve, .758 x .821 x 3.31	69	747-04521-0637	Ped, Brake
24	731-04604	Sleeve, .758 x .821 x 2.4375	70	936-0119	Washer, Lock, 5/16
25	932-0384	Spring, Extension, .62 Dia x 6.12	71	918-04034	Transmission, Single Speed
26	732-0525	Spring Clip, Shifter	72	683-04055A	Bracket Assembly, Torque
27	732-0716C	Spring, Extension, .59 OD x 4.00	73	683-04130	Bracket, Idler
28	732-0963	Spring, Extension, .50 Dia x 6.37	74	710-0227	Screw, #8-18 x .50
29	936-0169	Washer, Lock, 3/8	75	710-0514	Screw, 3/8-16, 1.00
30	710-0224	Screw, #10-16, .50	76	710-0604A	Screw, 5/16-18, .625
31	738-0372B	Spacer, Shoulder, 1.00 x .38 x .38	77	710-3290	Screw, 3/8-16, 1.12
32	747-04146B	Rod, Shift	78	712-0130	Nut, Lock, 3/8-16, Nylon
33	747-04164	Rod, Brake	79	725-1644	Switch Spring, Short
34	747-1127	Idler Rod, Adjustable, 3/8	80	926-0320	Plate, Insulator
35	948-0334	Spacer, .68	81	750-04294	Spacer, Shoulder
36	750-0566A	Spacer, .260 x .372 x 1.030	82	756-04209	Pulley, V-Type, 3.06
37	954-0467	Belt, V-Type	83	956-04015	Pulley Assembly, Variable Speed
38	954-0468	Belt, V-Type	84	683-04129	Bracket, Pulley
39	956-04002	Pulley, V-Type, 7.25 Dia.	85	710-0627	Screw, 5/16-24, .750
40	756-0981B	Idler Pulley, Flat 2.75 OD	86	710-0642	Screw, 1/4-20, .750
41	783-04224	Bracket, Shift	87	718-04012	Cup, Bearing
42	783-04360	Bracket, Shift, F-N-R	88	736-0362	Washer, Flat
43	783-04442-0637	Idler Bracket, Center Double	89	941-0600	Ball Bearing
44	647-0031B-0637	Control Assembly, Brake	90	736-3010	Washer, Flat, .407 x .812 x .135
45	647-0032A-0637	Control Assembly, Speed	91	936-0242	Washer, Bell, .340 x .872 x .060
46	683-0266	Pedal Assembly			

Model P60RP




Model P60RP

REF. NO.	PART NUMBER	DESCRIPTION
1	732-0614	Ring, Wire
2	916-0231	Ring, E Type, .750
3	936-0336	Flat Washer, 5/8 x 1.0 x .030*
	936-0337	Flat Washer, 5/8 x 1.0 x .040*
	936-0349	Flat Washer, 5/8 x 1.0 x .020*
4	936-0335	Washer, Thrust .635 x 1.26 x .06
5	910-1325	Self-tapping Screw, 1/4-20 x 1.625
6	918-04168	Upper Housing
7	711-1109	Input Shaft
8	941-0335	Needle Bearing, .625 x .813 x .495
9	717-1464	14-tooth Bevel Pinion
10	716-0108	Retaining Ring, .437
11	941-0340	Sleeve Bearing, .75 x 1.0 x 1.0
12	921-0338	Seal, .75 x 1.0 x .125
13	918-04096	Differential Assembly
14	941-0336	Flange Bearing, 5/8 x 3/4 x 3/4
15	917-04056	42-tooth Bevel Gear
16	961-0001	Brake Assembly
17	918-04045	Clutch Collar
18	936-0519	Flat Washer, .70 x 1.125 x .031
19	711-04134	Drive Shaft
20	936-0495	Thrust Washer, 1.0 x .632 x .0
21	941-0337	Flange Bearing, 5/8 x 3/4 x 15/16
22	911-0011	Detent Shaft Assembly
23	741-0862	Detent Ball
24	932-0863	Compression Spring
25	919-04018	Lower Housing
26	917-0678	Brake Puck
27	761-0202	Brake Disc
28	910-1206	Self-tapping Screw, 1/4-20 x 2.375
—	737-0148	Grease

*Use applicable flat washer in this application allowing .0150/.0020 in. end-play

NOTE: If rebuilding the upper housing, include two ounces (2 oz.) of a good quality grease in the input shaft cavity.


Model P60RP



Model P60RP


REF. NO.	PART NUMBER	DESCRIPTION
1	96606	Hook, Retainer
2	918-04126	Spindle Assembly
3	683-0254B-4008	Hanger Bracket Assembly
4	683-04239-4008	Idler Bracket
5	983-04075-4008	Deck Weldment, 50-inch
6	703-3279-4008	Chute Stop
7	710-0347	Screw, 3/8-16, 1.75
8	710-3103	Screw, 5/16-18 x 2.00
9	910-0528	Screw, 5/16-18, 1.25, Gr5
10	910-0599	Screw, 1/4-20 x 0.5
11	910-0726	Screw, 5/16-18 x.625
12	910-1260A	Screw, 5/16-18 x .75
13	710-04095	Screw, 3/8-16 x 1.0
14	910-3178	Screw, Carriage, 3/8-16 x .75
15	936-0300	Washer, Flat, .406 x .875 x .059
16	712-04065	Nut, Nylon Lock, 3/8-16
17	912-0417A	Nut, Hex, Flange, 5/8-18
18	737-04003C	Port, Water
19	912-0431	Nut, Flange Lock, 3/8-16
20	921-04041	Coupler, Hose
21	936-0760	Washer, Lock
22	631-04070	Chute Assembly, Side Discharge
23	914-0470	Pin, Cotter, 1/8 x 1.25
24	912-0641	Nut, Hex, M16-1.5
25	917-04074	Deck Adjustment Gear
26	756-1171	Pulley, 5.39"
27	932-0306A	Spring, Compression, .531 x 1.75
28	732-0459B	Spring, Extension, .94 x 6.74
29	734-04155	Deck Wheel, 5.0
30	734-0973	Deck Wheel, 5.0
31	936-0119	Washer, Lock, 5/16
32	926-0233	Push Nut
33	936-0406	Washer, Flat, .442 x 1.38 x .060
34	937-3000	Fitting, Lube, 3/16
35	938-0373	Shoulder Screw
36	938-3005A	Screw, Shoulder, .68 x 1.59
37	942-04053A	Blade, 17.90
38	747-1116	Rod, Deck Release .375 Dia.
39	783-04415-4008	Deck Skirt, RH
40	954-04077	Belt, V-Type, Aramid
41	756-04129	Pulley, Idler, 3.5"
42	783-04414A-4008	Deck Skirt, Center
43	783-04399-4008	LH Belt Cover
44	783-04400-4008	RH Belt Cover

Model P60RP



REF. NO.	PART NUMBER	DESCRIPTION
1	783-04419B-0637	Bracket, Clutch
2	910-0726	Screw, 5/16-12, .75
3	756-0639A	Pulley, 3.56"
4	710-04379A	Screw, Hex Cap, 7/16-20 x 3.50 GR5
5	936-0171	Washer, Lock, 7/16
6	917-1774B	Clutch, PTO
7	736-0277	Washer, Flat, 1.031 x 1.62 x .095
8	783-04467-0637	Deck Stop

Model P60RP



REF. NO.	PART NUMBER	DESCRIPTION
1	910-0227	Screw, #8-18, 0.500
2	910-0599	Screw, Hex, 1/4-20, 0.500
3	726-0205	Clamp
4	910-1315	Screw, Hex, 3/8-16 x 1.25
5	751-10161	Muffler, Dual Inlet
6	725-0157	Cable, Tie, 3/16 x .05 x 7.4
7	751-10349-16	Fuel Hose, Low Permeation
8	912-3005	Hex Flange Nut, 3/8-16
9	936-0300	Lock Washer, .406 x.875 x.059
10	751-0564B	Deflector, Muffler
11	783-04573-0637	Muffler Bracket, LH
12	783-04574-0637	Muffler Bracket, RH
13	783-04783	Heat Shield
14	951-3140	Drain, Oil
15	751-3141-14	Extension Hose, Oil Drain
16	951-3142	Cap, Oil Drain
17	683-04256-0637	Shield, Muffler
18	751-10007	Pipe, Exhaust, LH
19	751-10006	Pipe, Exhaust, RH
20	728-04000	Rivet, Pop, .188 x .325
21	910-0642	Screw, Hex, 1/4-20, 0.750
22	751-10353	Extension, Deflector