



Seat Adjustment, All Models



Ref.	Part Number	Description
1.	710-1268	Hex Hd. Wshr Screw, #10-16 x .375
2.	712-04063	Flangelock Nut, 5/16-18
3.	712-04064	Flangelock Nut, 1/4-20
4.	720-0309A	Seat Adjustment Grip
5.	726-0201	Speed Nut, .3125
6.	731-04074	Seat Adjustment Spacer
7.	732-0499	Compression Spring, .41 x 1.50
8.	732-1184	Extension Spring, .84 x 4.6
9.	736-0204	Flat Washer, .344 x .62 x .033
10.	736-0242	Bell Washer, .340 x .872 x .060


Ref.	Part Number	Description
11.	736-3019	Flat Washer, .531 x 1.062 x .134
12.	738-0137A	Shoulder Screw, .340 x .285 x 1/4-20
13.	738-0296	Shoulder Screw, .437 x .268 x 5/16-18
14.	738-0966A	Shoulder Bolt, .50 x .925 x 3/8-16
15.	783-0209D	Seat Lift Bracket
16.	783-0611	Seat Adjustment Stop
17.	783-0738D	Seat Pivot Bracket
18.	783-0739A	Seat Adjustment Lever
19.	783-0753	Seat Adjustment Selector




Ref.	Part Number	Description
1.	603-04303E	Frame Assembly
2.	703-05829	Drive Idler Arm
3.	710-0520	Hex Cap Screw, $\frac{3}{8}$ -16 x 1.5
4.	710-3005	Hex Cap Screw, $\frac{3}{8}$ -16 x 1.25
5.	712-04065	Hex Insert Flangelock Nut, $\frac{3}{8}$ -16
6.	732-0626	Extension Spring, .75 x 5.06
7.	736-0300	Flat Washer, .408 x .875 x .059
8.	738-04058	Shoulder Spacer, .39 x 1.0 x .7
9.	738-04162A	Shoulder Spacer, .884 x .19
10.	756-04129	Idler Pulley, 4.25 Dia.
11.	749-04358	Bumper Tube (54")
12.	711-0332	Clevis Pin, .50 x .78 (54")
13.	714-04023	Cotter Pin, .080 x 1.5625 (54")

Front Axle & Wheels

42"




50" & 54"



Ref.	Part Number	Description
1.	603-04370	Castor Wheel Bracket
2.	603-04385	Front Pivot Axle
3.	634-04323A	Wheel Assembly, 13 x 5-6
—	734-04255A	Tire, 13 x 5-6
4.	710-04186	Hex Lock Screw, 1/2-13 x 1.25
5.	710-04652	Hex Cap Screw, 1/2-20 x 7.25
6.	710-0514	Hex Cap Screw, 3/8-16 x 1.0
7.	711-04228	Axle Shaft
8.	712-3058	Hex Insert Lock Nut, 1/2-13
9.	731-05500	Flange Bearing, 1.0 x 1.246
10.	736-0169	Lock Washer, 3/8
11.	736-0227	Flat Washer, .39 x 1.5 x .134


Ref.	Part Number	Description
12.	736-0250	Flat Washer, 1.0 x 1.75 x .10
13.	737-3000	Lube Fitting, 3/16 Drive
14.	750-04775A	Spacer, .51 x .75 x 5.825
15.	750-04792	Hub, .76 x 1.23 x .92
16.	603-04148C	Front Pivot Axle
17.	603-04308	Castor Wheel Bracket
18.	634-04237A	Wheel Assembly, 11.0 x 4.0 x 5.0
19.	712-3022	Hex Lock Nut, 1/2-13 GRB
20.	738-04182A	Shoulder Screw, .75 x 4.75 x 7/16-14
21.	741-0516B	Flange Bearing, .76 x 1.0 x 1.2
22.	741-0990B	Flange Bearing, .76 ID w/Lube Ftg.



Ref.	Part Number	Description
1.	710-0227	Hex Washer Screw, #8-18 x .500
2.	710-0653	Hex Washer Screw, 1/4-20 x .375
3.	710-3015	Hex Screw, 1/4-20 x .75
4.	712-0271	Sems Nut, 1/4-20
5.	725-04022B	Hour Meter
6.	725-04165	Double Pole — Neutral Switch
7.	725-04174	Electric PTO Switch
8.	725-04228	Key Switch
9.	725-04363	Interlock Switch
10.	725-04439	Solenoid

Ref.	Part Number	Description
11.	725-04621A	Wire Harness
12.	725-1303	Outer Seat Spring Switch
13.	725-1439	Inner Seat Spring Switch
14.	725-1737A	Battery, 195 CC Wet
15.	725-1745	Key
16.	726-0278	Insulator Boss Plate
17.	726-0279	Insulator Plate
18.	726-0470	Cable Tie, 19 x 8.39"
19.	738-04237A	Shoulder Screw, #10-32 x .500


Operator's Platform, Small Console



Ref.	Part Number	Description
1.	603-04447A	Seat Frame
2.	603-04564	Console Bracket Assembly
3.	703-05373B	Foot Rest Bracket
4.	703-05894	Battery Hold Down Bracket
5.	703-06451	Console Mounting Bracket
6.	703-06623	Fuel Tank Bracket Support
7.	710-0599	Hex Washer Hd. Screw, 1/4-20 x .500
8.	710-0604A	Hex Washer Hd. Screw, 5/16-18 x .625
9.	710-0726	Hex Washer Hd. Screw, 5/16-12 x .750
10.	710-0778	Hex Wshr. Hd. Screw, 1/4-20 x 1.500
11.	710-0895	Hex Wshr. Hd. Screw, 1/4-15 x .750
12.	710-1260A	Hex Washer Hd. Screw, 5/16-18 x .750
13.	710-1611B	Screw, 5/16-18 x .750 (54")
14.	710-3008	Hex Screw, 5/16-18 x .75

Ref.	Part Number	Description
15.	710-0298	Jam Nut, 1/4-20
16.	712-04063	Flangelock Nut, 5/16-18
17.	712-04092	Speed Nut, 1/4-20
18.	726-3046	Ratchet Clip, .250
19.	731-0511	Trim Strip
20.	731-06478	Console (RH)
21.	731-06479	Console (LH)
22.	732-04035	Compression Spring, 1.28 x 3.125
23.	73504082	Foot Pad
24.	736-0148	External Tooth Lock Washer, 3/8
25.	757-04048	High Back Seat Arms (54")
26.	757-04077	High Back Seat (54")
26.	757-04075	High Back Seat (50")
27.	783-1489C	Seat Mounting Bracket

Operator's Platform, Large Console



Ref.	Part Number	Description
1.	603-04447A	Seat Frame Assembly
2.	703-05373B	Foot Rest Bracket
3.	703-05894	Battery Hold Down Bracket
4.	710-04261	Hex Washer Hd. Screw, #12-16 x .50
5.	710-0599	Hex Washer Hd. Screw, 1/4-20 x .500
6.	710-0604A	Hex Washer Hd. Screw, 5/16-18 x .625
7.	710-0726	Hex Washer Hd. Screw, 5/16-12 x .750
8.	710-0778	Hex Wshr. Hd. Screw, 1/4-20 x 1.500
9.	710-1260A	Hex Wshr. Hd. Screw, 5/16-18 x .750
10.	710-1611B	Hex Screw, 5/16-18 x .750 (A)
11.	712-0298	Jam Nut, 1/4-20
12.	712-04092	Speed Nut, 1/4-20
13.	728-3046	Ratchet Clip, .250


Ref.	Part Number	Description
14.	731-0511	Trim Strip
15.	731-06309	Console (RH) Oyster Gray (A,C)
—	731-04662D	Console (RH) Black (B)
16.	731-06310	Console (LH) Oyster Gray (A,C)
—	731-04663C	Console (LH) Black (B)
17.	732-04035	Compression Spring, 1.28 x 3.125
18.	735-04082	Foot Pad
19.	736-0148	External Tooth Lock Washer, 3/8
20.	757-04040	High Back Seat Arm (A)
21.	757-04077	High Back Seat, Gray (A)
—	757-04075	High Back Seat, Gray (C)
—	757-04041	High Back Seat, Black (B)
22.	783-1489C	Seat Bracket

A — 54" Deck

B — 42" & 50" Deck with Black Console & Seat

C — 42" & 50" Deck with Gray Console & Seat


Mower Deck, 42"



Ref.	Part Number	Description
1.	603-04156	Deck Lift Bracket
2.	603-04335C	Deck Housing
3.	618-0624	Spindle Assembly
4.	703-05824B	Idler Arm
5.	710-0347	Hex Cap Screw, 3/8-16 x 1.75
6.	710-0528	Hex Cap Screw, 5/16-18 x 1.25
7.	710-0599	Hex Washer Head Screw, 1/4-20 x .5
8.	710-1260A	Hex Washer Head Screw, 5/16-18 x .75
9.	710-0726	Hex Washer Head Screw, 5/16-12 x .75
10.	710-0751	Hex Cap Screw, 1/4-20 x .62
11.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
12.	710-3180	Hex Cap Screw, 5/16-18 x 1.75
13.	711-04069	Grass Catcher Pin, 1/4-20
14.	712-0324	Hex Insert Lock Nut, 1/4-20
15.	712-04064	Hex Insert Flange Lock Nut, 1/4-20
16.	712-04065	Hex Insert Flange Lock Nut, 3/8-16
17.	712-0417A	Hex Flange Nut, 5/8-18
18.	712-0429	Hex Insert Lock, 5/16-18
19.	712-0431	Hex Flange Lock Nut, 3/8-16
20.	712-0641	Hex Nut, M16-1.5
21.	712-3010	Hex Nut, 5/16-18
22.	714-0470	Cotter Pin, 1/8 x 1.25
23.	717-04074	Deck Adjustment Gear
24.	721-04041	Water Nozzle Adapter
25.	726-0233	Push Nut, .25 x .5
26.	731-1032B	Discharge Chute Assembly

Ref.	Part Number	Description
27.	731-2231B	Belt Cover
28.	732-0306	Compression Spring
29.	732-0459	Extension Spring, .94 Dia. x 6.74
30.	734-04155	Deck Ball Wheel, 5.0
31.	736-0119	Lock Washer, 5/16
32.	736-0225	Lock Washer
33.	736-3072	Flat Washer, .38 x .93 x .11
34.	737-04003C	Deck Water Nozzle
35.	738-04162A	Shoulder Spacer, .884 x .19
36.	738-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
37.	942-0616A	Blade, 3 in 1, 21.23
38.	747-1116	Deck Hanger Rod
39.	754-04137	V-Belt Type A Sec x 114.1
40.	756-04129	Idler Pulley, 4.25 Dia
41.	783-1146A	Deck Skirt
42.	738-1010A	Spindle Shaft, 5.75
43.	741-0919	Ball Bearing
44.	748-0433	Spacer, .820 x 1.15 x .73
45.	750-1000	Spacer, .8 x 1.10 x 1.322
46.	756-1227	Deck Pulley, 6.3 Dia
47.	731-1032B	Chute Deflector
48.	731-2363	Mulch Plug
49.	710-0134	Carriage Screw, 1/4-20 x .62
50.	712-3087	Wing Nut, 1/4-20
51.	783-1146A	Deck Skirt


Mower Deck, 50"



Ref.	Part Number	Description
1.	603-04328A	Deck Housing
2.	618-04125A	Spindle Assembly
3.	631-04070A	Discharge Chute Assembly
4.	683-0254	Deck Hanger Bracket
5.	703-05825B	Idler Arm
6.	703-3279	Stop Bracket
7.	703-3511A	Finger Guard
8.	710-0347	Hex Cap Screw, 3/8-16 x 1.75
9.	710-0528	Hex Cap Screw, 5/16-18 x 1.25
10.	710-0599	Hex Washer Head Screw, 1/4-20 x .5
11.	710-0726	Hex Washer Head Screw, 5/16-12 x .75
12.	710-1260A	Hex Washer Head Screw, 5/16-18 x .75
13.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
14.	710-3168	Carriage Screw, 3/8-16 x 1.0
15.	710-3178	Carriage Screw, 3/8-16 x .75
16.	712-04065	Hex Insert Flange Lock Nut, 3/8-16
17.	712-0417A	Hex Flange Nut, 5/8-18
18.	712-0431	Hex Flange Lock Nut, 3/8-16
19.	712-0641	Hex Nut, M16-1.5
20.	714-0470	Cotter Pin, 1/8 x 1.25
21.	717-04074	Deck Adjustment Gear
22.	721-04041	Water Nozzle Adapter
23.	732-0306A	Compression Spring
24.	732-0459C	Extension Spring, .94 Dia. x 6.74

Ref.	Part Number	Description
25.	734-04155	Deck Ball Wheel, 5.0
26.	736-0119	Lock Washer, 5/16
27.	736-0407	Bell Washer, .45 x 1.0 x .062
28.	736-0225	Internal Tooth Lock Washer, 5/8
29.	736-3072	Flat Washer, .38 x .93 x .110
30.	737-04003C	Deck Wash Nozzle
31.	738-04162A	Shoulder Spacer, .884 x .190
32.	738-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
33.	742-04053C	Blade, 2 in 1, 17.9
34.	747-1116	Deck Hanger Rod
35.	754-04044A	V-Belt Type A Sec x 134
36.	756-04129	Idler Pulley, 4.25 Dia
37.	783-04399	Belt Cover, LH
38.	783-04400	Belt Cover, RH
39.	783-04414	Center Skirt
40.	783-04415	Skirt RH
41.	750-1000	Spacer, .80 x 1.10 x 1.32
42.	750-1349A	Spacer, .79 x 1.82 x .55
43.	756-04216	V-Type Pulley, 5.39
44.	736-0315	Flat Washer, .76 x 1.50 x .12
45.	738-1010A	Spindle Shaft, 5.75
46.	741-0919	Ball Bearing
47.	748-0160A	Spacer, .79 x 1.25 x .175
48.	731-04651	Mulch Plug


Mower Deck, 54"



Ref.	Part Number	Description
1.	16606	Retainer Bracket
2.	603-04367A	Deck Housing
3.	603-04386A	Idler Assembly
4.	618-04608	Spindle Assembly
5.	631-04070A	Discharge Chute Assembly
6.	638-04012A	Shoulder Bolt Assembly
7.	683-0254B	Deck Hanger Bracket
8.	703-2093	Rear Inner Baffle
9.	703-3279	Stop Bracket
10.	703-3511	Finger Guard
11.	748-0160A	Spacer, .79 x 1.25 x .175
12.	710-0347	Hex Cap Screw, 3/8-16 x 1.75
13.	710-0521	Hex Cap Screw, 3/8-16 x 3.0
14.	710-0528	Hex Cap Screw, 5/16-18 x 1.25
15.	710-0599	Hex Washer Head Screw, 1/4-20 x .5
16.	710-0607	Hex Washer Head Screw, 5/16-18 x .5
17.	710-0623	Hex Washer Head Screw, 3/8-16 x .75
18.	710-0650	Hex Washer Head Screw, 5/16-18 x .875
19.	710-1260A	Hex Washer Head Screw, 5/16-18 x .75
20.	710-3168	Carriage Screw, 3/8-16 x 1.0
21.	710-3178	Carriage Screw, 3/8-16 x .75
22.	711-1737	Roller Pin, .5 x 10.06
23.	712-0290	Hex Lock Nut, 7/16-14
24.	712-04065	Hex Insert Flange Lock Nut, 3/8-16
25.	712-0417A	Hex Flange Nut, 5/8-18
26.	712-0431	Hex Flange Lock Nut, 3/8-16
27.	712-0641	Hex Nut, M16-1.5
28.	714-0111	Cotter Pin, 3/32 x 1.0
29.	714-0162	Cotter Pin, 5/32 x 1.25
30.	714-0470	Cotter Pin, 1/8 x 1.25
31.	717-1553B	Deck Adjustment Gear
32.	721-04041	Water Nozzle Adapter

Ref.	Part Number	Description
33.	731-05825	Deck Roller, 7.895
34.	731-05679	Front Roller
35.	732-0306A	Compression Spring
36.	732-0850	Extension Spring, 1.0 x 6.140
37.	734-04155	Deck Ball Wheel, 5.0
38.	736-0119	Lock Washer, 5/16
39.	736-0275	Flat Washer, .344 x .688 x .065
40.	736-0406	Flat Washer, .442 x 1.39 x .06
41.	736-0407	Bell Washer, .45 x 1.0 x .062
42.	736-0760	Lock Washer
43.	736-3010	Flat Washer, .407 x .812 x .135
44.	736-3072	Flat Washer, .38 x .93 x .110
45.	737-04003C	Deck Wash Nozzle
46.	738-04260	Shaft, .75 x 26.893
47.	738-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
48.	742-0677B	Blade, 18.5
49.	747-1116	Deck Hanger Rod
50.	750-0151	Spacer, .55 x .75 x 1.125
51.	750-0212	Spacer, .82 x 1.0 x .53
52.	750-04597	Spacer, .38 x .9 x 1.313
53.	754-04138A	V-Belt Type B Sec x 143
54.	756-04129	Idler Pulley, 4.25 Dia
55.	783-04690B	Deck Skirt
56.	783-04726	Stationary Idler Bracket
57.	783-1470A	Belt Cover
58.	783-1471	Belt Cover
59.	750-1000	Spacer, .80 x 1.10 x 1.32
60.	750-1349A	Spacer, .79 x 1.82 x .55
61.	756-04216	V-Type Pulley, 5.39
62.	738-1197	Spindle Shaft, 6.95
63.	741-0919	Ball Bearing


Engine Connections, 3 Gallon Tank 42"



Ref.	Part Number	Description
1.	603-04176A	Exhaust Tube
2.	703-05441A	Muffler Mounting Bracket
3.	703-05870	Muffler Tube Heat Shield
4.	710-0227	Hex Wsh. Hd. Screw, #8-18 x .5
5.	710-04261	Hx. Wsh. Hd. Screw, #12-16 x .5
6.	710-0599	Hx. Wsh. Hd. Screw, 1/4-20 x .5
7.	710-0726	Hx. Wsh. Hd. Screw, 5/16-12 x .75
8.	756-0978B	Drive Pulley
9.	710-1315	Hx. Wsh. Hd. Screw, 3/8-16 x 1.25
10.	710-3008	Hex Cap Screw, 5/16-18 x .75
11.	710-3157A	Hx Cap Lk. Screw, 7/16-20 x 3.25
12.	710-3217	Truss Hd. Mach. Screw, #8-32 x .375
13.	712-0142	Hex Nut, #8-32
14.	712-0271	Hex Sems Nut, 1/4-20
15.	712-04063	Hx. Insert Flange Lck Nut, 5/16-18
16.	717-04376	Electric PTO Clutch Assembly

Ref.	Part Number	Description
17.	721-0208	Exhaust Gasket (B&S- 272293)
18.	726-0205	Hose Clamp
19.	731-04914	Throttle Control Knob
20.	736-0148	Ext. Tooth Lock Washer, 3/8
21.	736-0171	Lock Washer, 7/16
22.	736-3008	Flat Washer, .344 x .75 x .12
23.	737-0125	Elbow Fitting
24.	746-04161	Throttle Cable, 39.0 Lg
25.	747-04228A	Tank Mounting Wire
26.	751-0564B	Muffler Deflector
27.	751-0617B	Muffler
28.	751-10057D	Fuel Tank, 3.0 Gal.
29.	751-10349	Fuel Line Hose
30.	751-3124D	Fuel Cap
31.	751-10517	Oil Drain Valve
32.	751-3141	Oil Drain Extension Hose


Engine Connections, 3 Gallon Tank 50" & 54"



Ref.	Part Number	Description
1.	603-04162	Exhaust Tube (RH)
2.	603-04163	Exhaust Tube (RH)
3.	703-05441A	Muffler Mounting Bracket
4.	710-0227	Hex Wash. Hd. Screw #8-18 x .5
5.	710-04248	Hex Cap Screw, 7/16-20 x 4.0
6.	710-04261	Hex Wash. Hd. Screw, #12-16 x .5
7.	710-0599	Hex Wash. Hd. Screw, 1/4-20 x .5
8.	710-0726	Hex Wash. Hd. Screw, 5/16-12 x .75
9.	710-1314A	Socket Hd. Screw, 5/16-18 x .75
10.	710-1315	Hex Wash. Hd. Screw, 3/8-16 x 1.25
11.	710-3008	Hex Cap Screw, 5/16-18 x .75
12.	710-3217	Truss Hd. Mach. Screw, #8-32 x .375
13.	712-0142	Hex Nut, #8-32
14.	712-0271	Sems Nut, 1/4-20
15.	712-04063	Hx Insert Flng. Lck. Nut, 5/16-18
16.	712-3005	Hex Jam Nut, 3/8-16
17.	717-04552	Elec. PTO Clutch Ass. (50" Deck)
—	717-1774C	Elec. PTO Clutch Ass. (54" Deck)
18.	721-0460	Exhaust Gasket


Ref.	Part Number	Description
19.	726-0197	Cable Tie
20.	726-0205	Hose Clamp
21.	731-04914	Throttle Control Knob
22.	736-0148	Ext. Tooth Lock Washer, 3/8
23.	736-0171	Lock Washer, 7/16
24.	736-0300	Flat Washer, .406 x .875 x .059
25.	736-04131	Flat Washer, .438 x 1.75 x .25
26.	746-04214	Choke Cable, 61Lg
27.	746-1086	Throttle Cable, 39.0 Lg
28.	747-04228A	Tank Mounting Wire
29.	751-0564B	Muffler Deflector
30.	751-0616B	Muffler
31.	751-10057C	Fuel Tank, 3.0 Gal.
32.	751-10349	Fuel Line Hose
33.	751-3124B	Fuel Cap
34.	751-10517	Oil Drain Valve
35.	751-3141-14	Oil Drain Extension Hose
36.	751-3142	Oil Drain Valve Cap
37.	756-0978B	Drive Pulley

Engine Connections, 3.5 Gallon Tank



Ref.	Part Number	Description
1.	603-04162	Exhaust Tube (RH)
2.	603-04163	Exhaust tube (LH)
3.	751-10692	Fuel Tank, 3.5 Gallon
4.	703-05441A	Muffler Bracket
5.	710-0227	Hex Washer Hd. Screw, #8-18 x .500
6.	710-04261	Hex Washer Hd. Screw #12-16 x .50
7.	710-04379A	Hex Screw, 7/16-20 x 3.50
8.	710-0599	Hex Washer Hd. Screw, 1/4-20 x .500
9.	710-1315	Hex Wshr. Hd. Screw, 3/8-16 x 1.250
10.	710-3008	Hex Screw, 5/16-18 x .75
11.	710-3217	Machine Screw, #8-32 x .375
12.	712-0142	Hex Nut, #8-32
13.	712-0271	Sems Nut, 1/4-20
14.	712-04063	Flange Lock Nut, 5/16-18
15.	712-3005	Flange Lock Nut, 3/8-16
16.	717-04552	Electric PTO Clutch Ass. (50" Deck)
—	717-1774C	Electric PTO Clutch Ass. (54" Deck)
17.	751-10703	Fuel Cap


Ref.	Part Number	Description
18.	721-0460	Exhaust Gasket
19.	726-0197	Cable Tie
20.	726-0205	Hose Clamp, .490
21.	731-04914	Throttle Control Knob
22.	736-0148	External Tooth Lock Washer, 3/8
23.	736-0171	Lock Washer, 7/16
24.	736-0277	Flat Washer, 1.031 x 1.620 x .095
25.	736-0300	Flat Washer, .406 x .875 x .059
26.	746-04214	Choke Cable, 61.0 Lg
27.	746-1086	Throttle Cable, .39 Lg x .62
28.	751-0564B	Muffler Deflector
29.	751-0616B	Dual Inlet Muffler
30.	751-10349	Low Permeation Fuel Hose, 1/4
31.	751-10517	Oil Drain
32.	751-3141	Oil Drain Extension Hose
33.	756-0978B	Engine Pulley
34.	751-10442	Fuel Pickup Fitting
35.	735-0149	Fuel Tank Bushing



Ref.	Part Number	Description
1.	618-04317	Wheel Hub
2.	618-04431A	Transmission Assembly (LH)
3.	618-04432A	Transmission Assembly (RH)
4A.	634-04294	Wheel Assembly (42"), 18 x 6.5 x 8
—	734-04246	Tire (42"), 18 x 6.5 x 8
—	734-0255	Valve Assembly, (42")
4B.	634-04171	Wheel Assembly (50"), 18 x 9.5 x 8
—	734-1729	Tire (50"), 18 x 9.5 x 8
—	603-04175	Rim Assembly (50")
—	734-0255	Valve Assembly (50")
5.	710-0176	Hex Cap Screw, 5/16-18 x 2.75

Ref.	Part Number	Description
6.	710-0395	Hex Cap Screw, 5/16-18 x 2.25
7.	710-3119	Hex Cap Screw Lock, 3/8-16 x .75
8.	712-04063	Hx Flange Insert Lck Nut, 5/16-18
9.	712-0459	Hex Flange Lock Nut, 7/16-20
10.	712-3050	Lug Nut, 7/16-14
11.	714-0507	Cotter Pin, 3/32 x .75
12.	736-0227	Flat Washer, .39 x 1.5 .134
13.	738-04192	Rod, .405 x 14.0
14.	747-04217C	Bypass Rod
15.	750-04561	Tube, .45 x .69 x 10.2
16.	754-04043	Type A Sec V-Belt x 57.7

Rear Drive & Wheels, 54"




Ref.	Part Number	Description
1.	618-04464	Transmission Assembly (RH)
2.	618-04465	Transmission Assembly (LH)
3.	618-04466	Breather
4.	631-04223	Expansion Tank Assembly
5.	634-0246A	Rim Assembly, 8.0 x 6.19 x 4
—	734-1873	Tire, 20 x 10 x 8
—	734-0255	Air Valve
6.	703-05938	Expansion Tank Bracket
7.	703-05940	Transmission Brace (LH)
8.	703-05941	Transmission Brace (RH)
9.	703-05989	Transmission Spacer
10.	710-0176	Hex Screw, $\frac{5}{16}$ -18 x 2.75
11.	710-0189	Hex Screw, $\frac{5}{16}$ -18 x 3.00
12.	710-0599	Screw, $\frac{1}{4}$ -20 x .500
13.	710-0788	Screw, $\frac{1}{4}$ -20 x 1.000
14.	711-1530	Ferrule, .325 x .312

Ref.	Part Number	Description
15.	712-04063	Flangelock Nut, $\frac{5}{16}$ -18
16.	712-04065	Flangelock Nut, $\frac{3}{8}$ -16
17.	712-04092	Speed Nut, $\frac{1}{4}$ -20
18.	712-3050	Lug Nut, $\frac{7}{16}$ -14
19.	714-0104	Cotter Pin, .072 x 1.13
20.	726-04059	Hose Clamp, .750
21.	731-05785	Cap, $\frac{1}{2}$ x .870
22.	732-0335	Compression Spring, .405 x 1.17
23.	732-04434	Extension Spring, .545 x 4.555
24.	736-04267	Flat Washer, .35 x 1.0 x .2
25.	738-04251	Rod, .337 x 14.75
26.	747-04636	Bypass Rod
27.	750-04759A	Tube, $\frac{7}{16}$ x $\frac{3}{4}$ x 11.3
28.	751-10511	Straight Fitting, $\frac{1}{16}$ x $\frac{1}{2}$
29.	754-04043A	V-Type Belt, 57.7

[illegible]

Operator's Control, All Models




Ref.	Part Number	Description
1.	603-04160B	Deck Lift Shift Assembly
2.	603-04322	Lapbar Lever Assembly (RH)
3.	603-04324	Lapbar Lever Assembly (LH)
4.	703-05387B	Lapbar Pivot Bracket
5.	703-05396A	Brake Handle
6.	703-05414A	Front Deck Hanger Bracket
7.	703-05793A	Deck Lift Arm Plate
8.	703-06096	Switch Actuator Bracket
9.	703-06169	Lift Link Plate, 5.50 Lg
10.	710-0433	Hex Lock Screw, ¼-20 x .625
11.	710-3005	Hex Screw, ⅜-16 x 1.25
12.	710-3008	Hex Screw, ⅝-18 x .75
13.	710-3180	Hex Screw, ⅝-18 x 1.75
14.	711-0832	Ferrule, ⅜-24 x .375
15.	712-0206	Hex Nut, ½-13
16.	712-04063	Flange Lock Nut, ⅝-18
17.	712-04064	Flange Lock Nut, ¼-20
18.	712-04065	Flange Lock Nut, ⅜-16
19.	712-0431	Flange Lock Nut, ⅜-16
20.	714-0104	Cotter Pin, .072 x 1.13
21.	716-0106	E-Ring, .625
22.	720-0274	Grip, 1.0 x 5.0
23.	720-0311	Handle Grip, ½

Ref.	Part Number	Description
24.	731-04735	Selector Handle
25.	731-05732	Spacer, .62 x 1.00
26.	732-0334	Compression Spring, .50 x .50
27.	732-04420	Torsion Spring, 1.194 (50" & 54")
28.	732-04432	Extension Spring, .59 x 4.00 (54")
29.	732-0874	Torsion Spring
30.	736-0270	Bell Washer, .265 x .75 x .062
31.	736-0272	Flat Washer, .510 x 1.00 x .060
32.	736-0275	Flat Washer, .344 x .688 x .065
33.	736-3019	Flat Washer, .531 x 1.062 x .134
34.	738-0143	Shoulder Screw, .496 x .336 x ⅜-16
35.	738-0296	Shoulder Screw, .437 x .268 x ⅝-18
36.	738-0507B	Shoulder Screw, .500 x .434
37.	738-0572	Shoulder Screw, .374 x 1.16
38.	741-0225	Hex Flange Bearing
39.	741-3074	Flange Bearing, .626 x .938 x .344
40.	747-04225A	Lapbar Control Rod
41.	747-04226	Shaft Control
42.	747-04401A	Deck Lift Front Hanger Rod
43.	747-04637	Deck Lift Handle Rod
44.	747-04651	Brake Rod (54")
45.	748-04169	Control Hub
46.	748-04169	Brake Rod Assembly (42" & 50")

REV	DATE	DESCRIPTION	DATE	BY
01	06/02/2008	RELEASED FOR 001C	06/02/2008	MD/SMAY
02	07/10/2008	RELEASED FOR 100LINS	07/10/2008	MD/SMAY
03	09/22/2008	SEAT SWITCH LENGTH #45 19.500"	09/22/2008	MD/SMAY
03	09/22/2008	ECO 34157	09/22/2008	MD/SMAY
03	09/22/2008	ECO 34157	09/22/2008	MD/SMAY

WIRING CONNECTION	PIN	FUNCTION
1	1	PTO LIGHT
2	2	PTO LIGHT
3	3	PTO LIGHT
4	4	PTO LIGHT
5	5	COMMON (GND)
6	6	COMMON (GND)
7	7	COMMON (GND)
8	8	COMMON (GND)
9	9	COMMON (GND)

ENGINE CONNECTION	PIN	FUNCTION
1	1	ENGINE ON
2	2	ENGINE ON
3	3	ENGINE ON
4	4	ENGINE ON
5	5	ENGINE ON
6	6	ENGINE ON



PRODUCTION	REV	DATE	DESCRIPTION	DATE	BY
01	06/02/2008	06/02/2008	RELEASED FOR 001C	06/02/2008	MD/SMAY
02	07/10/2008	07/10/2008	RELEASED FOR 100LINS	07/10/2008	MD/SMAY
03	09/22/2008	09/22/2008	SEAT SWITCH LENGTH #45 19.500"	09/22/2008	MD/SMAY
03	09/22/2008	09/22/2008	ECO 34157	09/22/2008	MD/SMAY
03	09/22/2008	09/22/2008	ECO 34157	09/22/2008	MD/SMAY

- NOTES:
1. SEAT SWITCH SHOWN W/ OPERATOR PRESENT NORMALLY CLOSED HELD OPEN - NCHOI.
 2. NEUTRAL SWITCHES SHOWN W/ UNIT IN NEUTRAL POSITION 1104 NCHOI 3/2-NCHOI.
 3. NEUTRAL SWITCHES SHOWN W/ UNIT IN REVERSE POSITION 1104 NCHOI 3/2-NCHOI.
 4. PTO SWITCH SHOWN IN OFF POSITION 13/9-NC,2/5-NO,1/4-NOI.
 5. BRAKE SWITCH SHOWN IN OFF POSITION.
 6. WITH NUMBER REPRESENTS ITEM REFERENCED ON SHEET 1 OF DRAWING.