



Model E18J



Ref No.	Part Number	Description
1	787-01629	19" Deck
2	687-02415	Transmission Support Bearing
3	710-1241	Screw, 1/4-15 x 1.000
4	710-04744	Screw, HL, #12-16 x 1.00
5	749-04556	Lower Handle
6	931-04462	Engine Shroud
7	710-0654A	Screw, 3/8-16 x 1.00
8	687-02555	Blade Adapter
9	942-0739	Mulching Blade
10	736-0524B	Blade Bell Support
11	710-1044	Screw, 3/8-24 x 1.50
12	731-05639A	Trailing Shield
13	731-05746	Rear Mulch Plug
14	731-04177	Side Discharge Chute
15	987-02055	Mulch Plug (Incl. 16-18)
16	732-1014	Torsion Spring
17	747-0710	Hinge Pin
18	17032A	Chute Deflector Adapter
19	736-0270	Belleville Washer
20	710-0599	Screw
21	931-05686	Rear Door
22	931-05634	Front Cover
23	687-02323-0637	Handle Bracket - RH
	687-02322-0637	Handle Bracket - LH
24	964-04134	Grass Bag
25	647-04082-0637	Grass Bag Frame
26	687-02225-0637	Front Bracket Assembly
27	936-0369	Washer, Flat, .508 x 1.00 x .020
28	687-02304-0637	Self Propelled Bracket Ass'y
29	710-3025	Hhcs, 5/16-18 x .625
30	710-1242	Screw, 5/16-14 x .750
31	712-04063	Nut, Flange Lock, 5/16-18
32	712-04065	Nut, Flange Lock, 3/8-16
33	734-1988	Front Wheel
34	634-04363	Rear Wheel
35	720-04096	Knob
36	732-04650	Wave Spring
37	749-04550	Upper Handle
38	736-0242	Washer, Bell, .340 x .872 x .060
39	720-0279	Knob
40	725-0157	Cable Tie

Ref No.	Part Number	Description
41	710-1205	Rope Guide
42	710-0779A	Screw, #10-16 x .500
43	746-04523	Control Cable
44	747-04995	Blade Control
45	710-1174	Bolt Carriage, 5/16-18 x 2.0
46	720-04072A	Star Knob
47	731-06190	Rear Baffle
48	732-04534	Door Torsion Spring - RH
	732-04535	Door Torsion Spring - LH
49	732-04338C	Spring Lever
50	726-0101	Nut, Spd
51	736-04413	Wshr, Wave, .385 ID x .598 OD
52	954-04158	V-Belt
53	741-0492A	Bushing, Lock, .505 Dia. X .62
54	747-04589	Rear Door Pivot Rod
55	749-04307-0637	Cross Bracket
56	738-04278	Scr., Shldr., 1/4-20 x .50
57	731-06974	Wheel Dust Cover
58	946-04519B	Drive Cable
59	735-04059	Grommet
60	747-04994A	Drive Control
61	918-04463A	Transmission
62	710-04531	Screw, 1/4-20 x .390
63	915-0221	Dowel Pin
64	716-0198	Retainer Ring
65	917-04192C	Spur Gear - RH
	917-04184C	Spur Gear - LH
66	731-05872	Spacer, Clip
67	731-06164	Engine Baffle
68	932-04262	Exten. Spring, .429OD x 2.515
69	748-0390	Bearing Support Spacer
70	750-04870	Sleeve Spacer, .550ID x .340 Lg.
71	750-04853	Sleeve Spacer, .550ID x 7.97 Lg.
72	725-04329	Battery Charger
73	925-04072	Electric Start Harness Assembly
74	925-04347	Key Switch
75	710-1667A	Screw, #10-16 x .750
76	925-0201	Key
77	925-04323	Battery
78	728-0199	Rivet


Model 18M



Ref No.	Part Number	Description
1	787-01629	19" Deck
2	687-02415	Transmission Support Bearing
3	710-1241	Screw, 1/4-15 x 1.000
4	710-04744	Screw, HL, #12-16 x 1.00
5	749-04556	Lower Handle
6	931-04462	Engine Shroud
7	710-0654A	Screw, 3/8-16 x 1.00
8	687-02555	Blade Adapter
9	942-0739	Mulching Blade
10	736-0524B	Blade Bell Support
11	710-1044	Screw, 3/8-24 x 1.50
12	731-05639A	Trailing Shield
13	731-05746	Rear Mulch Plug
14	731-04177	Side Discharge Chute
15	987-02055	Mulch Plug (Incl. 16-18)
16	732-1014	Torsion Spring
17	747-0710	Hinge Pin
18	17032A	Chute Deflector Adapter
19	736-0270	Belleville Washer
20	710-0599	Screw
21	931-05686	Rear Door
22	931-05634	Front Cover
23	687-02323-0637	Handle Bracket - RH
	687-02322-0637	Handle Bracket - LH
24	964-04134	Grass Bag
25	647-04082-0637	Grass Bag Frame
26	687-02225-0637	Front Bracket Assembly
27	936-0369	Washer, Flat, .508 x 1.00 x .020
28	687-02304-0637	Self Propelled Bracket Ass'y
29	710-3025	Hhcs, 5/16-18 x .625
30	710-1242	Screw, 5/16-14 x .750
31	712-04063	Nut, Flange Lock, 5/16-18
32	712-04065	Nut, Flange Lock, 3/8-16
33	734-1988	Front Wheel
34	634-04363	Rear Wheel
35	720-04096	Knob
36	732-04650	Wave Spring

Ref No.	Part Number	Description
37	749-04550	Upper Handle
38	736-0242	Washer, Bell, .340 x .872 x .060
39	720-0279	Knob
40	725-0157	Cable Tie
41	710-1205	Rope Guide
42	710-0779A	Screw, #10-16 x .500
43	946-04637	Control Cable
44	747-04995	Blade Control
45	710-1174	Bolt Carriage, 5/16-18 x 2.0
46	720-04072A	Star Knob
47	731-06190	Rear Baffle
48	732-04534	Door Torsion Spring - RH
	732-04535	Door Torsion Spring - LH
49	732-04338C	Spring Lever
50	726-0101	Nut, Spd
51	736-04413	Wshr, Wave, .385 ID x .598 OD
52	954-04158	V-Belt
53	741-0492A	Bushing, Lock, .505 Dia. X .62
54	747-04589	Rear Door Pivot Rod
55	749-04307-0637	Cross Bracket
56	738-04278	Scr., Shldr., 1/4-20 x .50
57	731-06974	Wheel Dust Cover
58	946-04519B	Drive Cable
59	735-04059	Grommet
60	747-04994A	Drive Control
61	918-04463A	Transmission
62	710-04531	Screw, 1/4-20 x .390
63	915-0221	Dowel Pin
64	716-0198	Retainer Ring
65	917-04192C	Spur Gear - RH
	917-04184C	Spur Gear - LH
66	731-05872	Spacer, Clip
67	731-06164	Engine Baffle
68	932-04262	Exten. Spring, .429OD x 2.515
69	748-0390	Bearing Support Spacer
70	750-04870	Sleeve Spacer, .550ID x .340 Lg.
71	750-04853	Sleeve Spacer, .550ID x 7.97 Lg.

Model Series 260




Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-1113	Control Cable - 37.75"
	746-1114	Control Cable - 50.56"
4.	946-04204	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	748-0390	Bearing Support Spacer
9.	732-1026	Spring Lever
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	631-04045	Mulching Baffle
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51
31.	731-0073	Transmission Cover

Ref No.	Part Number	Description
	931-04636	Transmission Cover (Yellow)
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	736-0524B	Blade Bell Support
35.	710-1044	Hex Cap Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	710-04531	Screw, 1/4-20 x .390
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	734-1987	Rear Wheel, 8 x 1.8, Bar
	734-04087	Rear Wheel, 8 x 1.8, Bar, Yellow
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel, 8 x 1.8, Bar
	634-04100	Front Wheel, 8 x 1.8, Bar, Yellow
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	731-0981C†	Hub Cap
57.	731-2626†	Deluxe Bail Cover
58.	936-0504†	Washer, Wave, .510 x .750 x .017

† If Equipped


Model 26J



Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-04300	Blade Control Cable
4.	746-04304	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	710-0606	Hex Screw, 1/4-20 x 1.50
9.	731-06749	Cable Mount
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	712-04064	Flange Lock Nut, 1/4-20
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51

Ref No.	Part Number	Description
31.	731-0073	Transmission Cover
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	732-1026	Spring Lever
35.	710-1044	Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	736-0524B	Blade Bell Support
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	631-04045	Mulch Plug
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	710-04531	Screw, 1/4-20 x .390
57.	734-1987	Rear Wheel
58.	748-0390	Bearing Support Spacer


Model 26M



Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-04300	Blade Control Cable
4.	746-04304	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	710-0606	Hex Screw, 1/4-20 x 1.50
9.	946-04295A	Choke Cable
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	712-04064	Flange Lock Nut, 1/4-20
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51
31.	731-0073	Transmission Cover

Ref No.	Part Number	Description
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	732-1026	Spring Lever
35.	710-1044	Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	736-0524B	Blade Bell Support
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	631-04045	Mulch Plug
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	710-04531	Screw, 1/4-20 x .390
57.	734-1987	Rear Wheel
58.	748-0390	Bearing Support Spacer
59.	710-04744	Screw, #12-16 x 1.00
60.	631-04437	Engine Shroud


Model Series 460



Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1092A-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	746-1132	Control Cable - 40.75"
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	787-01593	Engine Baffle Bracket
19	926-0240	Cable Tie
20	731-05642A	Rear Trailing Shield
21	710-0654A	Self-Tapping Sems Screw
22	946-04203	Drive Cable
23	964-04007A	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16

Ref No.	Part Number	Description
35	931-05013A	Transmission Cover
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	936-0447	Wave Washer
39	750-04594	Sleeve Spacer 8.985" Lg.
40	987-02221	Blade Adapter, 25mm
41	942-0741A	21" Mulching Blade
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
57	915-0221	Dowel Pin
58	736-0474	Washer
59	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
60	732-04175	Rear Spring Lever
61	738-04266	Shoulder Scr.500 Dia. x.434
62	734-1987	Rear Wheel
63	753-06116	Engine Baffle
64	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
65	747-04587	Pivot Rod

Model E46J




Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1233D-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	946-04589	Control Cable
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	731-06749	Control Cable Mount
19	926-0240	Cable Tie
20	710-04744	Screw, HL, #12-16 x 1.00
21	710-0654A	Self-Tapping Sems Screw
22	946-04303	Drive Cable
23	964-04128	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16
35	931-05013A	Transmission Cover
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	936-0447	Wave Washer
39	750-04594	Sleeve Spacer 8.985" Lg.
40	687-02195A	One Piece Blade Adapter
41	942-0741A	21" Mulching Blade

Ref No.	Part Number	Description
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
57	915-0221	Dowel Pin
58	736-0474	Washer
59	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
60	732-04175	Rear Spring Lever
61	738-04266	Shoulder Scr.500 Dia. x.434
62	734-1987	Rear Wheel
63	712-04064	Nut, FlgIk, 1/4-20
64	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
65	747-04587	Pivot Rod
66	731-05642A	Rear Trailing Shield
67	753-06116	Engine Baffle
68	787-01593	Engine Baffle Bracket
69	631-04440	Engine Shroud
70	725-04329	Battery Charger
	791-182534†	Battery Charger (w/LED Light)
71	925-04072	Electric Start Harness Ass'y.
72	925-04347	Key Switch
73	710-1667A	Screw, #10-16 x .750
74	925-0201	Key
75	925-04323	Battery
76	728-0199	Rivet
77	710-0606	Screw, 1/4-20 x 1.50

† If Equipped


Model Series 560



Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1092A-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	746-1132	Control Cable - 40.75"
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	936-0447	Wave Washer, 1.5 x 1.0 x .029
19	926-0240	Cable Tie
20	914-0104	Cotter Pin
21	710-0654A	Self-Tapping Sems Screw
22	946-04203	Drive Cable
23	964-04007A	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16
35	931-05013A	Transmission Cover

Ref No.	Part Number	Description
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	753-06116	Engine Baffle
39	750-04594	Sleeve Spacer 8.985" Lg.
40	987-02221	Blade Adapter Assembly
41	942-0741A	21" Mulching Blade
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02280A	Handle Bracket Assembly - LH
	987-02279A	Handle Bracket Assembly - RH
57	915-0221	Dowel Pin
58	736-0474	Washer, Flat, 1.01 x 1.50 x .035
59	987-02335	Pivot Arm Assembly - RH
	987-02336	Pivot Arm Assembly - LH
60	732-0866	Rear Spring Lever
61	720-0312	Foam Grip
62	738-04266	Shoulder Scr.500 Dia. x.434
63	734-04082	Rear Wheel
64	787-01593	Engine Baffle Bracket
65	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
66	747-04588	Pivot Rod
67	731-05642A	Rear Trailing Shield

Model Series V560




Ref No.	Part Number	Description
1	946-04206A	Variable Speed Cable
2	731-04150C	Rear Baffle 21" Rd.
3	710-1241	Screw, 1/4-15 x 1.000
4	732-04317	Extension Spring
5	747-1161A-0637	Blade Control
6	749-04206B-0637	Upper Handle
7	787-01258A-0637	Cable Mount Bracket
8	753-06060	Control Lever Assembly
9	720-0279	Handle Knob
10	720-04072A	Star Knob
11	710-1205	Eye Bolt
12	946-1130	Control Cable - 40"
	946-04589	Control Cable - 37.25" (Kohler)
13	710-1174	Carriage Bolt, 5/16-18 x 2.0
14	926-0240	Cable Tie
15	914-0104	Cotter Pin
16	912-0397	Wing Nut
17	964-04007A	Grass Bag
18	747-04080A-0637	Grass Bag Frame
19	736-0524B	Blade Bell Support
20	731-05642A	Rear Trailing Shield

Ref No.	Part Number	Description
21	731-06847	Rear Discharge Door
22	710-0703	Carriage Bolt, 1/4-20
23	732-04090A	Torsion Spring - RH
24	747-04588	Pivot Rod
25	931-05013A	Transmission Cover
26	710-1650	Shoulder Screw, # 12 -24
27	753-06116	Engine Baffle
28	749-0928A-0637	Lower Handle
29	954-04082A	V-Belt
30	731-04177	Side Discharge Chute
31	710-04329	Torx Screw
32	787-01593	Baffle Bracket
33	687-02195A	Blade Adapter Assembly
34	942-0741A	21" Mulching Blade
35	732-04294	Belt Keeper Wire
36	710-0896	Scr., 1/4-14 x.625
37	710-1257	Hex Screw, 3/8-24 x 2.50
38	710-0106†	Hhcs, 1/4-20 x 1.50
39	712-04064†	Nut, Flglk, 1/4-20
40	731-06749†	Mount, Cable
41	731-04859†	Bail Cover

† If Equipped

Model Series V560




Ref No.	Part Number	Description
1	750-04405	Slev. Spacer, 1.8" Lg.
2	750-04404	Slev. Spacer, 9.10" Lg.
3	710-0654A	TT Screw
4	787-01278	21" Deck
5	710-0599	TT Screw, 1/4-20 x 0.5
6	736-0270	Bell Washer
7	987-02055	Hinged Mulch Plug Assembly
8	17032A	Chute Deflector Adapter
9	732-1014	Torsion Spring
10	747-0710	Hinge Pin
11	918-04377B	Transmission Assembly
12	987-02193A	Height Adj. Assembly - LH
	987-02194A	Height Adj. Assembly - RH
13	987-02280A	Handle Bracket Assembly - LH
	987-02279A	Handle Bracket Assembly - RH
14	987-02334	Pivot Plate Assembly
15	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
16	782-5002B	Front Baffle
17	712-04065	Flange Lock Nut, 3/8-16
18	734-2042A	Front Wheel, 8 x 2.125

Ref No.	Part Number	Description
19	734-04093	Rear Wheel, 12 x 2.125, Gray
	734-04046	Rear Wheel, 12 x 2.125, Yellow
20	710-04531	Screw, 1/4-20 x .390
21	717-1762	Gear 14T FWD - RH
	717-1761	Gear 14T FWD - LH
22	915-0221	Dowel Pin
23	782-7551A	Wheel Dust Cap
24	916-0102	Snap Ring
25	736-0474	Flat Washer
26	710-0216	Hex Screw, 3/8-16 x .75
27	936-0447	Wave Washer
28	987-02347	Bearing Assembly
29	720-0426	Adjustment Knob
30	710-1652	TT Screw w/washer, 1/4-20 x .625
31	738-04266	Shoulder Screw, .500 Dia. x .385
32	987-02335	Pivot Arm Assembly - RH
	987-02336	Pivot Arm Assembly - LH
33	732-0866	Rear Spring Lever
34	720-0312	Foam Grip
35	736-0182	Washer, Spring, .500 x 1.00 x .022
36	731-07001†	Hubcap

† If Equipped


Model Series 830



Ref No.	Part Number	Description
1	946-04440	Drive Cable
2	735-04059	Rubber Grommet
3	747-04994A	Drive Control
4	732-04516	Shift Spring
5	747-04995	Blade Control
6	746-04438	Control Cable
7	749-04555	Lower Handle
8	725-0157	Cable Tie
9	732-04535	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01790	Front Deck Baffle
14	731-06304	Variable Spd. Cont. Panel Cover
15	726-0201	Speed Nut
16	710-0779A	Screw, #10-16 x .500
17	710-0895	Screw, 1/4-15 x .750
18	736-3000	Washer, Flat, .250 x .750 x .119
19	936-0275	Washer, Flat, .344 x .688 x .065
20	715-04073	Dowel Pin
21	631-04323	Variable Speed Control Panel
22	710-0642	Screw, TT, 1/4-20 x .750
23	946-04439A	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625

Ref No.	Part Number	Description
26	712-04063	Flange Lock Nut, 5/16-18
27	731-05462A	Trail Shield
28	731-05157	Rear Mulching Baffle
29	731-05702A	Rear Door
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072A	Star Knob
32	732-04534	Torsion Spring, RH
33	747-05034	Door Pivot Rod
34	647-04051B-0637	Grass Catcher Frame
35	964-04101	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04607-0637	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	987-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	710-0896	Screw, AB, 1/4-14 x .625
48	731-06189	4 Speed Actuator
49	731-06193A	Speed Selector Lever


Model Series 830



Ref No.	Part Number	Description
1	954-04176A	V-Belt
2	732-04338C	Spring Lever
3	720-04113	Height Adjuster Knob - Red
	720-04092	Height Adjuster Knob - Blue
4	917-04540B	Spur Gear, 14T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-0895	Screw, HL, 1/4-15 x .750
7	749-04267A-0637	Cross Bracket
8	687-02204B-0637	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	934-04430	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	917-04539B	Spur Gear, 14T - RH
16	731-06284	Baffle
17	731-06974	Wheel Dust Cover
18	687-02415	Transmission Bearing Support
19	731-05872	Clip Spacer
20	716-0198	Retaining Ring .875
21	687-02314A-0637	Rear Bracket Assembly
22	732-04630	Compression Spring
23	756-04316A	Upper Pulley

Ref No.	Part Number	Description
24	936-0406	Flat Washer, .442 x 1.38 x .060
25	756-04317A	Lower Pulley
26	687-02322-0637	Handle Bracket Assembly LH
27	915-0221	Dowel Pin
28	918-04826A	Transmission Assembly
29	687-02323-0637	Handle Bracket Assembly RH
30	748-0390	Bearing Support Spacer
31	732-04313	Extension Spring
32	748-04096	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	942-0741A	21" Mulching Blade
36	936-0447	Washer, Wave, 1.5 x 1.0 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112A	Engine Baffle
39	956-04046	Lower Pulley Assembly
40	756-04311A	Pulley, Half
41	736-04413	Wash., Wave, .385 ID x .598 OD
42	710-04774	Screw, 1/4-15 x 1.250
43	736-0242	Washer, Bell, .340 x .872 x .080
44	936-0369	Washer, Flat, .508 x 1.00 x .020
45	732-04650	Spr, Wave
46	750-05007	Spcr., 25mm x 1.375


Model Series 860



Ref No.	Part Number	Description
1	946-04440	Drive Cable
2	735-04059	Rubber Grommet
3	747-04994A	Drive Control
4	732-04516	Shift Spring
5	747-04995	Blade Control
6	746-04438	Control Cable
7	749-04557-0637	Lower Handle
8	725-0157	Cable Tie
9	732-04535	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01790	Front Deck Baffle
14	731-06304	Variable Spd. Cont. Panel Cover
15	710-0642	Screw, TT, 1/4-20 x .750
16	710-0779A	Screw, #10-16 x .500
17	726-0201	Nut, Speed
18	710-0895	Screw, 1/4-15 x .750
19	710-0703	Carriage Bolt, 1/4-20
20	912-0397	Wing Nut
21	631-04323	Variable Speed Control Panel
22	914-0104	Cotter Pin
23	946-04439A	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625
26	712-04063	Flange Lock Nut, 5/16-18

Ref No.	Part Number	Description
27	731-05462A	Trail shield
28	731-05157	Mulch Plug
29	731-05702A	Rear Door
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072A	Star Knob
32	732-04534	Torsion Spring, RH
33	747-05034	Door Rod
34	647-04051B-0637	Grass Catcher Frame
35	964-04101	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04607-0637	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	987-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	710-0896	Screw, AB, 1/4-14 x .625
48	731-06189	4 Speed Actuator
49	731-06193A	Speed Selector Level
50	715-04073	Dowel Pin
51	936-0275	Washer, Flat, .344 x .688 x .065
52	736-3000	Washer, Flat, .250 x .750 x .119


Model Series 860



Ref No.	Part Number	Description
1	954-04176A	V-Belt
2	732-04480A	Spring Lever
3	720-04097	Height Adjuster Knob - Red
	720-04092	Height Adjuster Knob - Blue
4	917-04577A	Spur Gear, 16T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-0895	Screw, 1/4-15 x .750
7	749-04414A-0637	Cross Bracket
8	687-02367B-0637	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	934-04404	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	917-04578A	Spur Gear, 16T - RH
16	917-04678	Gear, Spur, 23T
17	731-06145C	Wheel Dust Cover
18	741-0604A	Bearing Sleeve
19	787-01645A	Dust Cover Seal Plate
20	731-06146	Hub Cap
21	687-02390-0637	Rear Bracket Assembly
22	732-04630	Compression Spring
23	756-04316A	Upper Pulley
24	936-0406	Flat Washer, .442 x 1.38 x .060
25	756-04317A	Lower Pulley
26	987-02503	Handle Bracket Assembly LH (Includes Ref. #'s 18, 46, & 47)
27	915-0221	Dowel Pin

Ref No.	Part Number	Description
28	918-04826A	Transmission Assembly
29	987-02537	Handle Bracket Assembly RH (Includes Ref. #'s 18, 46, & 47)
30	756-04311A	Pulley, Half
31	732-04313	Extension Spring
32	748-04096	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	942-0741A	21" Mulching Blade
36	936-0447	Washer, Wave, 1.5 x 1.0 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112A	Engine Baffle
39	956-04046	Lower Pulley Assembly
40	710-0653	Screw, TT, 1/4-20 x .375
41	710-04774	Screw, 1/4-15 x 1.25
42	736-0182	Washer, Sprg, .500 x 1.00 x .022
43	936-0272	Washer, Flat, .510 x 1.00 x .060
44	711-05040	Shf., .500 Dia.
45	731-06284	Baffle
46	748-04177	Bearing Support
47	732-0708	Bearing Retainer
48	736-04413	Wshr, Wave, .385 ID x .598 OD
49	732-04557	Sprg, Comp., .63 OD x 1.00 Lg.
50	750-05061	Spacer, .690 x .870 x .150
51	750-05008	Spcr., 25mm x 1.375
52	750-05250	Spcr., Flg., .51 ID x .58 OD
53	936-0369	Washer, Flat, .508 x 1.00 x .020
54	732-04650	Spr, Wave


Model TB210



Ref No.	Part Number	Description
1	747-05214	Blade Control
2	749-04681-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01800	Engine Baffle Bracket
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02538	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	747-05210A	Drive Control
27	738-04419A	Sldr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	734-04014B	Rear Wheel

Ref No.	Part Number	Description
34	946-04674	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04675	Drive Cable
40	911-04149	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	738-04436A	Scr., Sldr., 1/4-20 x .70
65	954-04259A	V-Belt
66	787-01793	Front Axle Clip


Model TB270 ES



Ref No.	Part Number	Description
1	747-05214	Blade Control
2	749-04681-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01800	Engine Baffle Bracket
19	710-05073	Screw, 1/4-20 x .500
20	787-01806	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02538	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	747-05210A	Drive Control
27	738-04419A	Sldr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	734-04014B	Rear Wheel
34	946-04674	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04675	Drive Cable
40	911-04149	Rear Axle Assembly

Ref No.	Part Number	Description
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	738-04436A	Scr., Sldr., 1/4-20 x .70
65	954-04259A	V-Belt
66	787-01793	Front Axle Clip
67	725-04329	Battery Charger
68	710-0136	Screw, 1/4-20 x 1.75
69	710-3105	Bolt, Carr., 5/16-18 x .875
70	712-04063	Nut, Flglk., 5/16-18 x
71	925-0201	Key
72	725-04903	Battery
73	738-04431	Scr., Sldr., 5/16-14 x .972
74	725-05112	Key Switch
75	726-0201	Speed Nut
76	731-07135	Battery Housing
77	731-07154	Battery Housing Top
78	731-07155	Electric Start Housing
79	735-04213A	Lid Seal
—	725-05015	Wire Harness (Not Shown)


Model TB230



Ref No.	Part Number	Description
1	747-05267	Blade Control
2	749-04679-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	731-07199	Hubcap
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02528	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	753-06060	Control Lever Assembly
27	738-04419A	Slidr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	634-04626	Rear Wheel

Ref No.	Part Number	Description
34	946-04661	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04655	Variable Speed Cable
40	911-04144	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	787-01800	Engine Baffle Bracket
65	954-04260	V-Belt
66	787-01793	Front Axle Clip


Model TB250



Ref No.	Part Number	Description
1	747-05267	Blade Control
2	749-04679-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01793	Front Axle Clip
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02528	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	753-06060	Control Lever Assembly
27	738-04419A	Slidr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20

Ref No.	Part Number	Description
33	734-04014B	Rear Wheel
34	946-04670	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04655	Variable Speed Cable
40	911-04149	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	787-01800	Engine Baffle Bracket
65	954-04260	V-Belt


Engine Model 1P70MC



Ref No.	Part Number	Description
1.	951-10438	Fuel Tank
2.	951-10369	Flywheel Shroud
3.	951-10840	Reed Valve Assembly
4.	951-10334	Oil Filler Tube Assembly
5.	951-10863	Dipstick Assembly
6.	951-10413	Cylinder Head Complete
7.	951-10867	Short Block Assembly
8.	951-10321	Stop Switch and Brake Assembly
9.	951-10319	Recoil Spring and Pulley Assembly
10.	951-10344	Push Rod Kit
11.	951-10345	Valve Kit
12.	951-10370	Oil Drain Plug and Washer Assembly
13.	951-10366	Ignition Coil
14.	951-10862	Carburetor Assembly
15.	951-10307	Flywheel Key
16.	951-10865	Air Cleaner Housing Assembly Complete
17.	951-10342	Muffler Stud Assembly
18.	951-10364	Fuel Line Kit – Inc. hoses, clamps & filter
19.	951-10358	Fuel Filter
20.	951-10440	Fuel Cap
21.	951-10299	Recoil Starter Assembly
22.	951-10298	Air Cleaner Kit
23.	951-10297	Air Cleaner Thumb Screw
24.	951-10411	Muffler Guard
25.	951-10775	Muffler
26.	951-10402	Muffler Gasket /Heat Shield
27.	951-10387	Governor Return Spring
28.	951-10292	Spark Plug
29.	951-10869	Roll Over Valve Assembly
30.	951-10443	Carbon Canister
31.	951-10773	Spark Arrestor
–	952Z1P70MC	Engine – Complete
–	951-10868	Carburetor Kit – Major
–	951-10870	Cylinder Head Service Kit
–	951-10416	Gasket Kit – Complete
–	951-10417	Gasket Kit – External

NOTE: Illustrated parts without a numeric call-out are not servicable components.

Engine Model - 2P70MOB




Ref No.	Part Number	Description
1.	951-10368	Fuel Tank
2.	951-10855	Flywheel Shroud
3.	951-10335	Rubber Fuel Tank Mntg. Washer
4.	951-10334	Oil Filler Tube Assembly
5.	951-10852	Dipstick Assembly
6.	951-10413A	Cylinder Head Complete
7.	951-10857A	Short Block Assembly
8.	951-10858	Stop Switch and Brake Assembly
9.	951-10319	Recoil Spring and Pulley Ass'y.
10.	951-10344	Push Rod Kit
11.	951-10345	Valve Kit
12.	951-10370	Oil Drain Plug and Washer Ass'y.
13.	951-10854	Ignition Coil
14.	951-10881	Carburetor Assembly
15.	951-10307	Flywheel Key
16.	951-10412A	Air Cleaner Housing Complete
17.	951-10342	Muffler Stud Assembly
18.	951-10364	Fuel Line Kit – Inc. hoses, clamps & filter
19.	951-10358	Fuel Filter
20.	951-10300	Fuel Cap Assembly

Ref No.	Part Number	Description
21.	951-10299A	Recoil Starter Assembly
22.	951-10298	Air Cleaner Kit
23.	951-10297	Air Cleaner Thumb Screw
24.	951-10411	Muffler Guard
25.	951-10403	Muffler
26.	951-11179	Muffler Gasket /Heat Shield
27.	951-11178	Governor Return Spring
28.	951-10292	Spark Plug
29.	951-10351	Spark Arrestor
30.	951-10880A	Electric Starter
31.	951-10823	Relay Assembly
32.	951-10824	Relay Harness Connector
33.	951-10888	Primer Assembly
–	952Z2P70MOB	Engine – Complete
–	712-04221	Flywheel Nut
–	951-11045	Flywheel
–	951-11238	Governor Arm Bracket
–	951-10890	Carburetor Kit – Major
–	951-10859	Cylinder Head Service Kit
–	951-10416	Gasket Kit – Complete
–	951-10417	Gasket Kit – External

NOTE: Illustrated parts without a numeric call-out are not servicable components.

Model Series G460



Model Series G460

Ref No.	Part Number	Description
1	753-06060	Drive Control Assembly
2	749-0928A-0637	Lower Handle
3	710-0703	Carriage Bolt 1/4-20
4	918-04377B	Transmission Assembly
5	731-06847	Rear Discharge Door
6	954-04082A	V-Belt
7	747-1161A-0637	Blade Control
8	749-1092A	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	732-04090A	Torsion Spring - RH
12	747-04080A	Grass Bag Frame
13	720-0279	Handle Knob
14	720-04072A	Handle Knob
15	710-1205	Eye Bolt
16	746-1130	Control Cable
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	731-07049	Hub Cap
19	926-0240	Cable Tie
20	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
21	710-0654A	Self-Tapping Sems Screw
22	746-04206A	Drive Cable
23	964-04007A	Grass bag
24	710-1650	Shoulder Screw # 12 -24
25	747-04587	Pivot Rod
26	710-1241	Screw, 1/4-15 x 1.00
27	732-04317	Extension Spring
28	731-05642A	Rear Trailing Shield
29	731-04150C	Rear Baffle
30	936-0504	Washer, Wave, .510 x .750 x .017
31	912-0397	Wing Nut
32	931-05013A	Transmission Cover
33	687-02221	Blade Adapter
34	942-0741A	21" Mulching Blade
35	736-0524B	Blade Bell Support
36	710-1257	Hex Screw 3/8-24 x 2.50
37	782-7551A	Wheel Dust Cap
38	916-0102	Snap Ring
39	787-01258A-0637	Cable Mount Bracket
40	710-0896	Screw, 1/4-14 x .625
41	710-04329	Screw, .159 OD x .610

Ref No.	Part Number	Description
42	787-01593	Engine Baffle Bracket
43	936-0447	Washer, Wave, 1.5 x 1.0 x .029
44	931-06029	Engine Baffle
45	710-0599	TT Screw 1/4-20 x 0.5
46	736-0270	Bell Washer.265 x 0.75
47	17032A	Deflector Chute Adapter
48	732-1014	Torsion Spring
49	747-0710	Hinge Pin
50	987-02347	Bearing Assembly
51	787-01278-0691	21" Deck
52	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
53	750-04405	Sleeve Spacer, 1.8" Lg.
54	710-0216	Hex Screw, 3/8-16 x.75
55	712-04065	Flange Lock Nut, 3/8-16
56	782-5002B	Front Baffle
57	732-04294	Belt Keeper Wire
58	750-04404	Sleeve Spacer, 9.10" Lg.
59	987-02334	Pivot Plate Assembly
60	720-0426	Adjustment Knob
61	734-2042A	Front Wheel
62	710-04531	Screw, 1/4-20 x .390
63	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
64	710-1652	TT Scr. w/Washer 1/4-20 x.625
65	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
66	915-0221	Dowel Pin
67	736-0474	Washer
68	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
69	732-04175	Rear Spring Lever
70	738-04266	Shoulder Scr., 500 Dia. x. 385
71	734-2004B	Rear Wheel
72	725-04329	Battery Charger
73	925-04072	Electric Start Harness Assembly
74	925-04347	Key Switch
75	710-1667A	Screw, #10-16 x .750
76	925-0201	Key
77	925-04323	Battery
78	728-0199	Rivet