


# OPERATOR'S MANUAL



## 3-in-1 Battery Mower

### **WARNING**


**READ AND FOLLOW ALL SAFETY RULES AND INSTRUCTIONS IN THIS MANUAL  
BEFORE ATTEMPTING TO OPERATE THIS MACHINE.  
FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY.**

---

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

---

# Model 18A-212B



For a new battery pack, order part 725-05089.

| Ref. | Part Number | Description            |
|------|-------------|------------------------|
| 1    | 787-01839A  | Deck                   |
| 2    | 731-07671   | Shroud                 |
| 3    | 731-07619   | Side Discharge Door    |
| 4    | 731-07620   | Side Discharge Chute   |
| 5    | 731-07621   | Trail Shield           |
| 6    | 734-04537   | Front Wheel            |
| 7    | 734-04548   | Rear Wheel             |
| 8    | 731-07512   | Wheel Cap              |
| 9    | 721-04378   | Seal Line              |
| 10   | 731-07622   | Rear Door              |
| 11   | 731-07623   | Rear Baffle            |
| 12   | 731-07624   | Mulching Plug          |
| 13   | 711-05358   | Rear Shaft             |
| 14   | 732-04733   | Spring                 |
| 15   | 732-04734   | Spring                 |
| 16   | 787-01824A  | Left Bracket           |
| 17   | 787-08125A  | Right Bracket          |
| 18   | 711-05325   | Trail Shield Pin       |
| 19   | 787-01813   | Side Discharge Bracket |
| 20   | 711-05326   | Side Discharge Pin     |
| 21   | 732-04713   | Spring                 |
| 22   | 611-04176   | Front Axle Assembly    |
| 23   | 741-04464   | Front Shaft Bushing    |
| 24   | 741-04474   | Bearing                |
| 25   | 611-04177   | Rear Axle Assembly     |
| 26   | 741-04465   | Rear Shaft Bushing     |
| 27   | 732-04735   | Handle Adjust          |
| 28   | 732-04715   | Handle Adjust Spring   |
| 29   | 720-04143   | Handle Adjust Knob     |
| 30   | 787-01826   | Link Bar               |
| 31   | 724-04095   | Motor                  |
| 32   | 731-07515   | Fan                    |
| 33   | 742-04321   | Blade                  |
| 34   | 736-04486   | Flange                 |
| 35   | 731-07598   | Washer                 |
| 36   | 736-04487   | Washer                 |
| 37   | 712-04237   | Blade Nut              |
| 38   | 731-07672   | Support                |
| 39   | 731-07673   | Strain Relief          |
| 40   | 749-04670A  | Upper Handle           |
| 41   | 731-07522   | Handle Grip            |
| 42   | 749-04688A  | Lower Handle           |
| 43   | 720-04145   | Quick Release          |
| 44   | 736-04488   | Washer                 |
| 45   | 720-04146   | Quick Release Knob     |

| Ref. | Part Number | Description          |
|------|-------------|----------------------|
| 46   | 710-05151   | M8 Screw             |
| 47   | 715-04107   | Quick Release Pin    |
| 48   | 712-04257   | M8 Nut               |
| 49   | 712-04250   | M6 Lock Nut          |
| 50   | 720-04147   | Wing Knob            |
| 51   | 710-05082   | Screw                |
| 52   | 736-04489   | Washer               |
| 53   | 731-07524   | Cord Clip            |
| 54   | 714-04088   | Pin                  |
| 55   | 731-07513   | Cap                  |
| 56   | 625-04129   | Switch Box           |
| 57   | 725-05156   | Cord                 |
| 58   | 747-05304   | Clamp                |
| 59   | 764-04096   | Grassbag             |
| 60   | 731-07674   | Battery Pack Cover   |
| 61   | 731-07675   | Battery Pack Housing |
| 62   | 731-07676   | Handle               |
| 63   | 787-01840   | Hook                 |
| 64   | 725-05157   | Battery              |
| 65   | 725-05158   | Connector            |
| 66   | 725-05159   | PCB                  |
| 67   | 725-05160   | PCB Support          |
| 68   | 725-05161   | Connector            |
| 69   | 725-05162   | Safety Key           |
| 70   | 725-05163   | Key Connector        |
| 71   | 725-05164   | SA50 Connector       |
| 72   | 725-05165   | Supporter            |
| 73   | 731-07678   | Supporter            |
| 74   | 725-05170   | Connector            |
| 75   | 725-05169   | Connector            |
| 76   | 725-05168   | Fuse                 |
| 77   | 725-05167   | Board                |
| 78   | 725-05068   | Charger              |
| 79   | 736-04505   | Spring Washer        |
| 80   | 736-04506   | 8mm Washer           |
| 81   | 712-04258   | M8 Nut               |
| 82   | 710-05156   | ST4.2x16 Screw       |
| 83   | 710-05155   | ST4.2x25 Screw       |
| 84   | 710-05154   | ST4.8x16 Screw       |
| 85   | 710-05153   | M6x12 Screw          |
| 86   | 710-05118   | M5 x 12 Screw        |
| 87   | 714-04508   | Washer               |
| 88   | 716-04169   | 10mm Lock Ring       |
| 89   | 787-01841   | Support              |