

# Operator's Manual




4-Cycle

## WEEDWACKER® GAS TRIMMER

Model No. 316.791910

**INCREDI-PULL**™  
UNBELIEVABLE STARTING EASE™

with **MAX FIRE** IGNITION™




- SAFETY
- ASSEMBLY
- OPERATION
- MAINTENANCE
- PARTS LIST
- ESPAÑOL, P. 15

**CAUTION:** Before using this product, read this manual and follow all safety rules and operating instructions.

Sears Brands Management Corporation, Hoffman Estates, IL 60179 U.S.A.  
Visit our website: [www.craftsman.com](http://www.craftsman.com)

PARTS LIST

REPLACEMENT PARTS - MODEL 316.791910  
4-CYCLE GAS TRIMMER




## REPLACEMENT PARTS - MODEL 316.791910

### 4-CYCLE GAS TRIMMER

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-06134	Engine Cover Assembly (includes 2 & 3)	23	791-181751	O-Ring
2	753-04595	Cover Screw	24	753-05302	Air Cleaner Cover Assembly (includes 25)
3	753-05377	Screw	25	753-05254	Air Filter
4	753-05209	Rocker Cover	26	753-05253	Screw
5	753-05210	Rocker Cover O-Ring	27	753-06240	Fuel Tank Assembly w/Fuel Lines (includes 28)
6	753-05232	Cylinder O-Ring	28	753-1229	Fuel Cap
7	753-05400	Oil Plug (includes 8)	29	753-05259	Fuel Tank Pads
8	791-182290	Oil Plug O-Ring	30	753-05078	Spacer
9	753-06259	Crankcase Cover	31	753-05832	Starter Housing Assembly (includes 3)
10	753-05238	Crankcase Cover O-ring	32	753-06281	Clutch Assembly
11	753-06221	Flywheel Assembly	33	753-05263	Clutch Cover (includes 2)
12	753-05264	Lead Wires	34	791-182519	Anti-Rotation Screw
13	753-05401	Module Assembly	35	753-04003	Clamp Screw
14	753-05244	Muffler Gasket	36	791-180217	Nut
15	753-05245	Muffler Assembly (includes 14 & 16)	37	791-181025	Rocker Cover Screw
16	753-05246	Muffler Screw	38	753-06328	Shortblock Assembly (includes 3-8, 10 & 17)
17	753-05784	Spark Plug	*	753-05297	Spark Arrestor Assembly
18	753-05247	Insulator Gasket			
19	753-05248	Nut			
20	753-05249	Insulator			
21	753-05366	Carburetor Gasket			
22	753-06220	Carburetor w/Primer			

REPLACEMENT PARTS - MODEL 316.791910  
4-CYCLE GAS TRIMMER



Item	Part No.	Description
1	753-04234	Throttle Housing Assembly (includes 2-4)
2	753-04119	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch Assembly
5	753-05266	Throttle Cable Assembly
6	791-181808	Drive Shaft Housing
7	753-06039	D-Handle Assembly (includes 8)
8	753-06040	Bolt
9	791-181817	Flexible Drive Shaft
10	791-182519	Anti-Rotation Screw
11	753-05841	Gear Box Assembly (includes 15-25)
12	791-180547	Shield Mounting Hardware
13	791-180548	Shield Assembly (includes 14)
14	791-682061	Blade Assembly
15	791-181561	Thrust Washer
16	753-04257	Slider
17	791-181459	Small Spring
18	791-181532	E-Clip
19	791-181531	Spring
20	791-181462	Plunger
21	791-181463	C-Clip
22	791-181772	Inner Reel
23	791-181465B	Large Spring
24	791-181467	Foam Seal
25	791-181468B	Bump Knob Assembly (includes 23 & 24)

\* Items Not Shown