

ILLUSTRATED PARTS MANUAL



54" Hydrostatic Garden Tractor, 900 Series

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank you for purchasing an MTD Garden Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Axle, Front	6	Meter, Systems Indicator	16-19
Battery	4	Mower Deck, 50-inch	12
Choke Control	16-19	Mower Deck, 54-inch	14
Dash Panel	16-19	Muffler	3
Deck Lift Handle/Linkage	8	Pedal Controls	10
Drive System	10	PTO Pulley	4
Electrical Schematic	22	PTO Switch	16-19
Engine Accessories, Kohler Courage	20	Seat	8
Engine Accessories, Briggs Intek	21	Solenoid	4
Fender	8	Steering Wheel	6
Frame	4	Switches, Interlock	4
Fuel Tank	16-19	Throttle Control	14
Head Lamps	16-19	Wheels, Front	6
Hood	16-19	Wheels, Rear	10

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:

0637	Black	0650	Metallic Red (White Outdoor)
0709	Dark Green (Bolens, Mastercraft, Yard-Man Domestic)	0665	Dark Green (Yard-Man Export)
0662	Oyster Gray (MTD Gold)	0629	Silver Flake (MTD Platinum)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)	04038	Day Orange (Daedong)
0691	Black Jack (MTD Gold, MasterCut)	04015	Fire Red (Massey Ferguson)
0674	Yellow (Yard-Man)	04033	Flint Mica (Troy-Bilt XP)


PTO and Battery



Ref.	Part Number	Description
1	710-04379A	Hex Head Screw, 7/16-20:3.50
2	917-1774C	Electric PTO Clutch
—	917-04174A	Electric PTO Clutch, 50"
3	725-0157	Cable Tie, 3/16 x .05 x 7.4
4	936-0171	Lock Washer, 7/16
5	736-0277	Flat Washer, 1.031 x 1.620 x .095
6	683-04469A	Frame
7	756-0978B	Electric PTO Engine Pulley
8	710-04484	Taptite Screw, 5/16-18:.750
9	710-3005	Hex Head Screw, 3/8-16:1.25
10	712-04065	Flangelock Nut, 3/8-16
11	738-04058	Shoulder Spacer, .38 x 1.0 x .70
12	747-04121A	Battery Holder Rod
13	783-0349	Battery Tray
14	783-06089	Seat Frame Bracket
15	683-04219B	Bumper
16	712-3000	Hexlock Nut, 3/8-16
17	731-05674	Bumper Cap
18	738-0143	Shoulder Bolt, .496 x .336
19	714-04061	Quick Release Pin
20	710-04666	Hex Head Flange, 1/4-20:.75
21	712-0271	Sems Nut, 1/4-20
22	925-1707D	Battery
23	710-0653	Taptite Screw, 1/4-20:0.375
24	712-04064	Flangelock Nut, 1/4-20
25	725-04363	Interlock Switch
26	725-04439	Solenoid, 12 V
27	738-04237A	Shoulder Screw, #10-32:.500
28	747-05195	Belt Keeper Rod

* 50" Deck Models


Steering and Axle



Ref.	Part Number	Description
1	710-04095	Hex Head Screw, 3/8-16:1.00
2	710-0514	Hex Head Screw, 3/8-16:1.00
3	710-0643	Hex Head Screw, 5/16-18:1.00
—	710-0650	Hex Head Screw, 5/16-18:0.875, 50"
4	711-04998	LH Drag Link
5	711-04999	RH Drag Link
6	912-0240	Jam Nut, 7/16-20
7	712-04065	Flangelock Nut, 3/8-16
8	712-0459	Flangelock Nut, 7/16-20
9	712-3004A	Flangelock Nut, 5/16-18
10	717-1550F	Steering Gear
11	717-1554	Steering Pinion Gear
12	923-0448A	Ball Joint, 7/16-20
13	936-3004	Flat Washer, .406 x .875 x .105
14	736-3084	Flat Washer, .51 x 1.12 x .06
15	638-04040	RH Axle Assembly
16	738-04263	Steering Shaft, .625 OD x 24.25 LG
17	738-04363	Shoulder Spacer, .385 x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375
19	741-04237B	Hex Flange Bearing 5/8 PM
20	783-06043	Steering Support Bracket
21	638-04041	LH Axle Assembly
22	710-0395	Hex Head Screw, 5/16-18:2.25
23	710-0859	Hex Head Screw, 3/8-16:2.50

Ref.	Part Number	Description
24	710-3180	Hex Head Screw, 5/16-18:1.75
25	912-0214	Hexlock Nut, 3/8-24
26	712-04063	Flangelock Nut, 5/16-18
27	714-0162	Cotter Pin, 5/32:1.25
28	719-04413A	Pivot Bar Axle
29	748-04065	Steering Block
30	748-04068	Spacer, .71 ID x .125 OD x .56LG
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04028	Steering Wheel, Standard Grip
—	631-04008A	Steering Wheel, Soft Grip, 50"
33	731-04040	Steering Wheel Cap, Sprig
—	731-04039	Steering Wheel Cap, No Sprig, 50"
34	634-04466	Wheel Assembly
—	634-04562	Wheel Assembly, Ball Bearing, 50"
35	934-04082	Rim Assembly
—	934-04090A	Rim Assembly, Ball Bearing, 50"
36	734-1727	Tire
37	934-0255	Tubeless Air Valve
38	741-0516B	Flange Bearing, .760 x 1.00 x 1.20LG
39	741-0990B	Flange Bearing, .760ID
40	731-05674	Bumper Cap
—	931-3020	Hubcap, 50"
41	736-04228A	Flat Washer, .781ID x 1.590OD
—	736-0866	Flat Washer, .755 x .192 x .060, 50"


Seat and Fender



Ref.	Part Number	Description
1	683-04301	Lift Shaft Assembly
2	712-04063	Flangelock Nut, 5/16-18
3	712-04065	Flangelock Nut, 3/8-16
4	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
5	714-04040	Bow-Tie Cotter Pin
6	716-0106A	E-Ring, .625 DIA. SHAFT
7	720-0311	Handle Grip
8	732-0874	Torsion Spring
9	736-0105	Spring Washer, .401 x .870 x .063
10	738-0138A	Shoulder Screw, .437 x .470:5/16-18
11	938-0380	Shoulder Bolt, .500 x .270:3/8-16
12	941-0225	Hex Flange Bearing
13	746-0968	Lift Cable, 16.16 LG
14	747-04962A	Lift Handle
15	756-04331	Pulley Roller Cable
16	783-05546A	Lift Arm
17	710-04484	Taptite Screw, Lock Washer, 5/16-18:.750
18	710-0599	Taptite Screw, Lock Washer, 1/4-20
19	710-0895	Hi-Lo Screw, Lock Washer, 1/4-15
20	710-0932	Carriage Screw, 1/4-20:1.00
21	710-1260A	Taptite Screw, 5/16-18:.750
22	712-0271	Sems Nut, 1/4-20
23	731-06795	Lift Lever Cover
24	731-1993A	Cover with Cup Holder
25	731-2618	RH Fender Flare
26	731-2619	LH Fender Flare

Ref.	Part Number	Description
27	736-3078	Flat Washer, .344 x 1.00 x .063 HDN
28	783-06556	Fender
28*	783-06118	Fender, 50" Deck
29	710-04482	Hex Head Flange, 3/8-16:.875
30	712-3004A	Flangelock Nut, 5/16-18
31	725-0157	Cable Tie, 3/16 x .05 x 7.4
32	732-04561	Compression Spring, 1.71 x 3.735 x .238
33	732-04563	Compression Spring, .68 x 1.065 x .055
34	938-0296	Shoulder Screw, .437 x .268:5/16-18
35	783-06049	Seat Mounting Bracket
36	783-06050	Seat Adjustment Lever
37	783-06088	Seat Pivot Bracket
38	783-06448	Switch Retainer Clip
39	726-3046	Ratchet Clip
40	735-04138	LH Foot Pad
—	735-04137	LH Foot Pad, 50" Deck
41	735-04158	RH Foot Pad
—	735-04139	RH Foot Pad, 50" Deck
42	757-04086	Seat
43	925-05013	Seat Switch
44	783-06548	Lift Bracket
—	783-06181	Lift Bracket, 50" Deck
45	731-06584	Fender Cover Door
46	731-06676	LH Fender Cover
47	731-06700	RH Fender Cover
48	747-05039	Door Pin

Drive and Rear Wheels




Drive and Rear Wheels

Ref.	Part Number	Description
1	918-04317	Wheel Assembly Hub
2	918-04917	Transmission
3	710-0189	Hex Screw, 5/16-18:3.00
4	710-0227	Screw, #8-18:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0599	Taptite Screw, 1/4-20:0.500
7	710-0909A	Taptite Screw, 5/16-18:1.750
8	710-1007	Taptite Sems Screw, 3/8-16:1.500
9	710-1008	Taptite Sems Screw, 3/8-16:1.875
10	710-1189	Screw, #12-24:0.625
11	710-1325	Taptite Screw, 1/4-20:1.625
12	710-3011	Hex Screw, 3/8-16:2.25
13	710-3119	Hex Screw, 3/8-16:.750
14	912-0240	Jam Nut, 7/16-20
15	712-04063	Flangelock Nut, 5/16-18
16	712-04065	Flangelock Nut, 3/8-16
17	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
18	914-0111	Cotter Pin, 3/32:1.0
19	725-0157	Cable Tie, 3/16 x .05 x 7.4
20	725-04791A	Jumper Harness
21	725-1644	Short Spring Switch
22	926-0154	Push Mount Cable Tie 7.5 LG
23	926-0320	Insulator Nut Plate
24	931-1449A	Blade Fan
25	732-04528	Extension Spring, .50 DIA x 5.0 LG
26	732-04624	Extension Spring, 1.00 DIA x 4.75
27	732-0716D	Extension Spring, .59 OD x 4.00 LG
28	732-0932	Extension Spring, .38 DIA x 5.6
29	732-3118	Extension Spring, .375 OD x 1.44 LG
30	936-0227	Flat Washer, .390 x 1.500 x .134
31	936-0264	Flat Washer, .330 x .630 x .0635
32	936-3008	Flat Washer, .344 x .750 x .120
33	736-3010	Flat Washer, .407 x .812 x .135
34	647-04152A	Brake Control Assembly
35	738-04420	Shoulder Spacer, 1.375 x .380 x .183
36	747-04957A	Footpedal Bypass Transmission Rod
37	747-05124	Brake Rod

Ref.	Part Number	Description
38	747-05125A	Control Rod
39	747-05130	Disengage Rod
40	747-05181	Belt Keeper, 5/16
41	750-04456	Spacer, 260 x .372 x 1.420 LG
42	954-04244A	V Belt, 4L x 77.0
43	756-04224	Flat Idler Pulley, 2.75 OD
44	756-04325	V Idler Pulley, 3.06
45	783-05443A	Torque Bracket
46	783-05841	Switch Bracket
47	783-06027A	Center Idler Bracket
48	783-06501A	Deck Bracket
49	783-06503	Plate Bracket
50	783-0693A	Axle Bracket
51	683-04621	Hydro Pedal Bracket Assembly
52	710-0604A	Taptite Screw, 5/16-18:0.625
53	711-05068	Clevis Pin, 5/16 x 3.985
54	714-04040	Bow-Tie Cotter Pin
55	719-0584B	Control Pedal
56	726-0214	Push Cap
57	732-04587	Extension Spring, .63 DIA x 4.95 LG
58	735-04136	Brake Pedal Pad
59	736-0242	Bell Washer, .340 x .872 x .060
60	938-0380	Shoulder Bolt, .500 x .270:3/8-16
61	741-0495	Flange Bearing, .630 ID x .695 OD x .60
62	748-04203	Cruise Latch
63	783-05914	Pedal Support Bracket
64	783-05940	Pedal Support Bracket, 5/8
65	783-06103A	Brake Pedal Bracket
66	634-0202A	Wheel Assembly
67	712-3050	Lug Nut, 7/16-14
68	934-0255	Air Valve
69	734-04147	Tire
70	634-04238	Rim Assembly
71	683-04571	Hydro Pedal Bracket Assembly
72	735-04118A	Reverse Pedal Pad
73	735-04135	Forward Pedal Pad
74	783-06059	Drive Pedal Bracket


50" Deck



Ref.	Part Number	Description
1	96606	Hook Retainer Bracket
2	918-04126B	Pulley Spindle Assembly, 5.39
3	683-0254B	Deck Hanger Bracket Assembly
4	983-04582	Deck Assembly
5	703-3279	Chute Deflector Stop
6	710-0347	Hex Screw, 3/8-16:1.75
7	710-04095	Hex Screw, 3/8-16:1.00
8	710-04484	Taptite Screw, 5/16-18:.750
9	710-0528	Hex Screw, 5/16-18:1.25
10	710-0599	Taptite Screw, 1/4-20:0.500
11	756-04216	Deck Pulley
12	710-3005	Hex Screw, 3/8-16:1.25
13	710-3103	Hex Screw, 5/16-18:2.0
14	710-3178	Carriage Bolt, 3/8-16:0.75
15	911-3314	Roller Pin, 1/2 DIA x 7.31 LG
16	712-04063	Flangelock Nut, 5/16-18
17	712-04065	Flangelock Nut, 3/8-16
18	712-0417A	Flange Nut, 5/8-18
19	712-04243	Flexlock Nut, 1/2-13
20	912-0641	Hex Nut, M16-1.5 DIN 936
21	912-3010	Hex Nut, 5/16-18:GR5
22	914-0111	Cotter Pin, 3/32:1.0
23	753-04070	Lynch Pin, .1875
24	714-04040	Bow-Tie Cotter Pin
25	914-0470	Cotter Pin, 1/8 x 1.25
26	917-04074	Deck Adjustment Gear
27	921-04041	Water Nozzle Adaptor
28	731-05679	Front Roller
29	732-0459C	Extension Spring, .94 DIA. x 6.74 LG
30	732-04652	Compression Spring, .535 OD x 1.751
31	732-0934	Extension Spring, 1.15 OD x 5.99 LG
32	734-04155	Front Deck Wheel

Ref.	Part Number	Description
33	734-0973	Rear Deck Wheel
34	936-0119	Lock Washer, 5/16
35	736-0225	Lock Washer, 5/8
36	936-0300	Flat Washer, .406 x .875 x .059
37	736-0317	Bell Washer, .63 x 1.25 x .18
38	737-04003D	Water Nozzle
39	938-0373	Shoulder Bolt, .496 x 1.525:3/8-16
40	738-04162A	Shoulder Spacer, .8840 x .190
41	938-3056	Shoulder Bolt, .496 x 2.50:3/8-16
42	942-04053C	Blade
43	747-05067A	Front Deck Lift Rod
44	731-04651	Mulch Plug
45	747-05279	Deck Sway Rod
46	747-1116	Deck Release Handle Rod
47	754-04107	V Belt
48	756-04129B	Idler Pulley, 4.25"DIA
49	631-04092B	Chute Assembly
50	783-04414A	Center Skirt
51	783-04415	RH Skirt
52	783-05280	LH Belt Cover
53	783-05281	RH Belt Cover
54	783-05303	Idler Bracket
55	711-04565	Hinge Pin
56	732-04372	Torsion Spring
57	783-05030	Chute Bracket
58	736-0315	Flat Washer, .760 x 1.50 x .120
59	937-3000	Lube Fitting
60	738-1010A	Spindle Shaft
61	941-0919	Ball Bearing, .787ID x 1.85
62	748-0160A	Spacer, .790 ID x 1.25 OD x .175
63	750-1000	Spacer, .80 x 1.10 x 1.322
64	750-1349A	Spacer, .79 x 1.82 x .55


54" Deck



Ref.	Part Number	Description
1	12650	Height Adjust Bracket
2	96606	Retainer Hook Bracket
3	918-0671D	Spindle Assembly
4	683-0254B	Deck Hanger Bracket Assembly
5	983-04585	Deck Assembly
6	683-0459	Idler Assembly
7	703-2093	Inner Baffle
8	703-3279	Deflector Chute Stop
9	710-04095	Hex Screw, 3/8-16:1.00
10	710-04484	Taptite Screw, 5/16-18:.750
11	710-0521	Hex Screw, 3/8-16:3.00
12	710-0528	Hex Screw, 5/16-18:1.25
13	710-0597	Hex Screw, 1/4-20:1.00
14	710-0623	Taptite Screw, 3/8-16:0.750
15	710-0859	Hex Screw, 3/8-16:2.50
16	710-3103	Hex Screw, 5/16-18:2.00
17	710-3168	Carriage Bolt, 3/8-16:1.00
18	710-3178	Carriage Bolt, 3/8-16:0.75
19	911-0332	Clevis Pin, .50 DIA x .78 LG
20	911-3314	Roller Pin, 1/2 DIA x 7.31 LG
21	712-0229	Push Nut, 3/8
22	712-04063	Flangelock Nut, 5/16-18
23	712-04064	Flangelock Nut, 1/4-20
24	712-04065	Flangelock Nut, 3/8-16
25	712-0417A	Flange Nut, 5/8-18
26	712-04243	Flexlock Nut, 1/2-13
27	912-0641	Hex Nut, M16-1.5 DIN 936
28	912-3010	Hex Nut, 5/16-18
29	712-3022	Hexlock Nut, Counterlock, 1/2-13
30	914-0111	Cotter Pin, 3/32:1.0
31	914-0145	Click Pin, .092 x 1.64 LG
32	714-0162	Cotter Pin, 5/32:1.25
33	714-0220A	Lynch Pin, .1875
34	714-04040	Bow Tie Cotter Pin
35	914-0470	Cotter Pin, 1/8 x 1.25
36	715-0108	Spring Pin, 1/4 DIA x 1.00 LG
37	917-04074	Deck Gear
38	921-04041	Water Nozzle Adaptor
39	731-0335	Deck Roller
40	731-05679	Front Roller


Ref.	Part Number	Description
41	732-04652	Compression Spring, .535 OD x 1.751 LG
42	732-04692	Extension Spring, .85 OD x 5.915 LG
43	732-0934	Extension Spring, 1.15 OD x 5.99 LG
44	734-04155	Deck Wheel
45	936-0119	Lock Washer, 5/16
46	936-0179	Flat Washer, .531 x 1.25 x .100
47	736-0225	Lock Washer, 5/8
48	936-0300	Flat Washer, .406 x .875 x .059
49	936-0921	Lock Washer, 1/2
50	737-04003D	Deck Water Nozzle
51	738-0295	Shaft, .750 x .4712
52	738-1229A	Shield Screw, .625 x 2.50:1/2-13
53	938-3056	Shoulder Bolt, .496 x 2.50:3/8-16
54	942-0677B	Blade
55	747-04938	Belt Keeper Rod
56	747-05141A	Deck Lift Rod
57	937-3000	Lube Fitting
58	747-05284	Deck Sway Rod
59	747-1116	Deck Release Handle Rod
60	950-0212	Spacer, .82 ID x 1.00 OD x .53
61	750-04597	Spacer, .380 x .900 x 1.313
62	750-0933	Spacer, .385 ID x .88 x .64
63	954-04083	V Belt
64	756-04129B	Idler Pulley, 4.25"DIA
65	783-04013A	Pulley Stabilizer Bracket
66	783-04690B	Deck Skirt
67	783-04726	Stationary Idler Bracket
68	738-1197	Spindle Shaft, 6.95 LG
69	783-1470A	RH Spindle Cover
70	783-1471	LH Spindle Cover
71	941-0919	Ball Bearing, .787 ID x 1.85 OD x .551
72	748-0160A	Spacer, .790 ID x 1.25 OD x .175
73	750-1000	Spacer, .80 x 1.10 x 1.322 LG
74	750-1349A	Spacer, .79 x 1.82 x .55 LG
75	756-04216	Deck Pulley
76	631-04070A	Chute Assembly
77	711-04565	Hinge Pin
78	732-04372	Torsion Spring, .44 ID x 2.0
79	783-05030	Chute Bracket

Hood and Dash, 5 Style



Ref.	Part Number	Description
1	710-04484	Taptite Screw ,5/16-18:.750
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-0895	Hi-Lo Screw, 1/4-15:0.750
4	710-1017	Screw, 1/4-14:0.625
5	710-1611B	Taptite Screw ,5/16-18:0.750
6	714-04040	Bow Tie Cotter Pin
7	731-06169	Dash Panel
8	731-06639	Dash Lever
9	731-06642	Cruise Cover
10	747-05008	Control Rod
11	747-1196	Lever
12	783-04285F	RH Support Plate
13	783-04323F	LH Support Plate
14	710-04593	Taptite Screw ,5/16-18:0.375
15	710-0751	Hex Screw, 1/4-20:.620
16	712-04064	Flangelock Nut, 1/4-20
17	731-04949A	Grill Lens
18	731-05522A	Hood Scoop
19	738-04091A	Shoulder Screw, .43X.29:5/16-18
20	783-05454	Hood Pivot Bracket
21	783-05683	Hood
22	783-05685	Grill
23	751-0603A	Fuel Cap
24	751-0658E	Fuel Tank
25	925-0963	Lamp
26	925-1649	Lamp Socket
27	731-05165A	Plenum
28	946-04541	Throttle Control
29	946-04132	Choke Control
30	925-04227B	Key Switch Module
31	925-04036C	Hour Meter
32	925-04174	Electric PTO Switch
33	925-1745A	Key

Hood and Dash, C Style




Hood and Dash, C Style


Ref.	Part Number	Description
1	710-0192	Screw, #10-24:0.375
2	710-04484	Taptite Screw ,5/16-18:.750
3	710-0599	Taptite Screw ,1/4-20:0.500
4	710-0653	Taptite Screw, 1/4-20:0.375
5	710-0895	Hi-Lo Screw, 1/4-15:0.750
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	710-3217	Screw, #8-32:0.375
8	712-0142	Hex Nut, #8-32:GRA
9	714-0104	Cotter Pin, .072 DIA. X 1.13 LG
10	714-04040	Bow Tie Cotter Pin
11	731-05447A	Dash Lever, Cruise/Brake
12	731-05659	Steering Shaft Bushing
13	931-06553	Dash
14	731-1857	Control Knob
15	732-04580	Extension Spring, .500 DIA x 2.733 LG
16	747-05054	Control Rod
17	747-1323A	Rod, .250 DIA X 4.55 LG
18	783-04285F	RH Support Plate
19	783-04323F	LH Support Plate
20	783-05453A	Support Dash Bracket
21	783-1499	Bracket, Rod, Dash

Ref.	Part Number	Description
22	931-05765	Hood Assembly
23	683-04238	Bumper Assembly
24	710-05108	Screw, 1/4 DIA:.750
25	712-04065	Flangelock Nut, 3/8-16
26	725-0157	Cable Tie, 3/16 X .05 X 7.4
27	926-0154	Push Mount Cable Tie 7.5 LG
28	738-0143	Shoulder Bolt, .496 X .336:3/8-16
29	738-04091A	Shoulder Screw, .43 X .29:5/16-18
30	783-04606C	Hood Pivot Bracket
31	751-0603A	Fuel Cap
32	751-0658E	Fuel Tank, 3 Gallon
33	931-04577	Headlight Lens
34	925-0963	Lamp
35	925-1649	Lamp Socket
36	731-04679A	Plenum
37	925-04230B	Key Switch
38	746-04352	Throttle Control
39	746-1085A	Choke Control
40	925-04022B	Hour Meter
41	925-04174	Electric PTO Switch
42	925-1745A	Key

Engine Accessories, Kohler



Ref.	Part Number	Description
1.	683-04549	Shield Ass'y, Muffler
2.	710-0227	Screw, Ab, #8-18, 0.500,
3.	710-04683	Screw, Self-tapping, 3/8-16, 1.000,
4.	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
5.	710-1314A	Screw, Socket Head, 5/16-18, .750
6.	712-0271	Nut, Sems, 1/4-20
7.	751-3141-14	Hose, Extension, Oil Drain
8.	721-0377A	Gasket, Exhaust
9.	725-0157	Cable, Tie, 3/16 x .05 x 7.4
10.	726-0205	Clamp, Hose, .490 Dia.
11.	728-04000	Rivet, Pop, .188 Dia x .300
12.	751-10528A	Muffler, Intek Twin
13.	751-0564B	Deflector, Muffler
14.	751-10349	Hose, Fuel, Low Permeation, 1/4
15.	751-10353	Deflector, Muffler, Long
16.	951-10517A	Drain, Oil



Ref.	Part Number	Description
1	683-04549	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683	Taptite Screw, 3/8-16:1.000
4	710-0599	Taptite Screw, 1/4-20:0.500
5	710-1314A	Socket Head Screw, 5/16-18:.750
6	712-0271	Sems Nut, 1/4-20
7	783-06378A	Heat Shield
8	721-0460	Exhaust Gasket
9	725-0157	Cable Tie, 3/16 x .05 x 7.4

Ref.	Part Number	Description
10	726-0205	Hose Clamp, .490 DIA.
11	728-04000	Rivet, .188 DIA x .300 L
12	751-3141-14	Oil Drain Extension Hose
13	751-0564B	Muffler Deflector
14	751-10349	Fuel Hose
15	751-10353	Long Muffler Deflector
16	951-10517A	Oil Drain
17	751-10542A	Muffler Deflector

Electrical Schematic

