

ILLUSTRATED PARTS MANUAL



46" Hydrostatic Lawn Tractor, 900 Series

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank you for purchasing an MTD Lawn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Axle, Front	8	Mower Deck, 38-inch	16
Battery	4-7	Mower Deck, 42-inch	18
Dash Panel	22-27	Mower Deck, 46-inch	20
Deck Lift Handle/Linkage	10-13	Muffler	28-29
Drive System	14	Pedal Controls	14
Electrical Schematic	3	PTO Lever	4-7
Engine Accessories, Single	28	Seat	10-13
Engine Accessories, Twin	29	Solenoid	4-7
Fender	10-13	Steering Wheel	10-13
Frame	4-7	Switches, Interlock	4-7
Fuel Tank	22-25	Throttle/Choke Control	22-25
Head Lamps	22-25	Wheels, Front	10-13
Hood	22-25	Wheels, Rear	14
Meter, Systems Indicator	22-25		

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------

SERIAL NUMBER


-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------


Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:

0637	Black	0650	Metallic Red (White Outdoor)
0709	Dark Green (Bolens, Mastercraft, Yard-Man Domestic)	0665	Dark Green (Yard-Man Export)
0662	Oyster Gray (MTD Gold)	0629	Silver Flake (MTD Platinum)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)	04038	Day Orange (Daedong)
0691	Black Jack (MTD Gold, MasterCut)	04015	Fire Red (Massey Ferguson)
0674	Yellow (Yard-Man)	04033	Flint Mica (Troy-Bilt XP)


3







Ref.	Part Number	Description
1	647-04151	Handle Ass'y, PTO
2	710-04876	Hex Screw, 7/16-20, 3.50, Gr5
3	710-0599	Screw, Self-tapping, 1/4-20, 0.50
4	714-04040	Pin, Cotter, Bow-Tie 72
5	720-04049A	Grip, Handle, 3/8
6	732-0932	Spring, Ext, .38 Dia x 5.6
7	936-0171	Washer, Lock, 7/16, Regular Duty
8	736-0322	Washer, Flat, .450 x 1.250 x .164
9	738-04237A	Screw, Shoulder, #10-32, .500
10	741-04119A	Bearing, PTO
11	946-04618	Cable, Engag, Deck
12	750-0956	Spacer, 1.010 x 1.400 x .825
13	956-04067A	Pulley, Engine, 3.56 x 6.12 Dia.
14	683-04469A	Frame Ass'y, Lower
15	710-04484	Screw, Self-tapping, 5/16-18, .750,
16	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
17	712-04065	Nut, Flange Lock, 3/8-16, Grf,
18	738-04058	Spacer, Shoulder, .38 x 1.0 x .70
19	747-04121A	Rod, Battery
20	783-0349	Tray, Battery
21	783-06089	Bracket, Frame, Seat
22	925-1707D	Battery
23	710-04666	Hex Flange Screw, 1/4-20, .75, Gr5
24	712-0271	Nut, Sems, 1/4-20
25	710-0653	Screw, Self-tapping, 1/4-20, 0.375,
26	712-04064	Nut, Flange Lock, 1/4-20, Grf,
27	725-04232	Switch, 3-Pole
28	725-04363	Switch, Interlock
29	725-04439	Solenoid, 12V
30	725-04807	Switch, Plunger, Snap Mount
31	747-05171	Belt Keeper Rod

Electric PTO and Battery



Ref.	Part Number	Description
1	683-04469A	Frame
2	710-04484	Taptite Screw, 5/16-18:.750
3	710-3005	Hex Head Screw, 3/8-16:1.25
4	712-04065	Flangelock Nut, 3/8-16
5	738-04058	Shoulder Spacer, .38 x 1.0 x .70
6	747-04121A	Battery Holder Rod
7	783-0349	Battery Tray
8	783-06089	Seat Frame Bracket
9	710-04379A	Hex Head Screw, 7/16-20:3.50
10	917-04163A	Electric PTO Clutch
11	725-0157	Cable Tie, 3/16 x .05 x 7.4
12	936-0171	Lock Washer, 7/16
13	736-0277	Flat Washer, 1.031 x 1.620 x .095
14	756-0978B	Electric PTO Engine Pulley
15	925-1707D	Battery
16	710-0653	Taptite Screw, 1/4-20:0.375
17	712-04064	Flangelock Nut, 1/4-20
18	725-04363	Interlock Switch
19	725-04439	Solenoid, 12 V
20	738-04237A	Shoulder Screw, #10-32:.500
21	710-04666	Hex Head Flange, 1/4-20:.75
22	712-0271	Sems Nut, 1/4-20
23	747-05171	42" Belt Keeper Rod


Steering and Axle



Ref.	Part Number	Description
1	710-04095	Hex Screw, 3/8-16, 1.00, Gr5, Spec
2	710-0514	Hex Screw, 3/8-16, 1.00, Gr5, Std
3	710-0643	Hex Screw, 5/16-18, 1.00, Gr5, Lock
4	711-04998	Link, Drag LH
5	711-04999	Link, Drag RH
6	912-0240	Nut, Jam, 7/16-20, Gr2
7	712-04065	Nut, Flange Lock, 3/8-16, Grf,
8	712-0459	Nut, Flange Lock, 7/16-20, Grb, Lock
9	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
10	717-1550F	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20, Lock
13	936-3004	Washer, Flat, .406 x .875 x .105
14	736-3084	Washer, Flat, .51 x 1.12 x .06
15	938-04034	Axle Ass'y, RH .750 Dia (46" Deck)
—	638-04021	Axle Ass'y, RH .750 Dia (38" & 42")
16	738-04263	Shaft, Steering, .625 OD x 24.25
17	738-04363	Spacer, Shoulder, .385x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375, Special, 46" Only
—	738-04363	38" & 42" Decks
19	741-04237B	Bearing, Flange, Hex 5/8 Pm
20	783-06043	Bracket, Support, Steering
21	638-04035P	Axle Ass'y, LH .750 Dia (46" Deck)
—	638-04027	Axle Ass'y, LH .750 Dia (38" & 42")
22	710-0395	Hex Screw, 5/16-18, 2.25, Gr5, Std

Ref.	Part Number	Description
23	710-0859	Hex Screw, 3/8-16, 2.50, Gr5, Std
24	710-3180	Hex Screw, 5/16-18, 1.75, Gr5, Std
25	912-0214	Nut, Hex Lock, 3/8-24, Grb
26	712-04063	Nut, Flange Lock, 5/16-18, Grf
27	714-0162	Pin, Cotter, 5/32, 1.25
28	719-04413A	Axle, Pivot Bar, Cast
29	748-04065	Steering, Block
30	748-04068	Spacer, .71 ID x .125 OD x .56
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04028	Steering Wheel, Standard Grip
—	631-04008A	Steering Wheel, Soft Grip
33	731-04040	Cap, Sprig, Small
—	731-04039	Cap, Small
34	634-04406	Wheel Assembly
35	734-1731	Tire, 15 x 6 x 6
36	634-04405	Rim Assembly, Plastic Bearing, 46"
—	934-04091A	Rim Assembly, Ball Bearing, 38" & 42"
37	934-0255	Tubeless Air Valve
38	741-0516B	Flange Bearing, .760 x 1.00 x 1.20
39	741-0990B	Flange Bearing, .760 ID
40	731-05674	Cap, Bumper, 46"
—	931-3020	Cap, Bumper, 38" & 42"
41	736-04228A	Washer, Flat, .350 x 1.559 x .062, 46"
—	736-0866	Washer, Flat, .755 x 1.92 x .060, 38" & 42"
42	741-04137	Bearing, Ball, .750 x 1.750, 38" & 42"


Seat and Fender, 46"



Ref.	Part Number	Description
1	683-04223	Shaft Ass'y, Lift
2	712-04063	Nut, Flange Lock, 5/16-18, Grf
3	712-04065	Nut, Flange Lock, 3/8-16, Grf
4	914-0104	Pin, Cotter, .072 Dia. x 1.13
5	714-04040	Pin, Cotter, Bow-Tie 72
6	716-0106A	Ring, E Type, .625 Dia. Shaft
7	720-0311	Grip, Handle, 1/2
8	732-0874	Spring, Torsion
9	736-0105	Washer, Spring, .401 x .870 x .063
10	738-0138A	Screw, Shoulder, .437 x .470, 5/16-18
11	938-0380	Bolt, Shoulder, .500, 3/8-16
12	941-0225	Bearing, Hex Flange
13	746-0968	Cable, Lift, 16.16
14	747-04962A	Handle, Lift,
15	756-04331	Pulley, Roller, Cable
16	783-05546A	Lift Link
17	710-04484	Screw, Self-tapping, 5/16-18, .750,
18	710-0528	Hex Screw, 5/16-18, 1.25, Gr5, Std
19	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
20	710-0895	Screw, HL, 1/4-15, 0.750,
21	731-06795	Cover, Lift Lever

Ref.	Part Number	Description
22	731-1993A	Cover w/ Cup Holder
23	735-0690	Grommet, .4375 ID x .750
24	736-3078	Washer, Flat .344 x 1.00 x .063
25	750-3310	Spacer, Flange, .3125 x .4375 x .625
26	783-06259	Fender
27	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
28	720-04061	Knob, 3/8-16, .875
29	725-0157	Cable, Tie, 3/16 x .05 x 7.4
30	732-04561	Spring, Compr, 1.71 x 3.735 x .238
31	938-0296	Screw, Shoulder, .437 x .268, 5/16-18
32	783-06049	Bracket, Mounting, Seat
33	783-06088	Bracket, Pivot, Seat
34	783-06266	Bracket, Knob Adjustment, Seat
35	783-06448	Clip, Retaining, Switch
36	726-3046	Clip, Ratchet, .250 Dia
37	735-04138	Pad, Foot, LH
38	735-04158	Pad, Foot, RH
39	757-04081	Seat, Medium Back
40	925-05013	Switch, Seat
41	783-06443	Bracket, Lift, Man PTO, 6 Pos

Seat and Fender, 38" & 42"




Seat and Fender, 38" & 42"

Ref.	Part Number	Description
1	683-04223	Lift Shaft Assembly
2	712-04063	Flangelock Nut, 5/16-18
3	712-04065	Flangelock Nut, 3/8-16
4	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
5	914-0111	Bow-Tie Cotter Pin
6	716-0106A	E-Ring, .625 DIA. SHAFT
7	720-0311	Handle Grip
8	732-0874	Torsion Spring
9	736-0105	Spring Washer, .401 x .870 x .063
10	738-0138A	Shoulder Screw, .437 x .470:5/16-18
11	738-04130	Shoulder Bolt, .625 x .175:3/8-16
12	941-0225	Hex Flange Bearing
13	746-0968	Lift Cable, 16.16 LG
14	747-04962A	Lift Handle
15	756-04331	Pulley Roller Cable
16	783-04494B	Lift Arm, RH
—	783-04711B	Lift Arm, LH
17	710-04484	Taptite Screw, Washer, 5/16-18:.750
18	710-0528	Hex Screw, 5/16-18:1.25
—	710-1260A	Taptite Screw, 5/16-18:.750, 42"
19	710-0599	Taptite Screw, Lock Washer, 1/4-20
20	710-0895	Hi-Lo Screw, Lock Washer, 1/4-15
21	731-06584	Fender Cover Door

Ref.	Part Number	Description
22	731-06676	LH Fender Cover
23	731-06700	RH Fender Cover
24	735-0690	Grommet, .4375 x .750, 38" Only
25	736-3078	Flat Washer, .344 x 1.00 x .063 HDN
26	747-05039	Door Pin
27	750-3310	Spacer, .3125 x .4375, 38" Only
28	783-06118	Fender
29	710-04482	Hex Head Flange, 3/8-16:.875
30	712-3004A	Flangelock Nut, 5/16-18
31	725-0157	Cable Tie, 3/16 x .05 x 7.4
32	732-04561	Comp. Spring, 1.71 x 3.735 x .238
33	732-04563	Comp. Spring, .68 x 1.065 x .055
34	938-0296	Shoulder Screw, .437 x .268:5/16-18
35	783-06049	Seat Mounting Bracket
36	783-06050	Seat Adjustment Lever
37	783-06088	Seat Pivot Bracket
38	783-06448	Switch Retainer Clip
39	726-3046	Ratchet Clip
40	735-04137	LH Foot Pad
41	735-04139	RH Foot Pad
42	925-05013	Seat Switch
43	757-04086	Seat
44	783-06181	Lift Bracket

Drive and Rear Wheels




Drive and Rear Wheels

Ref.	Part Number	Description
1	918-0319	Hydro Transmission
2	710-0176	Hex Screw, 5/16-18:2.75
3	710-0227	Screw, #8-18:0.500
4	710-0351	Screw, #10-16:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0653	Taptite Screw, 1/4-20:0.375
7	710-1007	Screw, Sems, 3/8-16, 1.500
8	710-1325	Taptite Screw, 1/4-20:1.625
9	710-3011	Hex Screw, 3/8-16:2.25
10	712-0240	Jam Nut, 7/16-20
11	712-0346	Nut, Jamlock, 1/2-20
12	712-04063	Flangelock Nut, 5/16-18
13	712-0431	Flangelock Nut, 3/8-16
14	914-0111	Cotter Pin, 3/32:1.0
15	725-0157	Cable Tie, 3/16 X .05 X 7.4
16	725-04791A	Jumper Harness
17	725-1644	Short Spring Switch
18	926-0154	Push Mount Cable Tie 7.5 LG
19	926-0320	Insulator Nut Plate
20	731-05299A	Sleeve, .765 ID x 1.500 LG, 46"
—	731-05300A	Sleeve, .765 ID x 2.410 LG, 38" & 42"
21	731-06098	Hydro Fan
22	932-0209	Extension Spring, .48 OD X 2.03
23	732-04606	Extension Spring, .500 DIA X 12.6 LG
24	732-04624	Extension Spring, 1.00 DIA X 4.75
25	732-0716D	Extension Spring, .59 OD X 4.00 LG
26	732-0729	Wire Ring
27	732-3118	Extension Spring, .375 OD X 1.44 LG
28	936-0264	Washer, Flat, .330 X .630 X .0635
29	736-04263	Washer, Lock, TRANS HYDRO
30	936-3008	Washer, Flat, .344 X .750 X .120
31	736-3010	Washer, Flat, .407X.812X.135:HT
32	647-04152A	Brake Control Assembly, 46"
—	647-04152B	Brake Control Assembly, 38" & 42"
33	683-04537	Hydro Pedal Bracket Assembly
34	738-04420	Spacer, Shoulder, 1.375 X .380 X .183
35	747-04139	Rod, Brake, Hydro
36	747-04957A	Rod, Transmission, Footpedal Bypass
37	747-04979	Rod, Control, Hydro
38	747-04991	Rod, Hydro Bypass

Ref.	Part Number	Description
39	750-04456	Spacer, .260 X .372 X 1.420 LG
40	954-04207	Belt, V Type, Poly
41	756-04224	Pulley, Idler, Flat 2.75 OD
42	756-04308	Pulley, Input, 4.13 DIA
43	756-04325	Pulley, Idler, V-Type x 3.06
44	783-06027A	Bracket, Idler, Center Double
45	783-06133	Bracket, Mount, Hydro
46	783-06260	Bracket, Support, Belt Disengage
47	783-1019B	Switch Actuator Bracket
48	710-0604A	Taptite Screw, 5/16-18:0.625
49	711-05068	Clevis Pin, 5/16 x 3.985
50	712-04065	Flangelock Nut, 3/8-16
51	714-04040	Bow-Tie Cotter Pin
52	719-0584B	Control Pedal
53	726-0214	Push Cap
54	732-04587	Extension Spring, .63 DIA x 4.95 LG
55	735-04136	Brake Pedal Pad
56	736-0242	Washer, Bell, .340 x .872 x .060
57	938-0380	Shoulder Bolt, .500 x .270:3/8-16
58	741-0495	Flange Bearing, .630 ID x .695 OD x .60
59	748-04203	Cruise Latch
60	783-05914	Pedal Support Bracket
61	783-05940	Pedal Support Bracket, 5/8
62	783-06103A	Brake Pedal Bracket
63	731-2290A	Hub Cap
64	736-0430	Washer, Flat, .350 x 1.59 x .062
65	634-0104	Wheel Assembly
66	710-0627	Hex Screw, 5/16-24 x .750
67	634-04369	Rim Assembly, Plastic Bead, 46"
68	934-0255	Tubeless Air Valve
69	734-1730-0901	Tire, 20 x 8 x 8, 38" & 46"
—	734-1873-0901	Tire, 20 x 10 x 8, 42"
70	941-0490	Axle Hub
71	683-04488	Hydro Pedal Bracket Assembly
72	735-04118A	Reverse Pedal Pad
73	735-04135	Forward Pedal Pad
74	783-06059	Drive Pedal Bracket
75	918-04228	Wheel Assembly Hub, 38" & 42"
76	710-0627	Hex Screw, 5/16-24:.750
77	736-0242	Washer, Bell, .340 x .872 x .060


38" Deck



Ref.	Part Number	Description
1	618-04495A	Spindle Assembly, Pulley, 5.75" Dia
2	683-0254B	Bracket Assembly, Deck, LH Hanger
3	983-04264B	Deck Assembly, 38"
4	683-04541	PTO Cover
5	710-0347	Hex Screw, 3/8-16:1.75
6	710-04484	Taptite Screw, 5/16-18:.750
7	710-0528	Hex Screw, 5/16-18:1.25
8	710-0599	Taptite Screw, 1/4-20:0.500
9	710-3015	Hex Screw, 1/4-20:.75
10	710-3085	Hex Screw, 3/8-16:3.50
11	712-04065	Flangelock Nut, 3/8-16
12	712-0417A	Flange Nut, 5/8-18
13	712-04243	Flexlock Nut, 1/2-13
14	712-3006	Hex nut, 1/4-20
15	914-0470	Cotter Pin, 1/8 x 1.25
16	917-04074	Deck Gear
17	726-0233	Nut, Push, .25 ID X .50 OD
18	732-04247	Extension Spring, .850" DIA X 6.415 LG
19	732-04652	Comp. Spring, .535 OD x 1.751 LG
20	734-0973	Wheel, Deck, 5.0 x 1.38
21	936-0119	Washer, Lock, 5/16
22	736-0270	Washer, Bell, .265 X.75 X .062
23	936-0300	Flat Washer, .406 x .875 x .059
24	736-0317	Washer, Bell, .63 X 1.25 X .18
25	938-0373	Bolt, Shoulder, .496 X 1.525:3/8-16

Ref.	Part Number	Description
26	738-04162A	Spacer, Shoulder, .8840 X .190
27	942-0610A	Blade, 19.38", Star 3 in 1
28	747-04322	Rod, Deck, 38" Front Adjust
29	747-1116	Rod, Handle, Deck Release
30	750-04446	Spacer, 3/8 ID X .68 OD X 1.46 LG
31	954-04198C	V Belt, 88.80
32	756-04129B	Pulley, Idler, 4.25"DIA
33	710-0134	Scre, Carriage, 1/4-20 x .62
34	783-04602A	Cover, Belt, 5.66 DIA
35	783-04740	Bracket, Cable, Deck Engage
36	783-06388	Bracket, Idle
37	731-2363	Plug, Mulch
38	712-3087	Nut, Wing, 1/4-20
39	631-0216A	Chute, Deflector
40	703-1693A	Bracket, Mount, Hinge
41	911-0792	Pin, Hinge, .25 DIA x 6.75 LG
42	926-0106	Nut, Speed, Cap, 1/4 Rod
43	732-04537	Spring, Torsion
44	937-3000	Lube Fitting
45	938-04241	Spindle Shaft, 5.50 LG
46	941-0919	Ball Bearing, .787 ID x 1.85 OD x .551
47	750-04739	Spacer, .820 x 1.150 x .480 LG
48	750-1000	Spacer, .80 x 1.10 x 1.322 LG
49	756-1188	Deck Pulley, 5.75 DIA
NS	783-1297	Skirt, Deck, 38"


42" Deck



Ref.	Part Number	Description
1	918-04822A	Spindle Assembly, Pulley, 6.3
2	683-0254B	Deck Hanger Bracket Assembly
3	683-04598	Deck Assembly
4	710-04484	Taptite Screw, Washer, 5/16-18:.750
5	710-0514	Hex Head Screw, 3/8-16:1.00
6	710-0528	Hex Head Screw, 5/16-18:1.25
7	710-0599	Taptite Screw, Washer, 1/4-20:0.500
8	710-3144	Hex Head Screw, 3/8-16:2.00
9	710-3178	Carriage Bolt, 3/8-16:0.75
10	712-0229	Push Nut, 3/8
11	712-04065	Flangelock Nut, 3/8-16
12	712-0417A	Flange Nut, 5/8-18
13	712-04243	Lock Nut, 1/2-13
14	912-0641	Hex Nut, M16-1.5 DIN 936
15	753-04070	Lynch Pin, .1875
16	914-0470	Cotter Pin, 1/8 X 1.25
17	917-04074	Deck Gear
18	921-04041	Water Nozzle Adaptor
19	731-06496	Cover, Belt, Universal
20	732-0459C	Extension Spring, .94 DIA. X 6.74 LG
21	732-04652	Comp. Spring, .535 OD X 1.751 LG
22	734-04155	Front Deck Wheel
23	734-0973	Rear Deck Wheel
24	936-0119	Lock Washer, 5/16
25	936-0179	Flat Washer, .531 X 1.25 X .100
26	736-0225	Lock Washer, 5/8
27	736-0258	Flat Washer, .385 X 1.0 X .135

Ref.	Part Number	Description
28	736-0262	Flat Washer, .385 X .870 X .092
29	736-0317	Bell Washer, .63 X 1.25 X .18
30	936-0344	Flat Washer, .385 X 1.0 X .030
31	737-04003D	Water Nozzle
32	938-0373	Shoulder Bolt, .496 X 1.525:3/8-16
33	738-04162A	Shoulder Spacer, .8840 X .190
34	938-3056	Shoulder Bolt, .496 X 2.50:3/8-16
35	942-04312	2-in-1 Cutting Blade
36	747-04944B	Deck Lift Rod
37	631-04349	Chute Deflector
38	747-1116	Deck Release Handle Rod
39	954-04060B	V-Belt
40	756-04129B	Idler Pulley, 4.25"DIA
41	711-04847A	Hinge Pin
42	783-04740	Deck Engage Cable Bracket
43	732-04372	Torsion Spring
44	783-05946	Idler Bracket
45	783-06243	Deck Engage Cable Bracket
46	783-06368	4.25 Pulley Belt Guard Bracket
47	783-06632	Deck Stop
48	783-06643	Deck Idler Support Bracket
49	783-06074A	Chute Bracket
50	936-0351	Flat Washer, .760 IDX1.50 OD
51	738-1186A	Spindle Shaft, 6.05 LG.
52	941-0919	Ball Bearing, .787ID X 1.85 ODX.551
53	750-04936	Spacer, .792 X 1.060 X 1.860 LG
54	956-1227	Deck Pulley, 6.3 DIA


46" Deck



Ref.	Part Number	Description
1	918-04636A	Spindle Ass'y, Pulley, 6.93 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck
4	983-04525	Brake Ass'y, Deck
5	983-04578	Deck Ass'y, Offset
6	710-04484	Screw, Self-tapping, 5/16-18, .750,
7	710-0514	Hex Screw, 3/8-16, 1.00
8	710-0528	Hex Screw, 5/16-18, 1.25
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
10	710-0778	Screw, Self-tapping, 1/4-20, 1.500,
11	710-0809	Screw, Self-tapping, 1/4-20, 1.250,
12	710-1003	Screw, #10-16:.625
13	710-3144	Hex Screw, 3/8-16, 2.00
14	710-3178	Bolt, Carriage, 3/8-16, 0.75
15	712-0229	Nut, Push, 3/8
16	712-04063	Nut, Flange Lock, 5/16-18
17	712-04065	Nut, Flange Lock, 3/8-16
18	712-0417A	Nut, Flange, 5/8-18
19	712-04243	Nut, Lock, 1/2-13
20	912-0641	Nut, Hex, M16-1.5
21	753-04070	Pin, Lynch, .1875
22	914-0470	Pin, Cotter, 1/8 x 1.25
23	917-04074	Gear, Deck, Adjustment
24	731-06496	Belt Cover
25	932-0384	Spring, Extension, .62 Dia x 6.12
26	732-04652	Spring, Comp, .535 OD x 1.751
27	732-04727	Spring, Torsion, .992 I.D x 1.17 O.D
28	734-04155	Wheel, Deck, 5.0 Dia Ball
29	936-0119	Washer, Lock, 5/16, Regular Duty
30	936-0176	Washer, Flat, .265 x .938 x .120
31	936-0179	Washer, Flat, .531 x 1.25 x .100
32	736-0187	Washer, Flat, .64 x 1.24 x .06,
33	736-0225	Washer, Lock, 5/8, Int Tooth
34	736-0262	Washer, Flat, .385 x .870 x .092


Ref.	Part Number	Description
35	736-0317	Washer, Bell, .63 x 1.25 x .18
36	736-0344	Washer, Flat, .385 x 1.0 x .030
37	736-0362	Washer, Flat, .330 x 1.25 x .06,
38	738-04146	Plug, Bolt, M16 x 1.5
39	738-04162A	Spacer, Shoulder, .8840 x .190
40	738-04166	Spacer, Shoulder, .5000 x .1475
41	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
42	942-04290	Blade
43	747-04530	Rod, Keeper, Belt
44	747-04944A	Rod, Lift, Deck, Frt, 13.7
45	747-05011	Rod, Keeper, Belt
46	747-05052	Rod, Control, Brake
47	756-04356	Pulley, Deck, 6.93 Dia
48	747-1116	Rod, Handle, Deck Release
49	750-0258	Spacer, .315 x .750 x .375
50	750-0566A	Spacer, .260 x .375 x 1.030
51	751B221535	Clamp, Casing
52	954-04219	Belt, V-Type
53	756-04129B	Pulley, Idler, 4.25"Dia
54	937-3000	Fitting, 3/16, Lnc#70, Drive Lube
55	738-1186A	Shift, Spindle, 6.11.
56	783-05946	Bracket, Idler, Pivot
57	783-06243	Bracket, Cable, Deck Engage
58	783-06368	Bracket, Guard, Belt, 4.25 Pulley
59	783-06643	Bracket, Support, Deck Stationary Idler
60	783-06074A	Bracket, Chute
61	631-04461	Chute Ass'y, Deflector
62	732-04372	Torsion Spring, .44 ID x 2.0
63	941-0919	Ball Bearing, .787 ID x 1.85 OD x .551
64	750-04936	Spacer, .792 x 1.060 x 1.860
65	711-04847A	Hinge Pin
66	737-04003D	Deck Water Nozzle
67	921-04041	Water Nozzle Adaptor

Hood and Dash, 5 Style



Ref.	Part Number	Description
1	710-04484	Taptite Screw ,5/16-18:.750
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-0895	Hi-Lo Screw, 1/4-15:0.750
4	710-1017	Screw, 1/4-14:0.625
5	710-1611B	Taptite Screw ,5/16-18:0.750
6	714-04040	Bow Tie Cotter Pin
7	925-1649	Lamp Socket
8	731-06167	Dash Panel
9	731-06639	Dash Lever
10	731-06642	Cruise Cover
11	747-05008	Control Rod
12	747-1196	Lever
13	783-04285F	RH Support Plate
14	783-04323F	LH Support Plate
15	751-0603A	Fuel Cap
16	710-04593	Taptite Screw ,5/16-18:0.375
17	710-0751	Hex Screw, 1/4-20:.620
18	712-04064	Flangelock Nut, 1/4-20
19	731-04949A	Grill Lens
20	731-05522A	Hood Scoop
21	738-04091A	Shoulder Screw, .43X.29:5/16-18
22	783-05454	Hood Pivot Bracket
23	783-05683	Hood
24	783-05685	Grill
25	751-0659D	Fuel Tank
26	731-1999	Choke Plug
27	925-04227B	Key Switch Module
28	746-04364	Throttle/Choke Control
29	925-1745A	Key
30	925-04036C	Hour Meter
31	925-0963	Lamp
—	726-04096	Choke Hole Plug (Not Shown)

Hood and Dash, C Style




Hood and Dash, C Style

Ref.	Part Number	Description
1	710-0192	Screw, #10-24:0.375
2	710-04484	Taptite Screw ,5/16-18:.750
3	710-0599	Taptite Screw ,1/4-20:0.500
4	710-0653	Taptite Screw, 1/4-20:0.375
5	710-0895	Hi-Lo Screw, 1/4-15:0.750
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	710-3217	Screw, #8-32:0.375
8	712-0142	Hex Nut, #8-32:GRA
9	914-0104	Cotter Pin, .072 DIA. X 1.13 LG
10	714-04040	Bow Tie Cotter Pin
11	731-05447A	Dash Lever, Cruise/Brake
12	731-05659	Steering Shaft Bushing
13	931-06553	Dash
14	731-1857	Control Knob
15	732-04580	Extension Spring, .500 DIA x 2.733 LG
16	747-05054	Control Rod
17	747-1323A	Rod, .250 DIA X 4.55 LG
18	783-04285F	RH Support Plate
19	783-04323F	LH Support Plate
20	783-05453A	Support Dash Bracket
21	783-1499	Bracket, Rod, Dash
22	931-05765	Hood Assembly


Ref.	Part Number	Description
23	683-04238	Bumper Assembly
24	710-05108	Screw, 1/4 DIA:.750
25	712-04065	Flangelock Nut, 3/8-16
26	725-0157	Cable Tie, 3/16 X .05 X 7.4
27	926-0154	Push Mount Cable Tie 7.5 LG
28	738-0143	Shoulder Bolt, .496 X .336:3/8-16
29	738-04091A	Shoulder Screw, .43 X .29:5/16-18
30	783-04606C	Hood Pivot Bracket
31	931-04577	Headlight Lens
32	925-0963	Lamp
33	925-1649	Lamp Socket
34	751-0603A	Fuel Cap
35	751-0658E	Fuel Tank, 3 Gallon
36	731-04569A	Plenum
37	746-04352	Throttle Control, 42"
—	946-1084	Throttle Control, 38"
38	746-1085A	Choke Control, 42"
—	946-1088	Choke Control, 38"
39	925-04022B	Hour Meter
40	925-04174	Electric PTO Switch
41	925-04230B	Key Switch
42	925-1745A	Key

Fuel Tank, K Hood and Dash




Ref.	Part Number	Description
1.	731-06168	Dash Assembly, K-Style, Elect PTO
2.	710-0599	Screw, Self-tapping, 1/4-20, 0.500
3.	710-0607	Screw, Self-tapping,, 5/16-18, 0.500
4.	710-0895	Screw, HL, 1/4-15, 0.750
5.	710-1017	Screw, Ab, 1/4-14, 0.625
6.	710-1611B	Screw, Self-tapping, 5/16-18, 0.750
7.	714-04040	Pin, Cotter, Bow-Tie 72
8.	731-06639	Lever, Dash, K Style
9.	731-06642	Cover, Cruise
10.	732-04580	Spring, Extension, .500 Dia X 2.733
11.	735-0271A	Bumper, .62 Dia X .3
12.	747-05008	Rod, Control, Latch
13.	747-1196	Rod, Lever, Bent
14.	783-04285F	Support, Dash, Plate, RH
15.	783-04323F	Support, Dash, Plate LH
16.	925-1649	Socket, Lamp
17.	925-0963	Lamp, 12v
18.	710-05108	Hex Screw, 1/4, .75
19.	731-06095	Lens, LH
20.	731-06096	Lens, RH
21.	931-06796	Grille, K-Style (no Troy-Bilt)
	631-04272	Grille, K-Style (Troy-Bilt)
22.	710-0642	Screw, Self-tapping, 1/4-20, 0.750,
23.	747-04161	Support Rod, Tank
24.	747-04946	Support Rod, Tank
25.	751-0603A	Cap, Fuel
26.	751-10609	Tank, Fuel, 2.5 Gal.
27.	746-04364	Cable, Throttle/Choke (Single Cyl)
	946-04417	Cable, Throttle (Kohler Twin)
28.	746-1085A	Choke Control (Kohler Twin)
29.	731-1999	Plug, Choke (Single Cyl)
30.	925-04227B	Module Switch, Ignition
31.	925-04036C	Meter, Indicator (Hour)
	925-04156	Ammeter, Indicator
32.	925-1745A	Key, Ignition
33.	925-1752	PTO Switch
34.	683-04441	Hood, K-Style

Engine Accessories, Single



Ref.	Part Number	Description
1	683-04549	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683	Taptite Screw, 3/8-16:1.000
4	710-0599	Taptite Screw, 1/4-20:0.500
5	710-1314A	Socket Head Screw, 5/16-18:.750
6	710-1652	Taptite Screw, 1/4-20 x .625
7	712-0271	Sems Nut, 1/4-20
8	751-3141-14	Extension Hose, Oil Drain

Ref.	Part Number	Description
9	725-0157	Cable Tie, 3/16 x .05 x 7.4
10	726-0205	Hose Clamp, .490 DIA.
11	728-04000	Rivet, .188 DIA x .300 L
12	751-11022A	Muffler
13	751-0564B	Muffler Deflector
14	751-10349	Fuel Hose
15	751-10353	Long Muffler Deflector
16	951-10517A	Oil Drain



Ref.	Part Number	Description
1	683-04549	Shield Ass'y, Muffler
2	710-0227	Screw, Ab, #8-18, 0.500,
3	710-04683	Screw, Self-tapping, 3/8-16, 1.000,
4	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
5	710-1314A	Screw, Socket Head, 5/16-18, .750
6	712-0271	Nut, Sems, 1/4-20
7	751-3141-14	Hose, Extension, Oil Drain
8	721-0377A	Gasket, Exhaust
9	725-0157	Cable, Tie, 3/16 x .05 x 7.4
10	726-0205	Clamp, Hose, .490 Dia.
11	728-04000	Rivet, Pop, .188 Dia x .300
12	751-10528A	Muffler, Kohler Twin
13	751-0564B	Deflector, Muffler
14	751-10349	Hose, Fuel, Low Permeation, 1/4
15	751-10353	Deflector, Muffler, Long
16	951-10517A	Drain, Oil