


# REPLACEMENT PARTS - MODEL 316.791210


## 4-CYCLE TRIMMER



| Item | Part No.   | Description                            |
|------|------------|----------------------------------------|
| 1    | 753-06113  | Engine Cover Assembly (includes 2 & 3) |
| 2    | 753-04595  | Cover Screw                            |
| 3    | 791-181003 | Screw                                  |
| 4    | 753-05901  | Rocker Cover                           |
| 5    | 753-05902  | Rocker Cover O-Ring                    |
| 6    | 753-05910  | Cylinder O-Ring                        |
| 7    | 791-182379 | Breather Hose                          |
| 8    | 753-05408  | Oil Plug (includes 9)                  |
| 9    | 791-182290 | Oil Plug O-Ring                        |
| 10   | 753-06111  | Crankcase Cover                        |
| 11   | 753-05238  | Crankcase Cover O-ring                 |
| 12   | 753-06221  | Flywheel Assembly                      |
| 13   | 753-05264  | Lead Wires                             |
| 14   | 753-05447  | Module Assembly                        |
| 15   | 753-05245  | Muffler Assembly (includes 16 & 17)    |
| 16   | 753-05244  | Muffler Gasket                         |

| Item | Part No.   | Description                                                          |
|------|------------|----------------------------------------------------------------------|
| 17   | 753-05246  | Muffler Screw                                                        |
| 18   | 753-05784  | Spark Plug                                                           |
| 19   | 753-05247  | Insulator Gasket                                                     |
| 20   | 753-05248  | Nut                                                                  |
| 21   | 753-05249  | Insulator                                                            |
| 22   | 753-05366  | Carburetor Gasket                                                    |
| 23   | 753-06258  | Carburetor w/Primer                                                  |
| 24   | 791-181751 | Air Cleaner O-Ring                                                   |
| 25   | 753-05831  | Air Cleaner Cover Assembly (includes 26)                             |
| 26   | 753-05254  | Air Filter                                                           |
| 27   | 753-05253  | Screw                                                                |
| 28   | 753-06240  | Fuel Tank Assembly w/Fuel Lines (includes 29)                        |
| 29   | 753-1229   | Fuel Cap                                                             |
| 30   | 753-05259  | Fuel Tank Pads                                                       |
| 31   | 753-06498  | Starter Housing Assembly (includes 3)                                |
| 32   | 753-06281  | Clutch Assembly                                                      |
| 33   | 753-05263  | Clutch Cover (includes 2)                                            |
| 34   | 791-182519 | Anti-Rotation Screw                                                  |
| 35   | 753-04003  | Clamp Screw                                                          |
| 36   | 791-180217 | Nut                                                                  |
| 37   | 791-181025 | Rocker Cover Screw                                                   |
| 38   | 753-06317  | Shortblock Assembly (includes Crankcase, Cylinder, 3-9, 11, 14 & 18) |
| 39   | 753-05078  | Spacer                                                               |

# REPLACEMENT PARTS - MODEL 316.791210 4-CYCLE TRIMMER



| Item | Part No.   | Description                              |
|------|------------|------------------------------------------|
| 1    | 753-04234  | Throttle Housing Assembly (includes 2-4) |
| 2    | 753-04119  | Throttle Trigger                         |
| 3    | 791-182690 | Throttle Trigger Spring                  |
| 4    | 791-182405 | Switch Assembly                          |
| 5    | 753-05266  | Throttle Cable Assembly                  |
| 6    | 753-04236  | Upper Drive Shaft Assembly               |
| 7    | 753-06039  | D-Handle Assembly (includes 8)           |
| 8    | 753-06040  | Handle Hardware                          |
| 9    | 753-1190   | Split Boom Coupler (includes 10-13)      |
| 10   | 791-181981 | Adjustment Knob (includes 13)            |
| 11   | 791-182057 | Coupler Anti-Rotation Screw              |
| 12   | 791-181617 | Coupler Bolt                             |
| 13   | 753-04386  | Adjustment Knob Nut                      |
| 14   | 791-182387 | Lower Drive Shaft Housing (includes 15)  |
| 15   | 791-181852 | Lower Flexible Drive Shaft               |
| 16   | 791-180531 | Shield Mount Screw Assembly              |
| 17   | 753-05032  | Shield Assembly (includes 18)            |
| 18   | 753-05033  | Blade Assembly                           |
| 19   | 791-153597 | Lower Clamp Assembly (includes 20)       |
| 20   | 791-145569 | Anti-Rotation Screw                      |
| 21   | 753-05050  | Bushing Housing Assembly                 |
| 22   | 753-05034  | Adapter                                  |
| 23   | 753-05035  | Cutting Head Assembly (includes 24)      |
| 24   | 753-05036  | Cutting Head Cap                         |
| 25   | 791-610327 | Shoulder Strap Clip                      |

\* 753-05038 Tube of Line

\* Items Not Shown