




Electrical Schematic (Man. PTO)

Attachments:
 Bagger.....19A30003OEM
 Bumper Kit....OEM-190-679
 Mulch Kit.....19A30005OEM
 Snow Blade....OEM-190-833
 Snow Thrower.OEM-190-032




Electrical Schematic (Elec. PTO)







Ref.	Part Number	Description
1	647-04151	Handle Ass'y, PTO
2	710-04876	Hex Screw, 7/16-20, 3.50, Gr5
3	710-0599	Screw, Self-tapping, 1/4-20, 0.50
4	714-04040	Pin, Cotter, Bow-Tie 72
5	720-04049A	Grip, Handle, 3/8
6	732-0932	Spring, Ext, .38 Dia x 5.6
7	936-0171	Washer, Lock, 7/16, Regular Duty
8	736-0322	Washer, Flat, .450 x 1.250 x .164
9	738-04237A	Screw, Shoulder, #10-32, .500
10	741-04119A	Bearing, PTO
11	946-04618A	Cable, Engag, Deck
12	750-0956	Spacer, 1.010 x 1.400 x .825
13	956-04067A	Pulley, Engine, 3.56 x 6.12 Dia.
14	683-04469B	Frame Ass'y, Lower
15	710-04484	Screw, Self-tapping, 5/16-18, .750,
16	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
17	712-04065	Nut, Flange Lock, 3/8-16, Grf,
18	738-04058	Spacer, Shoulder, .38 x 1.0 x .70
19	747-04121A	Rod, Battery
20	783-0349	Tray, Battery
21	783-06089	Bracket, Frame, Seat
22	925-1707D	Battery
23	710-04666	Hex Flange Screw, 1/4-20, .75, Gr5
24	712-0271	Nut, Sems, 1/4-20
25	710-0653	Screw, Self-tapping, 1/4-20, 0.375,
26	712-04064	Nut, Flange Lock, 1/4-20, Grf,
27	725-04232	Switch, 3-Pole
28	725-04363	Switch, Interlock
29	725-04439	Solenoid, 12V
30	725-04807	Switch, Plunger, Snap Mount
31	747-05171A	Belt Keeper Rod
—	925-04105	Wire Harness, Main

Electric PTO and Battery



Ref.	Part Number	Description
1	683-04469B	Frame
2	710-04484	Taptite Screw, 5/16-18:.750
3	710-3005	Hex Head Screw, 3/8-16:1.25
4	712-04065	Flangelock Nut, 3/8-16
5	738-04058	Shoulder Spacer, .38 x 1.0 x .70
6	747-04121A	Battery Holder Rod
7	783-0349	Battery Tray
8	783-06089	Seat Frame Bracket
9	710-04379A	Hex Head Screw, 7/16-20:3.50
10	917-04163A	Electric PTO Clutch
11	725-0157	Cable Tie, 3/16 x .05 x 7.4
12	936-0171	Lock Washer, 7/16
13	736-0277	Flat Washer, 1.031 x 1.620 x .095
14	756-0978B	Electric PTO Engine Pulley
15	925-1707D	Battery
16	710-0653	Taptite Screw, 1/4-20:0.375
17	712-04064	Flangelock Nut, 1/4-20
18	725-04363	Interlock Switch
19	725-04439	Solenoid, 12 V
20	738-04237A	Shoulder Screw, #10-32:.500
21	710-04666	Hex Head Flange, 1/4-20:.75
22	712-0271	Sems Nut, 1/4-20
23	747-05171A	42" Belt Keeper Rod
24	732-0814	Spr, Extn, .56 Dia X 5.52
25	683-04219B†	Bumper Assembly, Universal
26	912-3000†	Nut, Hex Lock, 3/8-16, GrB
27	731-05674†	Cap, Bumper
28	738-0143†	Bolt, Shoulder, .496 x .336, 3/8-16
29	714-04061†	Pin, Quick Release, 1/2 Dia x .50
—	925-04104	Wire Harness, Main


† If Equipped



Ref.	Part Number	Description
1	710-04095	Hex Screw, 3/8-16, 1.00, Gr5, Spec
2	710-0514	Hex Screw, 3/8-16, 1.00, Gr5, Std
3	710-0643	Hex Screw, 5/16-18, 1.00, Gr5, Lock
4	711-04998	Link, Drag LH
5	711-04999	Link, Drag RH
6	912-0240	Nut, Jam, 7/16-20, Gr2
7	712-04065	Nut, Flange Lock, 3/8-16, Grf,
8	712-0459	Nut, Flange Lock, 7/16-20, Grb, Lock
9	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
10	717-1550F	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20, Lock
13	936-3004	Washer, Flat, .406 x .875 x .105
14	736-3084	Washer, Flat, .51 x 1.12 x .06
15	938-04034	Axle Ass'y, RH .750 Dia (46" Deck)
—	638-04021	Axle Ass'y, RH .750 Dia (42" Deck)
16	738-04263	Shaft, Steering, .625 OD x 24.25
17	738-04363	Spacer, Shoulder, .385x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375, Special, 46" Only
19	741-04237B	Bearing, Flange, Hex 5/8 Pm
20	783-06043	Bracket, Support, Steering
21	638-04035P	Axle Ass'y, LH .750 Dia (46" Deck)
—	638-04027	Axle Ass'y, LH .750 Dia (42" Deck)
22	710-0395	Hex Screw, 5/16-18, 2.25, Gr5, Std
23	710-0859	Hex Screw, 3/8-16, 2.50, Gr5, Std
24	710-3180	Hex Screw, 5/16-18, 1.75, Gr5, Std

Ref.	Part Number	Description
25	912-0214	Nut, Hex Lock, 3/8-24, Grb
26	712-04063	Nut, Flange Lock, 5/16-18, Grf
27	714-0162	Pin, Cotter, 5/32, 1.25
28	719-04413A	Axle, Pivot Bar, Cast
29	748-04065	Steering, Block
30	748-04068	Spacer, .71 ID x .125 OD x .56
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04028	Steering Wheel, Standard Grip
—	631-04008A	Steering Wheel, Soft Grip
—	631-04560	Steering Wheel, (International)
33	731-04040	Cap, Sprig, Small
—	731-04039	Cap, Small
—	731-04064A	Cap, Big
34	634-04406	Wheel Assembly
35	734-1731-0901	Tire, 15 x 6 x 6
36	634-04405	Rim Assembly, Plastic Bearing, 46"
—	934-04091A	Rim Assembly, Ball Bearing, 42"
37	934-0255	Tubeless Air Valve
38	741-0516B	Flange Bearing, .760 x 1.00 x 1.20
39	741-0990B	Flange Bearing, .760 ID
40	731-08049	Cap, Bumper, 46"
—	931-3020	Cap, Bumper, 42"
41	736-04228A	Washer, Flat, .350 x 1.559 x .062, 46"
—	736-0866	Washer, Flat, .755 x 1.92 x .060, 42"
42	941-04137	Bearing, Ball, .750 x 1.750, 42"
43	710-04484	Screw, Self-tapping, 5/16-18, .750,


Seat and Fender, 46"



Ref.	Part Number	Description
1	683-04223	Shaft Ass'y, Lift
2	712-04063	Nut, Flange Lock, 5/16-18, Grf
3	712-04065	Nut, Flange Lock, 3/8-16, Grf
4	914-0104	Pin, Cotter, .072 Dia. x 1.13
5	714-04040	Pin, Cotter, Bow-Tie 72
6	716-0106A	Ring, E Type, .625 Dia. Shaft
7	720-0311	Grip, Handle, 1/2
8	732-0874	Spring, Torsion
9	736-0105	Washer, Spring, .401 x .870 x .063
10	738-0138A	Screw, Shoulder, .437 x .470, 5/16-18
11	938-0380	Bolt, Shoulder, .500, 3/8-16
12	941-0225	Bearing, Hex Flange
13	746-0968	Cable, Lift, 16.16
14	747-04962A	Handle, Lift,
15	756-04331	Pulley, Roller, Cable
16	783-05546A	Lift Link
17	710-04484	Screw, Self-tapping, 5/16-18, .750,
18	710-0528	Hex Screw, 5/16-18, 1.25, Gr5, Std
19	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
20	710-0895	Screw, HL, 1/4-15, 0.750,
21	731-06795	Cover, Lift Lever

Ref.	Part Number	Description
22	731-1993A	Cover w/ Cup Holder
23	735-0690	Grommet, .4375 ID x .750
24	736-3078	Washer, Flat .344 x 1.00 x .063
25	750-3310	Spacer, Flange, .3125 x .4375 x .625
26	783-06259	Fender
27	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
28	720-04061	Knob, 3/8-16, .875
29	725-0157	Cable, Tie, 3/16 x .05 x 7.4
30	732-04849	Spring, Compr, 1.50 x 3.90 x .200
31	938-0296	Screw, Shoulder, .437 x .268, 5/16-18
32	783-06049	Bracket, Mounting, Seat
33	783-06088	Bracket, Pivot, Seat
34	783-06266	Bracket, Knob Adjustment, Seat
35	783-06448	Clip, Retaining, Switch
36	726-3046	Clip, Ratchet, .250 Dia
37	735-04138	Pad, Foot, LH
38	735-04158	Pad, Foot, RH
39	757-04086	Seat, Medium Back
40	925-05013	Switch, Seat
41	783-06443	Bracket, Lift, Man PTO, 6 Pos


Seat and Fender, 42"




Ref.	Part Number	Description
1	683-04223	Lift Shaft Assembly
2	712-04063	Flangelock Nut, 5/16-18
3	712-04065	Flangelock Nut, 3/8-16
4	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
5	914-0111	Bow-Tie Cotter Pin
6	716-0106A	E-Ring, .625 DIA. SHAFT
7	720-0311	Handle Grip
8	732-0874	Torsion Spring
9	736-0105	Spring Washer, .401 x .870 x .063
10	738-0138A	Shoulder Screw, .437 x .470:5/16-18
11	738-04130	Shoulder Bolt, .625 x .175:3/8-16
12	941-0225	Hex Flange Bearing
13	746-0968	Lift Cable, 16.16 LG
14	747-04962A	Lift Handle
15	756-04331	Pulley Roller Cable
16	783-04494B	Lift Arm, RH
—	783-04711B	Lift Arm, LH
17	710-04484	Taptite Screw, Washer, 5/16-18:.750
18	710-1260A	Taptite Screw, 5/16-18:.750
19	710-0599	Taptite Screw, Lock Washer, 1/4-20
20	710-0895	Hi-Lo Screw, Lock Washer, 1/4-15
21	731-06584	Fender Cover Door
22	731-06676	LH Fender Cover

Ref.	Part Number	Description
23	731-06700	RH Fender Cover
24	735-0690	Grommet, .4375 x .750, 38" Only
25	736-3078	Flat Washer, .344 x 1.00 x .063 HDN
26	747-05039	Door Pin
27	750-3310	Spacer, .3125 x .4375, 38" Only
28	783-06118	Fender
29	710-04482	Hex Head Flange, 3/8-16:.875
30	712-3004A	Flangelock Nut, 5/16-18
31	725-0157	Cable Tie, 3/16 x .05 x 7.4
32	732-04849	Comp. Spring, 1.50 x 3.90 x .200
33	732-04563	Comp. Spring, .68 x 1.065 x .055
34	938-0296	Shoulder Screw, .437 x .268:5/16-18
35	783-06049	Seat Mounting Bracket
36	783-06050	Seat Adjustment Lever
37	783-06088	Seat Pivot Bracket
38	783-06448	Switch Retainer Clip
39	726-3046	Ratchet Clip
40	735-04137	LH Foot Pad
41	735-04139	RH Foot Pad
42	925-05013	Seat Switch
43	757-04086	Seat
44	783-06181	Lift Bracket

Drive and Rear Wheels




42" Wheel Hub



Drive and Rear Wheels

Ref.	Part Number	Description
1	918-0319	Hydro Transmission
2	710-0176	Hex Screw, 5/16-18:2.75
3	710-0227	Screw, #8-18:0.500
4	710-0351	Screw, #10-16:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0653	Taptite Screw, 1/4-20:0.375
7	710-1007	Screw, Sems, 3/8-16, 1.500
8	710-1325	Taptite Screw, 1/4-20:1.625
9	710-3011	Hex Screw, 3/8-16:2.25
10	912-0240	Jam Nut, 7/16-20
11	912-0346	Nut, Jamlock, 1/2-20
12	712-04063	Flangelock Nut, 5/16-18
13	912-0431	Flangelock Nut, 3/8-16
14	914-0111	Cotter Pin, 3/32:1.0
15	725-0157	Cable Tie, 3/16 X .05 X 7.4
16	725-04791A	Jumper Harness
17	725-1644	Short Spring Switch
18	926-0154	Push Mount Cable Tie 7.5 LG
19	926-0320	Insulator Nut Plate
20	731-05299A	Sleeve, .765 ID x 1.500 LG, 46"
—	731-05300A	Sleeve, .765 ID x 2.410 LG, 42"
21	731-06098	Hydro Fan
22	932-0209	Extension Spring, .48 OD X 2.03
23	732-04606	Extension Spring, .500 DIA X 12.6 LG
24	732-04624	Extension Spring, 1.00 DIA X 4.75
25	732-0716D	Extension Spring, .59 OD X 4.00 LG
26	732-0729	Wire Ring
27	732-3118	Extension Spring, .375 OD X 1.44 LG
28	936-0264	Washer, Flat, .330 X .630 X .0635
29	736-04263	Washer, Lock, TRANS HYDRO
30	936-3008	Washer, Flat, .344 X .750 X .120
31	736-3010	Washer, Flat, .407X.812X.135:HT
32	647-04152D	Brake Control Assembly
33	683-04537	Hydro Pedal Bracket Assembly
34	738-04420	Spacer, Shoulder, 1.375 X .380 X .183
35	747-04139	Rod, Brake, Hydro
36	747-04957A	Rod, Transmission, Footpedal Bypass
37	747-04979	Rod, Control, Hydro
38	747-04991	Rod, Hydro Bypass
39	750-04456	Spacer, .260 X .372 X 1.420 LG
40	954-04207	Belt, V Type, Poly
41	756-04224	Pulley, Idler, Flat 2.75 OD


Ref.	Part Number	Description
42	756-04308	Pulley, Input, 4.13 DIA
43	756-04325	Pulley, Idler, V-Type x 3.06
44	783-06027A	Bracket, Idler, Center Double
45	783-06133	Bracket, Mount, Hydro
46	783-06260	Bracket, Support, Belt Disengage
47	783-1019B	Switch Actuator Bracket
48	710-0604A	Taptite Screw, 5/16-18:0.625
49	711-05068	Clevis Pin, 5/16 x 3.985
50	712-04065	Flangelock Nut, 3/8-16
51	714-04040	Bow-Tie Cotter Pin
52	719-0584B	Control Pedal
53	726-0214	Push Cap
54	732-04587	Extension Spring, .63 DIA x 4.95 LG
55	735-04136	Brake Pedal Pad
56	736-0242	Washer, Bell, .340 x .872 x .060
57	938-0380	Shoulder Bolt, .500 x .270:3/8-16
58	741-0495	Flange Bearing, .630 ID x .695 OD x .60
59	748-04203	Cruise Latch
60	783-05914	Pedal Support Bracket
61	783-05940	Pedal Support Bracket, 5/8
62	783-06103A	Brake Pedal Bracket
63	731-2290A	Hub Cap
64	736-0430	Washer, Flat, .350 x 1.59 x .062
65	634-0104	Wheel Assembly
66	710-0627	Hex Screw, 5/16-24 x .750
67	634-04369	Rim Assembly, Plastic Bead, 46"
68	934-0255	Tubeless Air Valve
69	734-1730-0901	Tire, 20 x 8 x 8, 46"
—	734-1873-0901	Tire, 20 x 10 x 8, 42"
70	941-0490	Axle Hub
71	683-04488	Hydro Pedal Bracket Assembly
72	735-04118A	Reverse Pedal Pad
73	735-04135	Forward Pedal Pad
74	783-06059	Drive Pedal Bracket
75	918-04228	Wheel Assembly Hub, 42"
76	710-0627	Hex Screw, 5/16-24:.750
77	736-0242	Washer, Bell, .340 x .872 x .060
78	738-0430	Scr, Shldr, .50 x .685 3/8-16
79	936-0344	Washer, Flat, .385 x 1.0 x .030
80	747-05444	Belt Keeper Rod
81	710-1026	Screw, Self Tapping, 1/4-20 x 1.75



Ref.	Part Number	Description
1	918-04822A	Spindle Assembly, Pulley, 6.3
2	683-0254B	Deck Hanger Bracket Assembly
3	683-04598	Deck Assembly, 42 w/ 4 wheel
	983-04572	Deck Assembly, 42 w/ 2 wheel
4	710-04484	Taptite Screw, Washer, 5/16-18:.750
5	710-3005	Hex Head Screw, 3/8-16:1.25
6	710-0528	Hex Head Screw, 5/16-18:1.25
7	710-0599	Taptite Screw, Washer, 1/4-20:0.500
8	710-3144	Hex Head Screw, 3/8-16:2.00
9	710-3178	Carriage Bolt, 3/8-16:0.75
10	712-0229	Push Nut, 3/8
11	712-04065	Flangelock Nut, 3/8-16
12	712-0417A	Flange Nut, 5/8-18
13	712-04243	Lock Nut, 1/2-13
14	912-0641	Hex Nut, M16-1.5 DIN 936
15	753-04070	Lynch Pin, .1875
16	914-0470	Cotter Pin, 1/8 X 1.25
17	917-04074	Deck Gear
18	921-04041	Water Nozzle Adaptor
19	731-06496	Cover, Belt, Universal
	783-06424A	Cover, Belt (International)
20	732-0459C	Extension Spring, .94 DIA. X 6.74 LG
21	732-04652	Comp. Spring, .535 OD X 1.751 LG
22	734-04155	Front Deck Wheel
23	734-0973	Rear Deck Wheel
24	936-0119	Lock Washer, 5/16
25	936-0179	Flat Washer, .531 X 1.25 X .100
26	736-0225	Lock Washer, 5/8
27	736-0258	Flat Washer, .385 X 1.0 X .135

Ref.	Part Number	Description
28	736-0262	Flat Washer, .385 X .870 X .092
29	736-0317	Bell Washer, .63 X 1.25 X .18
30	936-0344	Flat Washer, .385 X 1.0 X .030
31	737-04003D	Water Nozzle
32	938-0373	Shoulder Bolt, .496 X 1.525:3/8-16
33	738-04162A	Shoulder Spacer, .8840 X .190
34	938-3056	Shoulder Bolt, .496 X 2.50:3/8-16
35	942-04312	2-in-1 Cutting Blade
	942-04308	2-in-1 Cutting Blade (International)
36	747-04944B	Deck Lift Rod
37	631-04349	Chute Deflector
38	747-1116	Deck Release Handle Rod
39	954-04060B	V-Belt
40	756-04129B	Idler Pulley, 4.25"DIA
41	711-04847B	Hinge Pin
42	783-04740	Deck Engage Cable Bracket
43	732-04372	Torsion Spring
44	783-05946	Idler Bracket
45	783-06243	Deck Engage Cable Bracket
46	783-06368A	4.25 Pulley Belt Guard Bracket
47	783-06632	Deck Stop
48	783-06643	Deck Idler Support Bracket
49	783-06074A	Chute Bracket
50	936-0351	Flat Washer, .760 IDX1.50 OD
51	738-1186A	Spindle Shaft, 6.05 LG.
52	941-0919	Ball Bearing, .787ID X 1.85 ODX.551
53	750-04936	Spacer, .792 X 1.060 X 1.860 LG
54	956-1227	Deck Pulley, 6.3 DIA
55	936-3039	Washer, Flat, .406 x 1.50 x .105

46" Deck




Ref.	Part Number	Description
1	918-04865A	Spindle Ass'y, Pulley, 6.93 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck
4	983-04525	Brake Ass'y, Deck
5	983-04578A	Deck Ass'y, Offset, 46" 2W
6	710-04484	Screw, Self-tapping, 5/16-18, .750,
7	710-0514	Hex Screw, 3/8-16, 1.00
8	710-0528	Hex Screw, 5/16-18, 1.25
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
10	710-0778	Screw, Self-tapping, 1/4-20, 1.500,
11	710-0642	Screw, Self-tapping, 1/4-20, .75,
12	710-1003	Screw, #10-16:.625
13	710-3144	Hex Screw, 3/8-16, 2.00
14	710-3178	Bolt, Carriage, 3/8-16, 0.75
15	712-0229	Nut, Push, 3/8
16	712-04063	Nut, Flange Lock, 5/16-18
17	712-04065	Nut, Flange Lock, 3/8-16
18	712-0417A	Nut, Flange, 5/8-18
19	712-04243	Nut, Lock, 1/2-13
20	912-0641	Nut, Hex, M16-1.5
21	753-04070	Pin, Lynch, .1875
22	914-0470	Pin, Cotter, 1/8 x 1.25
23	917-04074	Gear, Deck, Adjustment
24	731-06496	Belt Cover
25	932-0384	Spring, Extension, .62 Dia x 6.12
26	732-04652	Spring, Comp, .535 OD x 1.751
27	732-04773	Spring, Torsion, .992 I.D x 1.17 O.D
28	734-04155	Wheel, Deck, 5.0 Dia Ball
29	936-0119	Washer, Lock, 5/16, Regular Duty
30	921-04041†	Water Nozzle Adaptor
31	936-0179	Washer, Flat, .531 x 1.25 x .100
32	736-0187	Washer, Flat, .64 x 1.24 x .06,
33	736-0225	Washer, Lock, 5/8, Int Tooth

Ref.	Part Number	Description
34	736-0262	Washer, Flat, .385 x .870 x .092
35	736-0317	Washer, Bell, .63 x 1.25 x .18
36	936-0344	Washer, Flat, .385 x 1.0 x .030
37	736-0362	Washer, Flat, .330 x 1.25 x .06,
38	738-04146	Plug, Bolt, M16 x 1.5
39	738-04162A	Spacer, Shoulder, .8840 x .190
40	748-0234	Spacer, Shoulder
41	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
42	942-04290	Blade
43	747-05323	Rod, Keeper, Belt
44	747-04944B	Rod, Lift, Deck, Frt, 13.7
45	747-05011	Rod, Keeper, Belt
46	747-05052	Rod, Control, Brake
47	756-04356	Pulley, Deck, 6.93 Dia
48	747-1116	Rod, Handle, Deck Release
49	750-0258	Spacer, .315 x .750 x .375
50	750-0566A	Spacer, .260 x .375 x 1.030
51	751B221535	Clamp, Casing
52	954-04219	Belt, V-Type
53	756-04129B	Pulley, Idler, 4.25"Dia
54	937-3000	Fitting, 3/16, Lnc#70, Drive Lube
55	738-1186A	Shift, Spindle, 6.11.
56	783-05946	Bracket, Idler, Pivot
57	783-06243	Bracket, Cable, Deck Engage
58	783-06368A	Bracket, Guard, Belt, 4.25 Pulley
59	783-06643	Bracket, Support, Deck Stationary Idler
60	783-06074A	Bracket, Chute
61	631-04288	Chute Ass'y, Deflector
62	732-04372	Torsion Spring, .44 ID x 2.0
63	941-0919	Ball Bearing, .787 ID x 1.85 OD x .551
64	750-04936	Spacer, .792 x 1.060 x 1.860
65	711-04847B	Hinge Pin
66	737-04003D†	Deck Water Nozzle

† If Equipped


Hood and Dash, 5 Style



Ref.	Part Number	Description
1	710-04484	Taptite Screw ,5/16-18:.750
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-0895	Hi-Lo Screw, 1/4-15:0.750
4	710-1017	Screw, 1/4-14:0.625
5	710-1611B	Taptite Screw ,5/16-18:0.750
6	714-04040	Bow Tie Cotter Pin
7	925-1649	Lamp Socket
8	731-06167	Dash Panel, No Sight Window
9	731-06639	Dash Lever
10	731-06642	Cruise Cover
11	747-05008	Control Rod
12	747-1196	Lever
13	783-04285F	RH Support Plate
14	783-04323F	LH Support Plate
15	751-0603A	Fuel Cap
	951-12179A	Fuel Cap, EPA
16	710-04593	Taptite Screw ,5/16-18:0.375
17	710-0751	Hex Screw, 1/4-20:.620
18	712-04064	Flangelock Nut, 1/4-20
19	731-04949A	Grill Lens
20	731-05522A	Hood Scoop
21	738-04091A	Shoulder Screw, .43X.29:5/16-18
22	783-05454	Hood Pivot Bracket
23	783-05683	Hood
24	783-05685	Grill
25	751-0659D	Fuel Tank
	951-04308	Fuel Tank, EPA
26	731-1999	Choke Plug
	946-04132†	Choke Cable
27	925-04227B	Key Switch Module
28	746-04364	Throttle/Choke Control
	946-04541†	Throttle Cable
29	925-1745A	Key
30	925-04036C	Hour Meter
31	925-0963	Lamp
32	731-05165A†	Plenum
—	726-04096	Choke Hole Plug (Not Shown)

† If Equipped


Hood and Dash, K Style



Ref.	Part Number	Description
1	931-04281A	Dash Assenbly
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-04484	Taptite Screw ,5/16-18:.750
4	710-0895	Hi-Lo Screw, 1/4-15:0.750
5	710-1017	Screw, 1/4-14:0.625
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	714-04040	Bow Tie Cotter Pin
8	731-06639	Dash Lever
9	731-06642	Cruise Cover
10	732-04580	Extension Spring, .500 DIA x 2.733 LG
11	735-0271A	Bumper
12	747-05008	Control Rod
13	747-1196	Lever
14	783-04285F	RH Support Plate
15	783-04323F	LH Support Plate
16	710-0642	Taptite Screw, 1/4-20:0.750
17	683-04441A	Hood Assembly
18	710-05108	Screw, 1/4 DIA:.750
19	731-06095	LH Lens
20	731-06096	RH Lens
21	738-04091A	Shoulder Screw, .43 x .29
22	747-04161	LH Tank Support Rod
23	747-04946	RH Tank Support Rod
24	751-10609	Fuel Tank
25	751-0603A	Fuel Cap
26	925-0963	Lamp
27	925-1649	Lamp Socket
28	946-1085A	Choke Cable
	946-04132	Choke Cable (International)
29	946-04417	Throttle Cable
	946-04541	Throttle Cable (International)
30	925-04227B	Key Switch Module
31	925-04036C	Hour Meter
32	925-04174	Electric PTO Switch
33	925-1745A	Key
34	931-06796	Grill
35	731-06194A	Hood Scoop
36	710-0751†	Hex Screw, 1/4-20:.620
37	712-04064†	Flangelock Nut, 1/4-20
38	931-06212†	Plenum

† If Equipped

Hood and Dash, C Style




Hood and Dash, C Style

Ref.	Part Number	Description
1	710-0192	Screw, #10-24:0.375
2	710-04484	Taptite Screw ,5/16-18:.750
3	710-0599	Taptite Screw ,1/4-20:0.500
4	710-0653	Taptite Screw, 1/4-20:0.375
5	710-0895	Hi-Lo Screw, 1/4-15:0.750
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	710-3217	Screw, #8-32:0.375
8	712-0142	Hex Nut, #8-32:GRA
9	914-0104	Cotter Pin, .072 DIA. X 1.13 LG
10	714-04040	Bow Tie Cotter Pin
11	731-05447A	Dash Lever, Cruise/Brake
12	731-05659	Steering Shaft Bushing
13	931-06553	Dash
14	731-1857	Control Knob
15	732-04580	Extension Spring, .500 DIA x 2.733 LG
16	747-05054	Control Rod
17	747-1323A	Rod, .250 DIA X 4.55 LG
18	783-04285F	RH Support Plate
19	783-04323F	LH Support Plate
20	783-05453A	Support Dash Bracket
21	783-1499	Bracket, Rod, Dash

Ref.	Part Number	Description
22	931-05765	Hood Assembly
23	683-04238	Bumper Assembly
24	710-05108	Screw, 1/4 DIA:.750
25	712-04065	Flangelock Nut, 3/8-16
26	725-0157	Cable Tie, 3/16 X .05 X 7.4
27	926-0154	Push Mount Cable Tie 7.5 LG
28	738-0143	Shoulder Bolt, .496 X .336:3/8-16
29	738-04091A	Shoulder Screw, .43 X .29:5/16-18
30	783-04606C	Hood Pivot Bracket
31	931-04577	Headlight Lens
32	925-0963	Lamp
33	925-1649	Lamp Socket
34	751-0603A	Fuel Cap
35	751-0658E	Fuel Tank, 3 Gallon
36	731-04569A	Plenum
37	746-04352	Throttle Control
38	946-1085A	Choke Control
39	925-04022B	Hour Meter
40	925-04174	Electric PTO Switch
41	925-04230B	Key Switch
42	925-1745A	Key


Engine Accessories, Single



Ref.	Part Number	Description
1	683-04549	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683	Taptite Screw, 3/8-16:1.000
4	710-0599	Taptite Screw, 1/4-20:0.500
5	710-1314A	Socket Head Screw, 5/16-18:.750
6	710-1652	Taptite Screw, 1/4-20 x .625
7	712-0271	Sems Nut, 1/4-20
8	751-3141-14	Extension Hose, Oil Drain
9	725-0157	Cable Tie, 3/16 x .05 x 7.4

Ref.	Part Number	Description
10	726-0205	Hose Clamp, .490 DIA.
11	728-04000†	Rivet, .188 DIA x .300 L
12	751-11943	Muffler
13	751-0564B†	Muffler Deflector
14	751-10349	Fuel Hose
15	751-11053	Long Muffler Deflector
16	951-10517A	Oil Drain
17	751-12089-28†	Hose, Vent

† If Equipped



Ref.	Part Number	Description
1	683-04549	Shield Ass'y, Muffler
2	710-0227	Screw, Ab, #8-18, 0.500,
3	710-04683	Screw, Self-tapping, 3/8-16, 1.000,
4	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
5	710-1314A	Screw, Socket Head, 5/16-18, .750
6	712-0271	Nut, Sems, 1/4-20
7	751-3141-14	Hose, Extension, Oil Drain
8	KH-24-041-49-S	Gasket, Exhaust,Kohler
	721-0460	Gasket, Exhaust, Briggs
9	725-0157	Cable, Tie, 3/16 x .05 x 7.4
10	726-0205	Clamp, Hose, .490 Dia.
11	728-04000	Rivet, Pop, .188 Dia x .300
12	751-10528A	Muffler, Kohler Twin
	751-10542A	Muffler, Briggs Twin
13	751-0564B	Deflector, Muffler
14	751-10349	Hose, Fuel, Low Permeation, 1/4
15	751-10353	Deflector, Muffler, Long
16	951-10517A	Drain, Oil