


# REPLACEMENT PARTS - MODEL TB2BV EC

## 2-CYCLE GAS BLOWER

PPN 41AS2BVG766




| Item | Part No.  | Description                               |
|------|-----------|-------------------------------------------|
| 1    | 753-06294 | Muffler Screws                            |
| 2    | 753-06027 | Muffler Assembly (includes 1 & 3)         |
| 3    | 753-05946 | Muffler Gasket                            |
| 4    | 753-05703 | Screw                                     |
| 5    | 753-06193 | Spark Plug                                |
| 6    | 753-06252 | Cylinder Gasket                           |
| 7    | 753-06687 | Shortblock Assembly (includes 4-6 & 8-11) |
| 8    | 753-06175 | Flywheel Assembly                         |
| 9    | 753-04833 | Washer                                    |
| 10   | 753-05687 | Nut                                       |
| 11   | 753-06443 | Module Assembly                           |

| Item | Part No.   | Description                           |
|------|------------|---------------------------------------|
| 12   | 753-05949  | Lead Wire                             |
| 13   | 753-04595  | Screw                                 |
| 14   | 753-06720  | Fuel Tank Assembly (includes 13 & 15) |
| 15   | 791-182529 | Fuel Cap                              |
| 16   | 753-06185  | Insulator O-Ring                      |
| 17   | 753-06189  | Insulator Assembly (includes 16)      |
| 18   | 753-06253  | Carburetor Gasket                     |
| 19   | 753-06753  | Carburetor Assembly                   |
| 20   | 753-06689  | Aircleaner Assembly (includes 21)     |
| 21   | 791-181757 | Air Filter                            |
| 22   | 753-06690  | Throttle Cable                        |

# REPLACEMENT PARTS - MODEL TB2BV EC

## 2-CYCLE GAS BLOWER

PPN 41AS2BVG766



| Item | Part No.   | Description                            |
|------|------------|----------------------------------------|
| 1    | 753-05937  | Lower Tube                             |
| 2    | 753-05936  | Upper Tube                             |
| 3    | 753-04595  | Screw                                  |
| 4    | 791-181862 | Screw                                  |
| 5    | 753-06695  | Engine Cover Assembly (includes 3 & 4) |
| 6    | 753-06694  | Muffler Cover Assembly (includes 3)    |
| 7    | 753-05932  | Outer Trigger Lock                     |
| 8    | 753-06693  | Impeller Housing                       |
| 9    | 753-05919  | Handle Grips                           |
| 10   | 753-05924  | Inner Trigger Lock                     |
| 11   | 753-05925  | Wavey Washer                           |
| 12   | 791-182405 | Switch                                 |
| 13   | 753-05930  | Throttle Trigger                       |
| 14   | 753-05928  | Washer                                 |
| 15   | 753-05926  | Latch Tube                             |
| 16   | 753-05939  | Latch Spring                           |

| Item | Part No.  | Description      |
|------|-----------|------------------|
| 17   | 753-05929 | Impeller         |
| 18   | 753-06701 | Nut              |
| 19   | 753-06700 | Adapter          |
| 20   | 753-06679 | Impeller Housing |
| 21   | 753-06699 | Intake Cover     |
| 22   | 753-05918 | Spring           |
| 23   | 753-06658 | Elbow            |
| 24   | 753-06659 | Bag              |
| 25   | 753-06660 | Upper Vac Tube   |
| 26   | 753-06661 | Lower Vac Tube   |
| 27   | 753-06696 | Door Lock        |
| 28   | 753-1202  | Screw            |