





Component	Part Number and Description	
	954-04060B	Deck Belt (42" Mowing Deck)
	918-04822A	Deck Spindle
	942-04308 942-04308-X	Blade (42" Deck) Extreme Blade (42" Deck)
	925-1707D	Battery
	951-12179A 951-12426	Fuel Tank Cap Fuel Tank Cap (CA Models Only)
	625-05002	Key Asm-Black Key W/Keychain
	734-1731	Tire (Front) 15 x 6 x 6 Square Shoulder
	734-1730	Tire (Rear) 20 x 8 x 8 Square Shoulder
	746-04367	Throttle Control/Cable
	631-04288	Discharge Chute Assembly

The following attachments and accessories are compatible for the Troy-bilt Lawn Tractor. See the retailer from which you purchased your tractor, an authorized Troy-bilt Service Dealer or phone (800) 828-5500 for information regarding price and availability.




CAUTION: This Troy-Bilt Lawn Tractor is NOT designed for use with any type of ground-engaging attachments (e.g. tiller or plow). Use of this type of equipment WILL void the tractor's warranty.

Model Number	Description
19A30006OEM	Mulch Kit
19A30003OEM	Bagger
OEM-190-679	Bumper Kit
OEM-190-833	Dozer Blade
OEM-190-032	42-Inch Two Stage Snow Thrower
490-900-M060	42 lb Rear Suit Case Weight Kit With Bracket
490-900-M059	42 Lb Rear Suit Case Weight
490-241-0023	Tire Chains 20X8
490-290-0013	Tractor Cover
OEM-190-607	Sun Shade
490-850-0005	Blade Removal Tool
490-850-0008	Oil Siphon
490-900-0045	Oil Filter Wrench
SPW-136	Spark Plug Wrench
490-325-L021	1 Gallon Tire & Tube Sealant By Tire Aid
490-325-L019	24 Oz Tire & Tube Sealant By Tire Aid
490-850-L013	Deluxe Tire/ Tube Foot Pump By Tire Aid
490-850-L014	Tire Aid Deluxe Tire Plug Kit By Tire Aid
490-328-L014	15" Tractor Tube With Sealant By Tire Aid
490-328-L016	18" & 20" Tractor Tube With Sealant By Tire Aid
22216	32 oz. STA-BIL ®

0637	Black
0709	Dark Green (Bolens, Yard-Man)
0662	Oyster Gray (MTD Gold)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)
0691	Black Jack (MTD Gold, MasterCut)

0674	Yellow (Yard-Man)
0650	Metallic Red (White Outdoor)
0629	Silver Flake (MTD Platinum)
04038	Day Orange (Daedong)
04033	Flint Mica (Troy-Bilt XP)


K Style Hood



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	631-04272	Grill Assembly, Troy-Bilt	29	746-04367	Throttle/Choke Cable
2	731-06404	K-Style Bumper	30	783-06991	Speed Latch - No RMC
3	683-04441A	Hood Assembly	31	683-04448	Battery Assembly Rod
4	710-04484	Screw, 5/16-18 x .750	32	726-0230	Cable Tie
5	710-0895	Screw, 1/4-15 x .750	33	747-05398	Speed Control Rod
6	725-0157	Cable Tie	34	783-06823	Speed Latch Tab
7	925-0963	Lamp	35	951-04304	1.36 Gallon Fuel Tank
8	731-06095	Left Lens	36	625-05002	Key, Assembly
9	731-06096	Right Lens	37	736-3006	Lock Washer, 1/4
10	738-04091A	Shoulder Screw, 5/16-18 x .43 x .29	38	936-3008††	Flat Washer, .344 x .750 x .120
11	783-05327B	Left Support Pivot Bracket	39	951-10589††	5 Gallon Carbon Canister
12	783-05328A	Right Support Pivot Bracket	40	951-10590††	Vent Filter Canister
13	710-04483	Screw, 1/4-20 x .500	41	951-10610 ††	Canister Adapter Bracket
14	710-05070	Screw, 1/4-20 x .500	42	751-10749-30††	Fuel Hose, White
15	710-0604A	Screw, 5/16-18 x .625	43	751-10750-28††	Fuel Hose, Yellow
16	712-04063	Flangelock Nut, 5/16-18	44	925-04659	3 Position Key Switch
17	710-05281	Screw, #12-16 x 1.25	45	951-12179A	Fuel Cap, 2.25"
18	783-07083	Gas Tank Support Bracket		951-12426	Fuel Cap, 2.25" EPA
19	910-0224	Screw, #10-16 x .500	46	751-12118	Rollover Valve
20	731-05265	Choke Plug	47	735-04081	Rubber Grommet, 23 x 3.55
21	710-1652	Tap Screw, 1/4-20, 0.625	48	751-12089-28	Hose Vent, 3/16 EPA
22	710-3144	Hex Screw, 3/8-16 x 2.0	49	710-0778	Hex Washer Screw, 1/4-20 x 1.50
23	710-3025	Hex Screw, 5/16-18 x .625	50	712-04065	Flangelock Nut, 3/8-16
24	931-08054	Dash, Upper	51	731-07885B	Shift Lever
25	741-0587	Bearing, .628 ID x 1.36	52	731-07966A	Index Control
26	783-06785A	Bracket, Steering Support	53	732-04877	Compr. Spring, .72 OD x .78
27	783-06811	Dash, Lower	—	925-04567G	Harness, LT-5, NRMCC, Dual
28	750-04465B	Flange Spacer, .390 x .671 x 1.095			

†† Equipped with CARB Fuel Tank


Frame and PTO Lift



Ref. No.	Part No.	Description
1	683-04195	Support Bracket
2	683-04649A	Frame Assembly
3	710-0134	Screw Carriage, 1/4-20 x .62
4	710-04484	Screw 5/16-18 x .750
5	710-0599	Screw, 1/4-20 x .500
6	710-3008	Hex Screw, 5/16-18 x .75
7	712-04063	Flangelock Nut, 5/16-18
8	712-04064	Flangelock Nut, 1/4-20
9	912-0429	Hexlock Nut, 5/16-18
10	732-04035	Compression Spacer, 1.28 x 3.125
11	736-0173	Flat Washer, .28 x .74 x .063
12	738-04237A	Shoulder Spacer, 10-32 x .500
13	783-04548D	Seat Frame Bracket
14	783-04637	Running Board Bracket
15	783-04753	Support Frame Bracket
16	783-04869A	Battery Bracket
17	710-04666	Hex Head Flange, 1/4-20 x .75
18	712-0271	Sems Nut, 1/4-20
19	925-1707D	230 CCA Battery
20	783-04536B	Support Bracket
21	647-04096A	PTO Handle Assembly
22	683-04155A	Lift Assembly, 42"
23	712-04065	Flangelock Nut, 3/8-16
24	714-04040	Bow-tie Cotter Pin


Ref. No.	Part No.	Description
25	716-0106A	E Ring
26	720-0311	Handle Grip, 1/2
27	732-04225	Torsion Spring
28	738-04130	Shoulder Bolt, 3/8-16 x .625 x .175
29	941-0225	Hex Flange Bearing
30	747-04282	Deck Lift Handle
31	747-04393	Lift Rod
32	783-04494C	42" Lift Arm, RH
33	783-04711C	42" Lift Arm, LH
34	725-04363	Switch Interlock
35	736-0322	Flat Washer, .450 x 1.250 x .164
36	741-04119A	PTO Bearing
37	946-04173E	Deck Engage Cable
38	756-04196A	Engine Pulley, 3.39 x 6.12
39	683-04448	Battery Hold Down Rod
40	936-0300	Flat Washer, .406 x .875 x .059
41	747-04857	42" Belt Keeper
42	710-0604A	Screw, 5/16-18.0 x .625
43	725-04439	12V Solenoid
44	710-3157A	Hex Screw, 7/16-20 x 3.25
45	914-0145	Click Pin, .092 x 1.64
46	720-04049A	Handle Grip, 3/8
47	732-04276A	PTO Spring Extension

Front End Steering




Ref. No.	Part No.	Description
1	617-04094	Front Steering Gear Assembly
2	710-0514	Hex Screw, 3/8-16 x 1.00
3	710-0643	Hex Screw, 5/16-18 x 1.00, Lock
4	710-1309	Machine Screw, 5/16-18 x .750
5	710-3180	Hex Screw, 5/16-18 x 1.75
6	912-0240	Jam Nut, 7/16-20
7	912-0214	Jamlock Nut, 3/8-24
8	712-04063	Flangelock Nut, 5/16-18
9	938-04013	42" & 46" Front RH Axle
10	923-0448A	Ball Joint, 7/16-20
11	736-0242	Bell Washer, .340 x .872 x .060
12	938-04014A	42" & 46" Front LH Axle
13	738-04141	Shoulder Bolt, 5/16-18 x .435 x .350
14	738-0919A	Steering Shaft, 5/8 x 22.08
15	941-04124	Flange Bearing, 5/8
16	934-0255	Valve, tubeless Air
17	747-05385	Steering Link
18	948-0389	Cap, 1.25 x .16
19	748-04065	Steering Block
20	748-04068	Spacer, .71 x .125 x .56
21	734-1731	Tire, 15 X 6 X 6 Sq Shoulder
22	738-04162C	Shoulder Spacer, .884 x .190
23	736-04228A	Flat Washer, .781 x 1.590
24	714-0162	Cotter Pin, 5/32 x 1.25
25	683-0128B	Pivot Axle
26	710-04484	Screw, 5/16-18 x .750
27	712-04065	Flangelock Nut, 3/8-16
28	914-0474	Cotter Pin, .125 x .75
29	934-04081-0662	Rim Asm, 6.0x4.5
30	634-04086-0911	Wheel Assembly
31	631-04028	Steering Wheel
32	931-0484A	Hub Cap
33	731-04681	Cap, Troy-Bilt
34	738-04128	Shoulder Bolt, 3/8-16 x .500 x 2.38
35	747-04299A	Fixed Rod
36	783-05326B	Pivot Bar Bracket
37	726-0341	Push Cap, 3/4
38	731-04057A	Standard Axle Cap
39	741-0660A	Flange Bearing, .760 x .941 x 1.0

Seat and Fender



Ref. No.	Part No.	Description
1	710-05070	Screw, 1/4-20 x .500
2	710-04484	Screw, 5/16-18 x .750
3	710-0599	Screw Pan Torx Head, 1/4-20 x .500
4	731-04591A	Cup Holder
5	710-0134	Screw Carriage, 1/4-20 x .62
6	783-04587D	Fender - Red
7	783-04843	Lift Adjuster Bracket - Powder Black
8	783-1489D	Seat Mount Bracket - Powder Black
9	712-04063	Flangelock Nut, 5/16-18
10	732-1184	Extension Spring
11	936-0108	Flat Washer, .510x .750 x .033
12	736-0242	Bell Washer, .340 x .872 x .060
13	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
14	783-0209D	Lift Seat Bracket
15	783-04081D	Pivot Seat Manual Adjust Bracket
16	757-04083A	Med. Back Seat, Black
17	725-1439	Inner Seat Spring
18	720-04061	Knob, 3/8-16 x .875
19	735-04047	Foot Pad, LH
20	735-04048	Foot Pad, RH
21	726-3046	Ratchet Clip, .250 x .500
22	710-0227	Screw, 8-18 x .500
23	726-0279	Insulator Plate
24	925-1303	Outer Seat Spring
25	726-0278	Insulator Boss Plate


Transmission



Transmission


Ref.	Part No.	Description	Ref.	Part No.	Description
1	918-04566	Transmission Drive Assembly	44	736-3040	Flat Washer, .406 x 1.920 x .060
2	17962	Plate Switch	45	936-0185	Flat Washer, .375 X .738 X .063
3	647-04266	Shaft Lever Assembly	46	725-04363	Switch Interlock
4	647-04201A	Pedal Assembly, drive	47	634-0104	Wheel, 20 x 8 x 8
5	647-04203A	Pedal Assembly, control	48	738-0372B	Shoulder Spacer, 1.00 X .38 X .38
6	683-04736	Pedal Bracket Assembly	49	738-04091A	Shoulder Screw, .43 x .29, 5/16-18
7	710-0227	Screw, 8-18:0.500	50	783-06807A	Stop Pedal Plate
8	710-04484	Screw, 5/16-18 x .750	51	741-0495	Flng Bearing .63 Id x .695 Od X .60
9	710-0604A	Screw, 5/16-18 x 0.625	52	934-0255	Valve, tubeless Air
10	710-0809	Screw, 1/4-20 x 1.250	53	747-05188	Brake Rod
11	710-0859	Hex Screw, 3/8-16 x 2.50	54	747-05243	Shift Rod, 46"
12	710-1007	Screw, 3/8-16 x 1.500	55	747-05596	Idler Adjustment Rod
13	710-1858A	Screw, 3/8-16 x 1.750	56	747-05415	Transmission Bypass Rod
14	710-1266	Hex Screw, 5/16-18 x .625	57	948-0334	Spacer, T-Axle .68
15	710-1026	Screw, 1/4-20 x 1.75	58	750-04456	Spacer, .260 X .372 X 1.420 Lg
16	710-3008	Hex Screw, 5/16-18 x .75	59	750-0566A	Spacer, .260 X .375 X 1.030 Lg
17	912-0240	Jam Nut, 7/16-20	60	954-04208	V Belt, 5L 40.9 Poly
18	712-0241	Hex Nut, 3/8-24	61	954-0467A	V Belt, 5L, 90.93 Poly
19	712-04063	Flangelock Nut, 5/16-18	62	956-04002	V Pulley 7.25 DIA SPUN
20	732-04764	Spring Extension, .56 OD x 12.05	63	756-04224	Idler Pulley
21	912-3000	Nut, 3/8-16, Centerlock	64	756-04325	Idler Pulley
22	712-0700	Flange Nut, 9/16-18	65	783-04536B	Pedal Support Bracket
23	734-1730	Tire, 20 X 8 X 8	66	783-04595A	Shaft Adjust Bracket
24	914-0209	Cotter Pin INT- .125 DIA	67	634-04369-0662	Rim, 8.0 X 7.0 X .750
25	714-04040	Bow-Tie Cotter Pin, 72	68	783-06562A	Frame Pedal Bracket, Rh
26	718-04407	Pulley Hub, 5/8 SPLINE	69	783-06769	Center Idler Bracket
27	720-04028	Shift Knob	70	783-06592A	Idler Bracket
28	923-3018	Ball joint	71	783-06641A	Pedal Support Bracket
29	725-0157	Cable tie	72	753-06662	Idler Bracket Assembly
30	725-1644	Short Spring Switch	73	683-04606	Bracket Assembly
31	726-0214	Push Cap, 5/8	74	710-1260A	Screw, 5/16-18 x 0.750
32	926-0320	Plate Insulator Nut	75	710-3005	Hex Screw, 3/8-16 x 1.25
33	731-04602	Sleeve, .758 x .821 x 3.3125	76	712-04065	Flangelock Nut, 3/8-16
34	731-04604	Sleeve, .758 x .821 x 2.4375	77	738-04162C	Shoulder Spacer, .8840 X .190
35	731-06330	Plug, 7/8	78	956-04015A	Variable Speed Pulley Assembly
36	731-06894	Shift Plate Bearing	79	683-04522	Belt Keepr Assembly
37	732-04488	Spring Extension, .38 OD x 3.25 LG	80	683-04612	Bracket Assembly
38	732-04612	Spring Extension, .70 OD X 12.00	81	710-05339	Screw, 5/16-24 x .750
39	732-04616B	Spring Extension, .97 Od X 6.18 Lg	82	710-0778	Screw, 1/4-20 x 1.500
40	732-0716D	Spring Extension, .59 OD x 4.00 LG	83	718-04261	Bearing Cup
41	735-0239	Foot Pad, 4.0 Long	84	736-0362	Flat Washer, .330 X 1.25 X .06
42	735-04272	Control Pad	85	941-0600	Ball Bearing, 17 x 40 x 12
43	936-0169	Lock Washer 3/8	86	747-05430	Spring Retainer Rod

42" Deck



Ref.	Part Number	Description
1.	918-04822A	Spindle Ass'y, Pulley, 6.3 Dia
2.	683-0254B	Bracket Ass'y, Deck, Hanger LH
3.	983-04511	Brake Ass'y, Deck, 42/46
4.	983-04525	Brake Ass'y, Deck, 46"
5.	983-04572A	Deck Ass'y, Offset, 42"
6.	710-04484	Screw, Self-tapping, 5/16-18, .750
7.	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
8.	710-0528	Hex Screw, 5/16-18, 1.25, Gr5, Std
9.	710-0599	Screw, Self-tapping, 1/4-20, 0.500
10.	936-3039	Flat Washer, .406 x 1.500 x .105
11.	710-0642	Screw, Self-tapping, 1/4-20, .750
12.	710-3144	Hex Screw, 3/8-16, 2.00, Gr5, Std
13.	710-3178	Bolt, Carriage, 3/8-16, 0.75, Gr1
14.	712-0229	Nut, Push, 3/8
15.	712-04063	Nut, Flange Lock, 5/16-18, Grf
16.	712-04065	Nut, Flange Lock, 3/8-16, Grf
17.	712-0417A	Nut, Flange, 5/8-18
18.	712-04243	Nut, Lock, 1/2-13
19.	783-06464	Deck Wash Plug
20.	714-04043	Bow-Tie Cotter Pin
21.	783-06074A	Chute Bracket
22.	917-04074	Gear, Deck, Adjustment
23.	932-0384	Spring, Extension, .62 Dia x 6.12
24.	783-07236	Pulley Cap
25.	732-04840	Spring, Torsion, .992 ID X 1.17 OD
26.	734-04155	Wheel, Deck, 5.0 Dia Ball
27.	936-0119	Washer, Lock, 5/16, Regular Duty

Ref.	Part Number	Description
28.	941-0919A	Bearing, Ball, .787id x 1.85 Odx.551
29.	936-0344	Washer, Flat, .385 X 1.0 X .030
30.	710-0376	Hex Cap Screw, 5/16-18 x 1.00
31.	720-05010	Cap, .290 x .500
32.	736-0262	Washer, Flat, .385 x .870 x .092
33.	750-04936	Spacer, .792 x 1.060 x 1.860
34.	783-06643	Bracket, Support, Stationary Idler
35.	748-04069	Deck Lift Pivot Cup
36.	738-04162C	Spacer, Shoulder, .8840 x .190
37.	748-04272	Shoulder Spacer
38.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
39.	942-04308	Blade, Cut, 21.23" 2-In-1, Econ
40.	747-05323	Rod, Keepr, Belt 42 Idler
41.	747-05141A	Rod, Lift, Deck, Frt, 12.7
42.	747-05105B	Rod, Control, Brake 42"
43.	631-04288	Chut Assembly, 42" Deck
44.	783-06424A	Deck Belt Cover, 42
45.	936-0351	Washer, Flat, .760 Idx1.50 OD
46.	738-1186A	Shift, Spindle, 6.11.
47.	954-04060B	Belt, V Type, A Sec X 96.5
48.	756-04129B	Pulley, Idler, 4.25"Dia
49.	711-04847B	Pin, Hinge, Dia .3125 x 7.96
50.	956-1227	Pulley, Deck, 6.3 Dia
51.	732-04372	Spring, Torsion, .44 I.D. X 2.0
52.	783-05946	Pivot idler Bracket, 46
53.	783-06243	Bracket, Cable, Deck Engage
54.	783-06368A	Bracket, Guard, Belt, 4.25 Pulley



Ref. No.	Part No.	Description
1	683-04549	Muffler Shield Assembly with Weld
2	710-0227	Screw, 8-18 x .500
3	710-04683A	Screw, 3/8-16 x 1.0
4	710-0599	Screw, 1/4-20 x .500
5	710-0642	Screw, 1/4-20 x .750
6	710-1314A	Socket Screw, 5/16-18 x .750
7	725-0157	Cable Tie
8	726-0205	Clamp Hose, .490 diameter
9	951-10517A	Oil Drain
10	751-3141-14	Oil Drain, Extension Hose
11	751-11943	Muffler
12	751-10349-28	Fuel Hose, Low Permeation
13	751-11053A	Muffler Deflector Long

17

