




Operator's Manual



Single Stage Snow Thrower


Model Series
140 through E173

SECTION 9: PARTS LIST FOR MODEL SERIES 140 THROUGH E173




Model Series 140 Through E173

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	710-0167	Carriage Bolt	25.	736-0176	Flat Washer
2.	710-0276	Carriage Bolt	26.	736-0159	Washer
3.	710-0323	Pan Head Screw	27.	736-0326	Flat Washer
4.	710-0451	Carriage Bolt	28.	736-0329	Lock Washer
5.	710-0642	Hex Washer Screw	30.	741-0600	Ball Bearing
6.	710-1005	Hex Washer Screw	31.	746-0910A	Cable—Clutch
7.	710-0773	Hex Washer Screw	32.	748-0234	Spacer
8.	710-0896	Hex Washer Screw	33.	749-0796	Handle—Lower
9.	710-3015	Hex Cap Screw	34.	756-0313	Flat Idler
10.	711-0848A	Axle	35.	784-5174	Bearing Cup
11.	712-0429	Hex Center Lock Nut	36.	784-5176	Cover—Belt
12.	712-3010	Hex Nut	37.	784-5175B	Idler/Brake Bracket
13.	712-0116	Hex Lock Nut	38.	684-0114	Blower Housing
15.	712-3027	Hex Lock Flanged Nut	39.	784-5485	Auger Ass'y. Comp.
16.	720-0284	Knob	40.	753-0613	Auger Rubber Replacement
17.	731-0851A	Chute Keeper	41.	710-0352	Hex Washer Screw
18.	731-0915B	Lower Chute	42.	784-5720	Crank Bracket
19.	731-0921	Upper Chute	43.	710-0451	Cap Screw
20.	731-1033	Shave Plate	44.	736-0242	Bell Washer
21.	732-0357A	Extension Spring	45.	741-0475	Bushing
22.	736-0108	Flat Washer	46.	710-0191	Hex Screw
23.	736-0119	Lock Washer			




Ref. No.	Part No.	Description
1	734-1176	Wheel Ass'y.

Models 140, 150, E150 and E151




Ref. No.	Part No.	Part Description
1.	710-1270	Oval C-Sunk Screw
2.	710-0487	Carriage Bolt
3.	712-0324	Lock Nut
4.	720-0284	Handle Knob
5.	725-0157	Cable Tie
6.	746-0883	Control Lever
7.	747-0946	Control Handle Assembly
8.	749-0705	Upper Handle
9.	736-0451	Saddle Washer

Models 142, E152, E172 and E173




Ref. No.	Part No.	Part Description
1.	710-1270	Oval C-Sunk Screw
2.	710-0487	Carriage Bolt
3.	712-0324	Lock Nut
4.	720-0295	Foam Grip
5.	720-0284	Handle Knob
6.	725-0157	Cable Tie
7.	736-0451	Saddle Washer
8.	746-0883	Control Lever
9.	747-0956	Control Handle Assembly
10.	749-0711A	Upper Handle

Model Series 140




Ref. No.	Part No.	Part Description
1.	710-0157	Hex Screw 5/16-24 x 0.75"
2.	710-0805	Hex Screw 5/16-18 x 1.5"
3.	710-1652	Self-Tapping Screw 1/4-20 x .625"
4.	726-0205	Hose Clamp
5.	736-0119	Lock Washer
6.	736-0242	Belleville Washer
7.	750-0589	Spacer
8.	750-0716	Spacer
9.	751-0352	Gas Tank : 1 quart
10.	751-0535	Fuel Line Hose
11.	754-0367	V-Belt
12.	756-0416B	V-Pulley Half
13.	756-0550	V-Pulley
14.	784-5177	Engine Support Bracket
—	OEM-390-996	Electric Start Kit (Optional)

Models 150 through 172, E150 through E172



Ref. No.	Part No.	Part Description
1.	629-0236	Extension Cord
		*Electric start models only
2.	705-5139A	Support Bracket: Gas Tank
3.	710-0157	Hex Screw 5/16-24 x .75"
4.	710-1003	Special Screw
5.	710-1652	Self-Tapping Screw
6.	710-3013	Hex Screw 1/4-20 x .50"
7.	710-3025	Hex Screw 5/16-24 x .625
8.	726-0152	Mounting Clamp
9.	726-0205	Hose Clamp
10.	731-2113A	Cup
11.	736-0119	Lock Washer
12.	736-0242	Belleville Washer
13.	736-0329	Lock Washer
14.	741-0475	Plastic Bushing
15.	—	Recoil Handle
		**Obtain from engine manufacturer
16.	751-0535	Fuel Line Hose
17.	751-0540A	Fuel Tank: 2 Quart
18.	751-0800	Fuel Cap
19.	754-0101A	V-Belt
20.	756-0416B	V-Pulley Half
21.	756-0475	Pulley
—	OEM-390-996	Electric Start Kit (Optional)


Models 140 and E142



Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	684-0056	Dash—21"	16.	736-0185	Flat Washer
2.	710-1090	Hex Flange Screw	17.	736-0225	Internal Lock Washer
3.	710-0895	Hex Tap Screw	18.	736-0400	Flat Washer
4.	710-1268	Hex Tap Screw	20.	741-0475	Bushing
5.	712-0252	Hex Nut	21.	784-5178A	Bracket, Chute Crank
6.	712-3010	Hex Nut	22.	784-5344	Crank Assembly, Chute
7.	714-0104	Cotter Pin	23.	714-0111	Cotter Pin †
9.	720-0201A	Chute Crank Knob	24.	747-0737	Chute Crank—Upper †
10.	725-0201	Key—Ignition	26.	684-0126	Chute Crank—Lower †
11.	725-1425	Switch—Key	27.	750-0785	Spacer †
12.	726-0100	Nut Push	29.	735-0234	Grommet - Rubber †
13.	731-0702	Shroud	30.	747-0697	Eyebolt - Chute Crank †
14.	731-1133B	Plug	31.	712-3010	Nut - Hex †
15.	736-0119	Lock Washer	32.	736-0451	Washer - Saddle †


† Optional chute crank assembly on Model 140 only

Model Series 150 and E150



Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	684-0126	Chute Crank Assembly	15.	726-0100	Push Cap
2.	684-0160	Dash Assembly	16.	731-1089A	Choke Cover
3.	710-1003	Special Screw	17.	731-1133B	Cap
4.	710-1090	Hex Flange Screw	18.	731-1988	Shroud: 21" Yellow
5.	710-1268	Special Screw		731-1087	Shroud: 21" Black
6.	710-1652	Self-Tapping Screw	19.	735-0234	Rubber Grommet
7.	712-0252	Jam Nut	20.	736-0119	Lock Washer
8.	712-3010	Hex Nut: 5/16-18	21.	736-0185	Flat Washer
9.	714-0104	Hairpin Clip	22.	736-0225	Internal Lock Washer
10.	714-0507	Cotter Pin	23.	736-0400	Flat Washer
11.	715-0138	Roll Pin	24.	736-0451	Saddle Washer
12.	720-0201A	Knob	25.	747-0697	Eye Bolt
13.	725-0201	Ignition Key	26.	747-0737	Upper Chute Crank
14.	725-1425	Key Switch	27.	750-0785	Spacer

Models E160 through E172



Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	684-0126	Chute Crank Assembly	15.	725-1347	Ignition Switch Cap
2.	684-0160	Dash Assembly	16.	725-1425	Switch: Recoil Start Key
3.	710-1003	Special Screw	17.	726-0100	Push Cap
4.	710-1090	Hex Flange Screw 5/16-18 x 1.25"	18.	731-1089A	Choke Cover
5.	710-1268	Special Screw	19.	731-1133B	Cap
6.	710-1652	Self-Tapping Screw 1/4-20 x .625"	20.	731-1765	Shroud: 21" Black
7.	712-3010	Hex Nut 5/16-18	21.	735-0234	Rubber Grommet
8.	714-0104	Hairpin Clip	22.	736-0119	Lock Washer: 5/16
9.	714-0507	Cotter Pin	23.	736-0185	Flat Washer: .375 x .738 x .063
10.	715-0138	Roll Pin	24.	736-0225	Int. Lock Washer: 5/8 x 1.058 x .046
11.	720-0201A	Knob: Chute Crank	25.	736-0451	Saddle Washer: 320 ID x .93 OD
12.	725-0201	Ignition Key	26.	747-0697	Eyebolt
	725-1341B	Ignition Key w/o Logo	27.	747-0737	Upper Chute Crank
14.	725-1346	Ignition Switch Nut	28.	750-0785	Spacer