


128 LD

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	545125301	Assy-Cable/Wire Harness	21.	530015814	Screw
2.	545066001	Trigger	22.	530016014	Screw
3.	545062001	Housing-Throttle (RH)	23.	545003902	Screw
4.	530016448	Screw	24.	530015771	Screw
5.	530016449	Screw	25.	530057554	Bracket-Shield
6.	530016454	Spring-Trigger	26.	530096295	Assy-Gearbox
7.	530059804	Lockout-Throttle	27.	537234901	Driver Disc
8.	545045601	Spring-Lockout	28.	537338306	Assy-T25 Cutting Head
9.	545067001	Housing-Throttle (LH)			
10.	545030601	Kit-Switch	Not Shown		
11.	545042201	Handle - Assist			
12.	530015820	Bolt	530031159	Wrench-Hex (5/32")	
13.	545003370	Kit-Driveshaft Upper (Incl. 16, & flex)			
14.	530059185	Clamp - Handle Assist			
15.	530016152	Wingnut			
16.	530016344	Screw			
17.	545132002	Flexshaft			
18.	545180848	Kit-Lower Shaft (Incl. 17)			
19.	545030901	Kit-Shield (Incl. 20,21,24)			
20.	530052286	Limiters - Line			


✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information. (Located at the END of the IPL)

Parts List No. 545192138		Husqvarna ® PARTS LIST	MODEL 128LD (US/CAN)
Date 11/25/08	NEW		Page: 2
NOTE : Illustration may differ from actual model due to design changes.			

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150253	Filter	25.	530016426	Screw	48.	530015768	Locknut
2.	530016101	Nut - Carb. Screw	26.	545029603	Starter Hsg. w/eyelet	49.	530016456	Screw
3.	545084601	Air Box	27.	545029801	Kit - Starter Spring	50.	545017501	Assy - Fan Housing
4.	530057844	Lever - Choke	28.	545029701	Kit - Starter Pulley	51.	530150039	Assy - Clutch Drum
5.	545050402	Kit-Carb. Gasket (Incl 7,61)	29.	530016468	Screw	52.	545050405	Kit - Clutch Assy.
6.	530035596	Adaptor - Carb.	30.	545106301	Assy - Starter Hsg(Incl. 23,24,26,27,28,29)	53.	530057852	Spacer
7.	545081898	Kit - Gasket (foam)	31.	530059780	Isolator - Tank	54.	530039242	Flywheel
8.	530016400	Bolt	32.	530058982	Bolt - Muffler	55.	545054601	Crankcase
9.	545001001	Cylinder	33.	530015241	Screw	56.	545013401	Bearing
10.	952030201	Plug - Spark (RCJ-8Y)	34.	530150440	Shield - Heat	57.	545030001	Kit - Crankshaft
11.	545050403	Kit - Crankshaft seal	35.	530016449	Screw	58.	530015162	Retainer - Piston Pin
12.	530016475	Washer - Starter	36.	545104901	Guard - Muffler	59.	530019283	Ring - Piston
13.	545160301	Spring - Starter Cup	37.	545030501	Kit - Spark Arrestor	60.	545030301	Kit - Piston (Incl. 58,59)
14.	545102303	Assy - Starter Cup	38.	545057501	Assy - Muffler	61.	545081898	Kit - Gasket (adaptor seal)
15.	530059800	Coupling - Starter	39.	545081898	Kit - Gasket-paper met	62.	530015897	Screw
16.	530095646	Assy - Fuel Filter	40.	530015897	Screw	63.	545081850	Kit - Carb. (Incl. 4,5)
17.	545081897	Kit - Fuel Line	41.	545046701	Module - Ignition	64.	530057846	Cover - Air Box
18.	530150350	Assy - Cap w/ret. (Incl. 19)	42.	530039227	Assy - Leadwire	65.	530059796	Assy - Knob
19.	545081898	Kit Gasket O-ring - Fuel Cap	43.	530016456	Screw	66.	545081898	Kit - Gasket (Incl. 5,7,11,19,39,61)
20.	545105105	Assy - Fuel Tank (Incl. 16,17,18,19)	44.	530016463	Washer	67.	545003321	Kit - Decal
21.	530057851	Shroud - Rear	45.	530094189	Washer - Clutch	Not Shown		
22.	530016448	Screw	46.	530016469	Screw	530058709	Bulb-Purge	
23.	545029901	Kit - Rope	47.	530016470	Screw			
24.	530150318	Handle - Starter						

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)