


128LDX

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

Parts List No. 545192135		Husqvarna ® PARTS LIST	MODEL 128LDX (US/CAN)
Date 5/28/09	Replaces 545192135 - 4/22/09		NOTE : Illustration may differ from actual model due to design changes.



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	545125301	Assy-Cable/Wire Harness	20.	530052286	Limiter-Line
2.	545066001	Trigger	21.	530015814	Screw
3.	545062001	Housing-Throttle (RH)	22.	530016014	Screw
4.	530016448	Screw	23.	545003902	Screw
5.	530016449	Screw	24.	537338306	Assy-T25 Cutting Head
6.	530016454	Spring-Trigger	25.	530015771	Screw
7.	530059804	Lockout-Throttle	26.	530057554	Bracket-Shield
8.	545045601	Spring-Lockout	27.	530096295	Assy-Gearbox
9.	545067001	Housing-Throttle (LH)	28.	537234901	Driver Disc
10.	545030601	Kit-Switch			
11.	725238051	Screw			
12.	503879001	Knob			
13.	545144303	Assy - Loop Handle			
14.	503940301	Spacer			
15.	502197101	Nut - Square M6			
16.	545006074	Kit-Driveshaft Upper (Incl. 17, & flex)			
17.	503200725	Screw	530031159	Wrench-Hex (5/32")	
18.	545180849	Kit-Lower Shaft (incl. flex,22,23,26,27)			
19.	545030901	Kit-Shield (Incl. 20,21,25)			


Not Shown

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

Parts List No. 545192135		Husqvarna ® PARTS LIST	MODEL 128LDX (US/CAN)
Date 5/28/09	Replaces 545192135 - 4/22/09		NOTE : Illustration may differ from actual model due to design changes.

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150253	Filter	25.	545186502	Hsg.-Starter w/eyelet	48.	530016469	Screw
2.	530016101	Nut-Carb. Screw	26.	545008087	Kit-Spring	49.	530016470	Screw
3.	530057844	Lever - Choke	27.	545008078	Kit-Starter Pulley	50.	530015768	Nut
4.	530058709	Bulb-Purge	28.	544038802	Spring - Driver	51.	530016456	Screw
5.	545008086	Kit-Carb. Gasket (Incl. 7,64)	29.	544038702	Pulley-Driver	52.	545017501	Assy-Fan Housing
6.	530035596	Adaptor-Carb.	30.	530016468	Screw	53.	530150039	Assy-Clutch Drum
7.	545008084	Foam-Gasket (kit)	31.	545186501	Assy-Starter Hsg.(Incl. 22,23,25,26,27,28,29,30)	54.	530055122	Assy-Clutch
8.	530016400	Bolt	32.	530058982	Bolt-Muffler	55.	530057852	Spacer
9.	952030201	Plug-Spark (RCJ-8Y)	33.	530015241	Screw	56.	530039242	Flywheel
10.	545008084	Seal-Cylinder (kit)	34.	530150440	Shield-Heat	57.	545195601	Crankcase-Cast
11.	545008084	Seal-Crankshaft (kit)	35.	530016449	Screw	58.	545013401	Bearing
12.	503873305	Assy-Starter Pawl	36.	545104901	Guard-Muffler	59.	545195202	Assy-Crankshaft
13.	530095646	Assy-Fuel Filter	37.	545030501	Kit-Spark (Incl. 33)	60.	530015162	Retainer-Piston Pin
14.	530069599	Kit-Fuel Line (Incl. 15)	38.	573031501	Kit-Muffler (Incl. 32,33,37,39)	61.	530019283	Ring-Piston
15.	530023877	Fitting-Fuel line	39.	545008084	Gasket-Paper Met.(kit)	62.	545081814	Kit-Piston (Incl. 60,61)
16.	530150350	Assy-Cap w/ret.(Incl. 17)	40.	530015897	Screw	63.	545008083	Kit-Piston/Cyl.(Incl. 62)
17.	545008084	O-ring - Fuel Cap (kit)	41.	545046701	Module	64.	545008084	Seal-adaptor (kit)
18.	530059780	Isolator-Fuel Tank	42.	530039227	Assy-Leadwire	65.	530015897	Screw
19.	545180870	Kit-Fuel Tank Assy. (Incl. 13,14,15,16,17,18)	43.	530016456	Screw	66.	545081850	Kit-Carb. (Incl. 3,4,5)
20.	530057851	Shroud-Rear	44.	530016463	Washer	67.	545084601	Airbox
21.	530016448	Screw	45.	530094189	Washer-Clutch	68.	530057846	Cover-Air Box
22.	545008079	Kit-Rope	46.	545173401	Bearing - Thrust	69.	530059796	Assy-Knob
23.	545043204	Handle-Starter	47.	530016420	Washer - Thrust	70.	545008084	Kit-Gasket (Incl. 5,7,10,11,17,39,64)
24.	530016426	Screw				71.	545003319	Kit-Decal

↖ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)