

254



1.1996

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt




Remplace

Vervangt


Reemplaza

Ersätter


106 22 70-64

A***compl 501 87 40-06****F****compl 501 86 50-01****J*****compl 503 16 73-01****compl 501 45 54-03**


*compl 501 86 95-09
*compl 501 86 95-08 (USA)




***compl 503 50 39-03**




***compl 506 18 23-71**



***compl 501 86 00-04**




D




E

***compl 501 76 13-10**





H



L

*compl 503 54 16-01







② **501 66 84-01**
Packningssats
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas

N *compl 503 55 85-01


Tillbehör
Accessories
Zubehöre
Accessoires
Accesorios




503 55 86-01 NV 4



503 55 86-02 NV 5



*501 69 17-01




*501 91 14-01




*503 62 12-01

Y



≥ = Up to
Bis
A
Tot
A
T.o.m.

Serial no. ≥ 3450001



Serial no. ≥ 4500497

