


WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530059667	Assy.-Isolator	27.	530056402	Handle-Starter	52.	530047061	Assy.-Clutch Drum w/bearing
2.	530047608	Limiter Strap	28.	530027531	Spring-Recoil	53.	530015611	Washer-Clutch
3.	530059668	Spring-Isolator	29.	530015920	Screw	54.	530014949	Assy. Clutch
4.	530015158	Washer	30.	530015127	Washer-Flywheel	55.	530071259	Kit - Oil Pump (incl. 56,57,59)
5.	530016018	Screw	31.	530047534	Assy-Flywheel	56.	530037820	Gear-Worm Spring
6.	530015843	Screw	32.	530047192	Assy-Fuel Cap	57.	530049477	Elbow-Oil Pickup
7.	545048001	Front Handle	33.	530023877	Fitting-fuel line	58.	530016064	Screw
8.	530015940	Screw	34.	530069216	Kit-Fuel line (large)	59.	530019206	Seal Block
9.	530015814	Screw	35.	530016149	Spring-Switch	60.	530047663	Assy-Oil Pick-up (Incl. 61,62)
10.	530044691	Bar - 14"	36.	530015775	Screw	61.	530038373	Pick-up Oiler
11.	530051538	Chain - 14"	37.	530047581	Cover-Rear Handle	62.	530056533	Filter-Oil
12.	530014381	Kit-Spike (Incl. 13)	38.	530015886	Screw	63.	545139901	Assy.-Chain Brake
13.	530016439	Screw	39.	530015906	Screw	64.	530015917	Nut-Bar Mounting
14.	530016132	Screw	40.	530036098	Throttle Lockout	65.	530015826	Pin-Bar Adjust
15.	530038238	Plate-Bar Mount.	41.	530036097	Trigger-Throttle	66.	530038593	Retainer
16.	530015814	Screw	42.	545025001	Handle - Rear	67.	530069611	Kit-Bar Adjusting (incl. # 65,66)
17.	530029850	Chain Catcher	43.	530071958	Kit-Isolator (Upper)			
18.	530016133	Bolt-Bar	44.	530015875	Screw			
19.	530057236	Assy-Oil Cap	45.	530059668	Spring-Isolator			
20.	530071666	Kit-Oil Vent	46.	530057473	Lever-Switch			
21.	530016134	Nut-Flywheel	47.	530057474	Lever-Choke			
22.	530016080	Screw	48.	530049005	Grommet-Knob			
23.	530037817	Starter Pulley	49.	530015922	Nut-"U"-Type			
24.	530015892	Screw	50.	530058730	Assy-Chassis (fuel lines and caps)			
25.	530049335	Housing-Fan	51.	530015907	Washer-Thrust			
26.	530069232	Kit - Rope						


★ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016153	Screw	21.	530037813	Diffuser-Muffler	38.	545113101	Assy-Crankshaft
2.	530047578	Assy-Cylinder Shield	22.	530036103	Screen-Spark	39.	530047207	Assy-Muffler (Incl. 19,20,21,22,23)
3.	530069247	Kit-Fuel Line (Small)	23.	530016132	Bolt-Muffler			
4.	530071835	Kit-Air Purge (incl. #5)	24.	530047631	Grommet-Throttle Cable			
5.	530015780	Screw	25.	545081885	Kit-Carburetor (WT-891) (Incl. grommet)			
6.	530095646	Assy-Fuel Pick-up	26.	530069608	Gasket-Carb. (kit)			Not Shown
7.	530047442	Strap-Ground	27.	530016386	Screw			
8.	530039167	Ignition Module	28.	530049700	Carb. Adapter			
9.	530015814	Screw	29.	530016187	Screw			
10.	530057475	Assy-Wire Harness	30.	530069608	Gasket-Adaptor(kit)			Manual
11.	530037793	Foam-Air Filter	31.	530037380	Ring-Piston (46cc)			(Euro 1)
12.	530016101	Nut	32.	530015697	Retainer-Piston Pin			(Euro 2)
13.	530057702	Assy-Air Box	33.	545081872	Kit-Piston (46cc) (Incl. 31 & 32)			(Euro 3)
14.	530049244	Grommet-Carb Adjust	34.	530069608	Kit-Engine Gasket (Incl. 20, 26 & 30)			(Euro 4)
15.	530054144	Seal-Carb Adapter	35.	530031135	Scrench			(Euro 5)
16.	952030150	Spark Plug (RCJ-7Y)	36.	530056363	Assy-Seal & Bearing			(Russian)
17.	530016136	Clip-High Tension Lead	37.	530037935	Cap-Crankcase			(Turkish)
18.	545122101	Cylinder (46cc)						545003025 Decal-Warning CE
19.	530049870	Backplate-Muffler						
20.	530069608	Gasket-Muffler(kit)						

✓ = NEW PART NUMBER FOR THIS IPL

* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)